


Green Cell Battery VGP-BPS26 VGP-BPS26A VGP-BPL26 for Sony Vaio PCG-71811M
71911M 71614M

Generuota 2026-08-24



Name	Description
Compatible with these devices	Sony Vaio VPCCB15FH
Compatible with these devices	Sony Vaio VPCCB2Z8E
Compatible with these devices	Sony Vaio VPCCB4S3C
Compatible with these devices	Sony Vaio VPCEG1FGX
Compatible with these devices	Sony Vaio VPCEH12FX
Compatible with these devices	Sony Vaio VPCEH1M8E
Compatible with these devices	Sony Vaio VPCEH2BGN
Compatible with these devices	Sony Vaio VPCEH2L1R
Compatible with these devices	Sony Vaio VPCEH3M1R
Compatible with these devices	Sony Vaio VPCEJ3A4E
Cell technology	Lithium ion
Compatible with these devices	SONY VAIO SVE14A16EC

Name	Description
Compatible with these devices	SONY VAIO SVE14A2C5E
Compatible with these devices	Sony Vaio SVE1412ECXP
Compatible with these devices	Sony Vaio SVE14A15FHB
Compatible with these devices	Sony Vaio SVE14A1V6RW
Compatible with these devices	Sony Vaio SVE14A29CJS
Compatible with these devices	Sony Vaio SVE14A3M1RP
Compatible with these devices	Sony Vaio SVE15115ENW
Compatible with these devices	Sony Vaio SVE1511C1RSI
Compatible with these devices	Sony Vaio SVE1511L1EW
Compatible with these devices	Sony Vaio SVE1511X1EB
Compatible with these devices	Sony Vaio SVE1512A4E
Compatible with these devices	Sony Vaio SVE1512H6EB
Compatible with these devices	Sony Vaio SVE1512SAC
Compatible with these devices	Sony Vaio SVE1513APXS
Compatible with these devices	Sony Vaio SVE1513MCXW
Compatible with these devices	Sony Vaio SVE1711P1E
Compatible with these devices	Sony Vaio SVE1712T1EB

Name	Description
Compatible with these devices	Sony Vaio SVE1713V1RB
Compatible with these devices	Sony Vaio VPCCA2S1E
Compatible with these devices	Sony Vaio VPCCB2
Compatible with these devices	Sony Vaio VPCCB3C5E
Compatible with these devices	Sony Vaio VPCEG13FX
Compatible with these devices	Sony Vaio VPCEG2CFX
Compatible with these devices	Sony Vaio VPCEH190X
Compatible with these devices	Sony Vaio VPCEH2
Compatible with these devices	Sony Vaio VPCEH2F4E
Compatible with these devices	Sony Vaio VPCEH2P1E
Compatible with these devices	Sony Vaio VPCEJ1S1E
Compatible with the following battery models	VGP-BPS26A
Compatible with these devices	SONY VAIO SVE14A25CF
Compatible with these devices	Sony Vaio SVE14119FJP
Compatible with these devices	Sony Vaio SVE14137CCW
Compatible with these devices	Sony Vaio SVE14A1S1EW
Compatible with these devices	Sony Vaio SVE14A25CXS

Name	Description
Compatible with these devices	Sony Vaio SVE14A2V1EW
Compatible with these devices	Sony Vaio SVE14A3V1EP
Compatible with these devices	Sony Vaio SVE15118FW
Compatible with these devices	Sony Vaio SVE1511F1EB
Compatible with these devices	Sony Vaio SVE1511P1E
Compatible with these devices	Sony Vaio SVE15121CF
Compatible with these devices	Sony Vaio SVE1512D4E
Compatible with these devices	Sony Vaio SVE1512KCXS
Compatible with these devices	Sony Vaio SVE1512Y1RB
Compatible with these devices	Sony Vaio SVE1513E1RW
Compatible with these devices	Sony Vaio SVE1513V1ESI
Compatible with these devices	Sony Vaio SVE17125CXB
Compatible with these devices	Sony Vaio SVE1713F1EW
Compatible with these devices	Sony Vaio VPCCA17EC
Compatible with these devices	Sony Vaio VPCCA3S1R
Compatible with these devices	Sony Vaio VPCCB15
Compatible with these devices	Sony Vaio VPCCB2C5E

Name	Description
Compatible with these devices	Sony Vaio VPCCB48EC
Compatible with these devices	Sony Vaio VPCEG16
Compatible with these devices	Sony Vaio VPCEG3AEN
Compatible with these devices	Sony Vaio VPCEH1GGX
Compatible with these devices	Sony Vaio VPCEH25FDP
Compatible with these devices	Sony Vaio VPCEH2IFXB
Compatible with these devices	Sony Vaio VPCEH3F1R
Compatible with these devices	Sony Vaio VPCEJ2BFXB
Compatible with these devices	SONY VAIO SVE14128CC
Compatible with these devices	SONY VAIO SVE14A27CA
Compatible with these devices	Sony Vaio SVE14126CXB
Compatible with these devices	Sony Vaio SVE1413E1RW
Compatible with these devices	Sony Vaio SVE14A1V1EP
Compatible with these devices	Sony Vaio SVE14A27CGH
Compatible with these devices	Sony Vaio SVE14A2X1EB
Compatible with these devices	Sony Vaio SVE15114FJP
Compatible with these devices	Sony Vaio SVE1511AFXS

Name	Description
Compatible with these devices	Sony Vaio SVE1511J1EB
Compatible with these devices	Sony Vaio SVE1511S1ESI
Compatible with these devices	Sony Vaio SVE15123CNB
Compatible with these devices	Sony Vaio SVE1512G4E
Compatible with these devices	Sony Vaio SVE1512NCXB
Compatible with these devices	Sony Vaio SVE15137CGS
Compatible with these devices	Sony Vaio SVE1513K1EW
Compatible with these devices	Sony Vaio SVE151G13M
Compatible with these devices	Sony Vaio SVE1712H1EB
Compatible with these devices	Sony Vaio SVE1713P1RB
Compatible with these devices	Sony Vaio VPCCA1S2C
Compatible with these devices	Sony Vaio VPCCB15FW
Compatible with these devices	Sony Vaio VPCCB3
Compatible with these devices	Sony Vaio VPCCB4S4C
Compatible with these devices	Sony Vaio VPCEG1S1R
Compatible with these devices	Sony Vaio VPCEH13
Compatible with these devices	Sony Vaio VPCEH1M9E

Name	Description
Compatible with these devices	Sony Vaio VPCEH2COE
Compatible with these devices	Sony Vaio VPCEH2L4E
Compatible with these devices	Sony Vaio VPCEH3MFX
Compatible with these devices	Sony Vaio VPCEJ3AJ
Weight	300g
Compatible with these devices	SONY VAIO SVE14A16FA
Compatible with these devices	SONY VAIO SVE14A2S
Compatible with these devices	Sony Vaio SVE1412ECXW
Compatible with these devices	Sony Vaio SVE14A15FNB
Compatible with these devices	Sony Vaio SVE14A1X1EH
Compatible with these devices	Sony Vaio SVE14A2M1EB
Compatible with these devices	Sony Vaio SVE14A3M1RW
Compatible with these devices	Sony Vaio SVE15117FN
Compatible with these devices	Sony Vaio SVE1511C1RW
Compatible with these devices	Sony Vaio SVE1511M1E
Compatible with these devices	Sony Vaio SVE1511X1ESI
Compatible with these devices	Sony Vaio SVE1512AJ

Name	Description
Compatible with these devices	Sony Vaio SVE1512H6EW
Compatible with these devices	Sony Vaio SVE1512SCC
Compatible with these devices	Sony Vaio SVE1513B1EW
Compatible with these devices	Sony Vaio SVE1513MPXS
Compatible with these devices	Sony Vaio SVE1711P1EW
Compatible with these devices	Sony Vaio SVE1712Z1RB
Compatible with these devices	Sony Vaio SVE171C11T
Compatible with these devices	Sony Vaio VPCCA2S1R
Compatible with these devices	Sony Vaio VPCCB22FDB
Compatible with these devices	Sony Vaio VPCCB3M1E
Compatible with these devices	Sony Vaio VPCEG14
Compatible with these devices	Sony Vaio VPCEG2DFX
Compatible with these devices	Sony Vaio VPCEH1AFX
Compatible with these devices	Sony Vaio VPCEH23FDB
Compatible with these devices	Sony Vaio VPCEH2FGX
Compatible with these devices	Sony Vaio VPCEH38FN
Compatible with these devices	Sony Vaio VPCEJ1Z1E

Name	Description
Compatible with these devices	Sony Vaio VPCEL2S1E
Compatible with these devices	SONY VAIO SVE14A25CG
Compatible with these devices	Sony Vaio SVE14119FJW
Compatible with these devices	Sony Vaio SVE14137CXB
Compatible with these devices	Sony Vaio SVE14A1S1RB
Compatible with these devices	Sony Vaio SVE14A26CAH
Compatible with these devices	Sony Vaio SVE14A2V1RB
Compatible with these devices	Sony Vaio SVE14A3V1EW
Compatible with these devices	Sony Vaio SVE151190X
Compatible with these devices	Sony Vaio SVE1511F1ESI
Compatible with these devices	Sony Vaio SVE1511P1EW
Compatible with these devices	Sony Vaio SVE15121CFB
Compatible with these devices	Sony Vaio SVE1512E1EB
Compatible with these devices	Sony Vaio SVE1512L1RW
Compatible with these devices	Sony Vaio SVE1512Z1EB
Compatible with these devices	Sony Vaio SVE1513E4E
Compatible with these devices	Sony Vaio SVE1513W1EB

Name	Description
Compatible with these devices	Sony Vaio SVE17127CXB
Compatible with these devices	Sony Vaio SVE1713F4E
Compatible with these devices	Sony Vaio VPCCA18EC
Compatible with these devices	Sony Vaio VPCCA3S6C
Compatible with these devices	Sony Vaio VPCCB15FA
Compatible with these devices	Sony Vaio VPCCB2M0E
Compatible with these devices	Sony Vaio VPCCB48FJ
Compatible with these devices	Sony Vaio VPCEG16EC
Compatible with these devices	Sony Vaio VPCEG3AGX
Compatible with these devices	Sony Vaio VPCEH1J1E
Compatible with these devices	Sony Vaio VPCEH25FDW
Compatible with these devices	Sony Vaio VPCEH2IFXW
Compatible with these devices	Sony Vaio VPCEH3G1E
Compatible with these devices	Sony Vaio VPCEJ2C4E
Compatible with these devices	SONY VAIO SVE14128CH
Compatible with these devices	SONY VAIO SVE14A27CC
Compatible with these devices	Sony Vaio SVE14126CXP

Name	Description
Compatible with these devices	Sony Vaio SVE1413RCXB
Compatible with these devices	Sony Vaio SVE14A1V1EW
Compatible with these devices	Sony Vaio SVE14A27CJW
Compatible with these devices	Sony Vaio SVE14A2X1EH
Compatible with these devices	Sony Vaio SVE15114FJW
Compatible with these devices	Sony Vaio SVE1511AJ
Compatible with these devices	Sony Vaio SVE1511J1ESI
Compatible with these devices	Sony Vaio SVE1511V1E
Compatible with these devices	Sony Vaio SVE15123CV
Compatible with these devices	Sony Vaio SVE1512GCXS
Compatible with these devices	Sony Vaio SVE1512P1EB
Compatible with these devices	Sony Vaio SVE15137CGW
Compatible with these devices	Sony Vaio SVE1513KCXS
Compatible with these devices	Sony Vaio SVE151G13T
Compatible with these devices	Sony Vaio SVE1712H1EW
Compatible with these devices	Sony Vaio SVE1713P4E
Compatible with these devices	Sony Vaio VPCCA1S3C

Name	Description
Compatible with these devices	Sony Vaio VPCCB15FX
Compatible with these devices	Sony Vaio VPCCB32FDR
Compatible with these devices	Sony Vaio VPCCB4S5C
Compatible with these devices	Sony Vaio VPCEG2
Compatible with these devices	Sony Vaio VPCEH13FX
Compatible with these devices	Sony Vaio VPCEH1M9R
Compatible with these devices	Sony Vaio VPCEH2C1E
Compatible with these devices	Sony Vaio VPCEH2L9E
Compatible with these devices	Sony Vaio VPCEH3N1E
Compatible with these devices	Sony Vaio VPCEJ3B1E
Voltage	11.1V (10.8V)
Compatible with these devices	SONY VAIO SVE14A16FG
Compatible with these devices	SONY VAIO SVE14A2S1C
Compatible with these devices	Sony Vaio SVE14132CXB
Compatible with these devices	Sony Vaio SVE14A15FXB
Compatible with these devices	Sony Vaio SVE14A1X1ES
Compatible with these devices	Sony Vaio SVE14A2M1EP

Name	Description
Compatible with these devices	Sony Vaio SVE14A3M2ES
Compatible with these devices	Sony Vaio SVE15117FNB
Compatible with these devices	Sony Vaio SVE1511C4E
Compatible with these devices	Sony Vaio SVE1511M1EB
Compatible with these devices	Sony Vaio SVE1511X1RB
Compatible with these devices	Sony Vaio SVE1512B1EW
Compatible with these devices	Sony Vaio SVE1512HCXS
Compatible with these devices	Sony Vaio SVE1512SDC
Compatible with these devices	Sony Vaio SVE1513B4E
Compatible with these devices	Sony Vaio SVE1513N1EW
Compatible with these devices	Sony Vaio SVE1711Q1E
Compatible with these devices	Sony Vaio SVE171390X
Compatible with these devices	Sony Vaio SVE171C4E
Compatible with these devices	Sony Vaio VPCCA2SFX
Compatible with these devices	Sony Vaio VPCCB22FDW
Compatible with these devices	Sony Vaio VPCCB3P1E
Compatible with these devices	Sony Vaio VPCEG14FJ

Name	Description
Compatible with these devices	Sony Vaio VPCEG37FM
Compatible with these devices	Sony Vaio VPCEH1AJ
Compatible with these devices	Sony Vaio VPCEH23FDL
Compatible with these devices	Sony Vaio VPCEH2G4E
Compatible with these devices	Sony Vaio VPCEH38FW
Compatible with these devices	Sony Vaio VPCEJ2A4E
Compatible with these devices	SONY VAIO SVE14121CV
Compatible with these devices	SONY VAIO SVE14A25CH
Compatible with these devices	Sony Vaio SVE14121CVW
Compatible with these devices	Sony Vaio SVE14138CCB
Compatible with these devices	Sony Vaio SVE14A1S1RP
Compatible with these devices	Sony Vaio SVE14A26CCB
Compatible with these devices	Sony Vaio SVE14A2V1RP
Compatible with these devices	Sony Vaio SVE14A3V1RB
Compatible with these devices	Sony Vaio SVE15119FJB
Compatible with these devices	Sony Vaio SVE1511F1EW
Compatible with these devices	Sony Vaio SVE1511PGX

Name	Description
Compatible with these devices	Sony Vaio SVE15121CV
Compatible with these devices	Sony Vaio SVE1512E1ESI
Compatible with these devices	Sony Vaio SVE1512M1EW
Compatible with these devices	Sony Vaio SVE15134CXP
Compatible with these devices	Sony Vaio SVE1513E9EB
Compatible with these devices	Sony Vaio SVE1513W1ESI
Compatible with these devices	Sony Vaio SVE171290X
Compatible with these devices	Sony Vaio SVE1713G1EW
Compatible with these devices	Sony Vaio VPCCA190
Compatible with these devices	Sony Vaio VPCCA3SFX
Compatible with these devices	Sony Vaio VPCCB15FDB
Compatible with these devices	Sony Vaio VPCCB2M1E
Compatible with these devices	Sony Vaio VPCCB490X
Compatible with these devices	Sony Vaio VPCEG16EG
Compatible with these devices	Sony Vaio VPCEG3AJ
Compatible with these devices	Sony Vaio VPCEH1J8E
Compatible with these devices	Sony Vaio VPCEH2A4E

Name	Description
Compatible with these devices	Sony Vaio VPCEH2J1E
Compatible with these devices	Sony Vaio VPCEH3H1E
Compatible with these devices	Sony Vaio VPCEJ2C5E
Compatible with these devices	SONY VAIO SVE14128CV
Compatible with these devices	SONY VAIO SVE14A27CG
Compatible with these devices	Sony Vaio SVE14126CXW
Compatible with these devices	Sony Vaio SVE1413RCXP
Compatible with these devices	Sony Vaio SVE14A1V1RB
Compatible with these devices	Sony Vaio SVE14A27CNH
Compatible with these devices	Sony Vaio SVE14A2X1EP
Compatible with these devices	Sony Vaio SVE15114FXS
Compatible with these devices	Sony Vaio SVE1511B1E
Compatible with these devices	Sony Vaio SVE1511J1EW
Compatible with these devices	Sony Vaio SVE1511V1EW
Compatible with these devices	Sony Vaio SVE15123CVW
Compatible with these devices	Sony Vaio SVE1512GCXW
Compatible with these devices	Sony Vaio SVE1512Q1EW

Name	Description
Compatible with these devices	Sony Vaio SVE15137CXS
Compatible with these devices	Sony Vaio SVE1513L1ESI
Compatible with these devices	Sony Vaio SVE17115FG
Compatible with these devices	Sony Vaio SVE1712K1EW
Compatible with these devices	Sony Vaio SVE1713Q1EB
Compatible with these devices	Sony Vaio VPCCA1SLE
Compatible with these devices	Sony Vaio VPCCB16
Compatible with these devices	Sony Vaio VPCCB32FDW
Compatible with these devices	Sony Vaio VPCCB4S6C
Compatible with these devices	Sony Vaio VPCEG25FDB
Compatible with these devices	Sony Vaio VPCEH14FM
Compatible with these devices	Sony Vaio VPCEH1S0E
Compatible with these devices	Sony Vaio VPCEH2DFX
Compatible with these devices	Sony Vaio VPCEH2LGX
Compatible with these devices	Sony Vaio VPCEJ15FG
Compatible with these devices	Sony Vaio VPCEJ3C5E
Item code	SY08

Name	Description
Compatible with these devices	SONY VAIO SVE14A16FN
Compatible with these devices	SONY VAIO SVE14A37CX
Compatible with these devices	Sony Vaio SVE14132CXP
Compatible with these devices	Sony Vaio SVE14A15FXS
Compatible with these devices	Sony Vaio SVE14A1X1RH
Compatible with these devices	Sony Vaio SVE14A2M1EW
Compatible with these devices	Sony Vaio SVE14A3M2RS
Compatible with these devices	Sony Vaio SVE15117FW
Compatible with these devices	Sony Vaio SVE1511C5E
Compatible with these devices	Sony Vaio SVE1511M1ESI
Compatible with these devices	Sony Vaio SVE1511X1RSI
Compatible with these devices	Sony Vaio SVE1512B4E
Compatible with these devices	Sony Vaio SVE1512I1ESI
Compatible with these devices	Sony Vaio SVE1512T1ESI
Compatible with these devices	Sony Vaio SVE1513BCXS
Compatible with these devices	Sony Vaio SVE1513O9ESI
Compatible with these devices	Sony Vaio SVE1711Q1EB

Name	Description
Compatible with these devices	Sony Vaio SVE1713A1EB
Compatible with these devices	Sony Vaio SVE171D4E
Compatible with these devices	Sony Vaio VPCCA2Z0E
Compatible with these devices	Sony Vaio VPCCB26EC
Compatible with these devices	Sony Vaio VPCCB3S1E
Compatible with these devices	Sony Vaio VPCEG14FX
Compatible with these devices	Sony Vaio VPCEG37YC
Compatible with these devices	Sony Vaio VPCEH1BFX
Compatible with these devices	Sony Vaio VPCEH23FDP
Compatible with these devices	Sony Vaio VPCEH2GGX
Compatible with these devices	Sony Vaio VPCEH39FJ
Compatible with these devices	Sony Vaio VPCEJ2A9E
Compatible with these devices	SONY VAIO SVE14122CA
Compatible with these devices	SONY VAIO SVE14A25CV
Compatible with these devices	Sony Vaio SVE14122CAB
Compatible with these devices	Sony Vaio SVE14138CCW
Compatible with these devices	Sony Vaio SVE14A1S1RW

Name	Description
Compatible with these devices	Sony Vaio SVE14A26CCP
Compatible with these devices	Sony Vaio SVE14A2V1RPI
Compatible with these devices	Sony Vaio SVE14A3V1RW
Compatible with these devices	Sony Vaio SVE15119FJP
Compatible with these devices	Sony Vaio SVE1511G1ESI
Compatible with these devices	Sony Vaio SVE1511Q1E
Compatible with these devices	Sony Vaio SVE15121CVB
Compatible with these devices	Sony Vaio SVE1512E1EW
Compatible with these devices	Sony Vaio SVE1512M6EB
Compatible with these devices	Sony Vaio SVE15134CXS
Compatible with these devices	Sony Vaio SVE1513F1EB
Compatible with these devices	Sony Vaio SVE1513W1RB
Compatible with these devices	Sony Vaio SVE17129CC
Compatible with these devices	Sony Vaio SVE1713G4E
Compatible with these devices	Sony Vaio VPCCA1AFJ
Compatible with these devices	Sony Vaio VPCCA3X1R
Compatible with these devices	Sony Vaio VPCCB15FDD

Name	Description
Compatible with these devices	Sony Vaio VPCCB2M8E
Compatible with these devices	Sony Vaio VPCCB4AJ
Compatible with these devices	Sony Vaio VPCEG18EC
Compatible with these devices	Sony Vaio VPCEG3BFX
Compatible with these devices	Sony Vaio VPCEH1LOE
Compatible with these devices	Sony Vaio VPCEH2A9E
Compatible with these devices	Sony Vaio VPCEH2J1R
Compatible with these devices	Sony Vaio VPCEH3HFX
Compatible with these devices	Sony Vaio VPCEJ2D1E
CAPACITY	4400 mAh
Compatible with these devices	SONY VAIO SVE14128CW
Compatible with these devices	SONY VAIO SVE14A27CN
Compatible with these devices	Sony Vaio SVE14127CCB
Compatible with these devices	Sony Vaio SVE1413RCXW
Compatible with these devices	Sony Vaio SVE14A1V1RP
Compatible with these devices	Sony Vaio SVE14A27CVH
Compatible with these devices	Sony Vaio SVE14A2X1EW

Name	Description
Compatible with these devices	Sony Vaio SVE15115EA
Compatible with these devices	Sony Vaio SVE1511B1EB
Compatible with these devices	Sony Vaio SVE1511JFXW
Compatible with these devices	Sony Vaio SVE1511V1RB
Compatible with these devices	Sony Vaio SVE15124CXP
Compatible with these devices	Sony Vaio SVE1512H1EB
Compatible with these devices	Sony Vaio SVE1512Q1RB
Compatible with these devices	Sony Vaio SVE15137CXW
Compatible with these devices	Sony Vaio SVE1513L1EW
Compatible with these devices	Sony Vaio SVE17115FGB
Compatible with these devices	Sony Vaio SVE1712L1EB
Compatible with these devices	Sony Vaio SVE1713R1EB
Compatible with these devices	Sony Vaio VPCCA2
Compatible with these devices	Sony Vaio VPCCB17EC
Compatible with these devices	Sony Vaio VPCCB35FG
Compatible with these devices	Sony Vaio VPCCB457C
Compatible with these devices	Sony Vaio VPCEG25FDP

Name	Description
Compatible with these devices	Sony Vaio VPCEH15
Compatible with these devices	Sony Vaio VPCEH1S1E
Compatible with these devices	Sony Vaio VPCEH2DFXB
Compatible with these devices	Sony Vaio VPCEH2MOE
Compatible with these devices	Sony Vaio VPCEJ15FGB
Compatible with these devices	Sony Vaio VPCEL13FDW
Compatible with the following battery models	VGP-BPS26
Compatible with these devices	SONY VAIO SVE14A17EC
Compatible with these devices	SONY VAIO SVE14A3C5E
Compatible with these devices	Sony Vaio SVE14132CXW
Compatible with these devices	Sony Vaio SVE14A15FXW
Compatible with these devices	Sony Vaio SVE14A1X1RS
Compatible with these devices	Sony Vaio SVE14A2M1RW
Compatible with these devices	Sony Vaio SVE14A3M6EB
Compatible with these devices	Sony Vaio SVE15118EC
Compatible with these devices	Sony Vaio SVE1511CFXS
Compatible with these devices	Sony Vaio SVE1511MFXS

Name	Description
Compatible with these devices	Sony Vaio SVE1511X1RW
Compatible with these devices	Sony Vaio SVE1512C1RB
Compatible with these devices	Sony Vaio SVE1512J1EW
Compatible with these devices	Sony Vaio SVE1512U1ESI
Compatible with these devices	Sony Vaio SVE1513C1EB
Compatible with these devices	Sony Vaio SVE1513P1EW
Compatible with these devices	Sony Vaio SVE1711Q1RB
Compatible with these devices	Sony Vaio SVE1713A1EW
Compatible with these devices	Sony Vaio VPCCA1
Compatible with these devices	Sony Vaio VPCCA3
Compatible with these devices	Sony Vaio VPCCB27FDL
Compatible with these devices	Sony Vaio VPCCB3S1R
Compatible with these devices	Sony Vaio VPCEG15
Compatible with these devices	Sony Vaio VPCEG38EC
Compatible with these devices	Sony Vaio VPCEH1C5E
Compatible with these devices	Sony Vaio VPCEH23FDW
Compatible with these devices	Sony Vaio VPCEH2H1E

Name	Description
Compatible with these devices	Sony Vaio VPCEH3C5E
Compatible with these devices	Sony Vaio VPCEJ2AFX
Compatible with these devices	SONY VAIO SVE14122CG
Compatible with these devices	SONY VAIO SVE14A26CA
Compatible with these devices	Sony Vaio SVE14122CHW
Compatible with these devices	Sony Vaio SVE1413APXB
Compatible with these devices	Sony Vaio SVE14A1S6EB
Compatible with these devices	Sony Vaio SVE14A26CFH
Compatible with these devices	Sony Vaio SVE14A2V1RW
Compatible with these devices	Sony Vaio SVE14A3V2ES
Compatible with these devices	Sony Vaio SVE15119FJW
Compatible with these devices	Sony Vaio SVE1511G1EW
Compatible with these devices	Sony Vaio SVE1511Q1EB
Compatible with these devices	Sony Vaio SVE15122CA
Compatible with these devices	Sony Vaio SVE1512E4E
Compatible with these devices	Sony Vaio SVE1512M6ESI
Compatible with these devices	Sony Vaio SVE15134CXW

Name	Description
Compatible with these devices	Sony Vaio SVE1513H4E
Compatible with these devices	Sony Vaio SVE1513X9RB
Compatible with these devices	Sony Vaio SVE1712A4E
Compatible with these devices	Sony Vaio SVE1713M1EB
Compatible with these devices	Sony Vaio VPCCA1AGJ
Compatible with these devices	Sony Vaio VPCCA4AJ
Compatible with these devices	Sony Vaio VPCCB15FDG
Compatible with these devices	Sony Vaio VPCCB2S1C
Compatible with these devices	Sony Vaio VPCCB4C5E
Compatible with these devices	Sony Vaio VPCEG190X
Compatible with these devices	Sony Vaio VPCEG3BGX
Compatible with these devices	Sony Vaio VPCEH1L1R
Compatible with these devices	Sony Vaio VPCEH2AFX
Compatible with these devices	Sony Vaio VPCEH2J4E
Compatible with these devices	Sony Vaio VPCEH3J1E
Delivery from	0 PLN
Warranty	12 months

Name	Description
Compatible with these devices	SONY VAIO SVE14135CG
Compatible with these devices	SONY VAIO SVE14A27CV
Compatible with these devices	Sony Vaio SVE14127CNW
Compatible with these devices	Sony Vaio SVE1413TCXB
Compatible with these devices	Sony Vaio SVE14A1V1RW
Compatible with these devices	Sony Vaio SVE14A27CXH
Compatible with these devices	Sony Vaio SVE14A2X2ES
Compatible with these devices	Sony Vaio SVE15115EAB
Compatible with these devices	Sony Vaio SVE1511B1EW
Compatible with these devices	Sony Vaio SVE1511K1E
Compatible with these devices	Sony Vaio SVE1511V1RSI
Compatible with these devices	Sony Vaio SVE15124CXS
Compatible with these devices	Sony Vaio SVE1512H1ESI
Compatible with these devices	Sony Vaio SVE1512Q1RW
Compatible with these devices	Sony Vaio SVE15138CCW
Compatible with these devices	Sony Vaio SVE1513L1RB
Compatible with these devices	Sony Vaio SVE1711A4E

Name	Description
Compatible with these devices	Sony Vaio SVE1712P1EB
Compatible with these devices	Sony Vaio SVE1713S1EW
Compatible with these devices	Sony Vaio VPCCA26EC
Compatible with these devices	Sony Vaio VPCCB17FG
Compatible with these devices	Sony Vaio VPCCB37FDP
Compatible with these devices	Sony Vaio VPCCB4SFX
Compatible with these devices	Sony Vaio VPCEG25FDW
Compatible with these devices	Sony Vaio VPCEH15EG
Compatible with these devices	Sony Vaio VPCEH1S1R
Compatible with these devices	Sony Vaio VPCEH2EOE
Compatible with these devices	Sony Vaio VPCEH2M1E
Compatible with these devices	Sony Vaio VPCEJ1J1E
Compatible with these devices	Sony Vaio VPCEL15EC
Compatible with the following battery models	VGP-BPL26
Compatible with these devices	SONY VAIO SVE14A18EC
Compatible with these devices	Sony Vaio SVE11113FXB
Compatible with these devices	Sony Vaio SVE14132PXB

Name	Description
Compatible with these devices	Sony Vaio SVE14A16FAH
Compatible with these devices	Sony Vaio SVE14A25CAPI
Compatible with these devices	Sony Vaio SVE14A2M2RS
Compatible with these devices	Sony Vaio SVE14A3M6EP
Compatible with these devices	Sony Vaio SVE15118FA
Compatible with these devices	Sony Vaio SVE1511D1E
Compatible with these devices	Sony Vaio SVE1511N1EB
Compatible with these devices	Sony Vaio SVE1511Y1E
Compatible with these devices	Sony Vaio SVE1512C4E
Compatible with these devices	Sony Vaio SVE1512J6EB
Compatible with these devices	Sony Vaio SVE1512W1EB
Compatible with these devices	Sony Vaio SVE1513C1EW
Compatible with these devices	Sony Vaio SVE1513P1RB
Compatible with these devices	Sony Vaio SVE1711Z1RB
Compatible with these devices	Sony Vaio SVE1713A4E
Compatible with these devices	Sony Vaio VPCCA15
Compatible with these devices	Sony Vaio VPCCA3AFX

Name	Description
Compatible with these devices	Sony Vaio VPCCB28EC
Compatible with these devices	Sony Vaio VPCCB3S8E
Compatible with these devices	Sony Vaio VPCEG15EA
Compatible with these devices	Sony Vaio VPCEG38FA
Compatible with these devices	Sony Vaio VPCEH1CFX
Compatible with these devices	Sony Vaio VPCEH24FX
Compatible with these devices	Sony Vaio VPCEH2H4E
Compatible with these devices	Sony Vaio VPCEH3CFX
Compatible with these devices	Sony Vaio VPCEJ2AFXB
Compatible with these devices	SONY VAIO SVE14122CH
Compatible with these devices	SONY VAIO SVE14A26CC
Compatible with these devices	Sony Vaio SVE14122CVW
Compatible with these devices	Sony Vaio SVE1413BCXB
Compatible with these devices	Sony Vaio SVE14A1S6EP
Compatible with these devices	Sony Vaio SVE14A26CGS
Compatible with these devices	Sony Vaio SVE14A2V1RWI
Compatible with these devices	Sony Vaio SVE14A3V2RS

Name	Description
Compatible with these devices	Sony Vaio SVE1511A1E
Compatible with these devices	Sony Vaio SVE1511G4E
Compatible with these devices	Sony Vaio SVE1511Q1ESI
Compatible with these devices	Sony Vaio SVE15122CAW
Compatible with these devices	Sony Vaio SVE1512E6EB
Compatible with these devices	Sony Vaio SVE1512M6EW
Compatible with these devices	Sony Vaio SVE15135CXP
Compatible with these devices	Sony Vaio SVE1513HCXS
Compatible with these devices	Sony Vaio SVE1513Y1ESI
Compatible with these devices	Sony Vaio SVE1712ACXB
Compatible with these devices	Sony Vaio SVE1713M1RW
Compatible with these devices	Sony Vaio VPCCA1AHJ
Compatible with these devices	Sony Vaio VPCCA4C5E
Compatible with these devices	Sony Vaio VPCCB15FDP
Compatible with these devices	Sony Vaio VPCCB2S1E
Compatible with these devices	Sony Vaio VPCCB4M1E
Compatible with these devices	Sony Vaio VPCEG1AFX

Name	Description
Compatible with these devices	Sony Vaio VPCEG3PFX
Compatible with these devices	Sony Vaio VPCEH1L8E
Compatible with these devices	Sony Vaio VPCEH2AJ
Compatible with these devices	Sony Vaio VPCEH2J9R
Compatible with these devices	Sony Vaio VPCEH3J1R
Compatible with these devices	Sony Vaio VPCEJ2E1E
Size	270x50x21 mm
Compatible with these devices	SONY VAIO SVE14A15FA
Compatible with these devices	SONY VAIO SVE14A28CC
Compatible with these devices	Sony Vaio SVE14128CCB
Compatible with these devices	Sony Vaio SVE1413TCXP
Compatible with these devices	Sony Vaio SVE14A1V6EB
Compatible with these devices	Sony Vaio SVE14A28CCH
Compatible with these devices	Sony Vaio SVE14A35CXH
Compatible with these devices	Sony Vaio SVE15115EG
Compatible with these devices	Sony Vaio SVE1511B1RB
Compatible with these devices	Sony Vaio SVE1511K1EB

Name	Description
Compatible with these devices	Sony Vaio SVE1511V1RW
Compatible with these devices	Sony Vaio SVE15124CXW
Compatible with these devices	Sony Vaio SVE1512H1EW
Compatible with these devices	Sony Vaio SVE1512R1EW
Compatible with these devices	Sony Vaio SVE15138CXS
Compatible with these devices	Sony Vaio SVE1513L1RW
Compatible with these devices	Sony Vaio SVE1711AJ
Compatible with these devices	Sony Vaio SVE1712P1RB
Compatible with these devices	Sony Vaio SVE1713S1RB
Compatible with these devices	Sony Vaio VPCCA27EC
Compatible with these devices	Sony Vaio VPCCB17FGB
Compatible with these devices	Sony Vaio VPCCB37FDR
Compatible with these devices	Sony Vaio VPCCB4X1E
Compatible with these devices	Sony Vaio VPCEG290X
Compatible with these devices	Sony Vaio VPCEH15EN
Compatible with these devices	Sony Vaio VPCEH1S8E
Compatible with these devices	Sony Vaio VPCEH2E1R

Name	Description
Compatible with these devices	Sony Vaio VPCEH2M1R
Compatible with these devices	Sony Vaio VPCEJ1L1E
Compatible with these devices	Sony Vaio VPCEL16FGB
Cell manufacturer	Greencell
Compatible with these devices	SONY VAIO SVE14A18FJ
Compatible with these devices	Sony Vaio SVE11113FXW
Compatible with these devices	Sony Vaio SVE14135CGW
Compatible with these devices	Sony Vaio SVE14A16FGH
Compatible with these devices	Sony Vaio SVE14A25CFB
Compatible with these devices	Sony Vaio SVE14A2M6EB
Compatible with these devices	Sony Vaio SVE14A3M6EW
Compatible with these devices	Sony Vaio SVE15118FAB
Compatible with these devices	Sony Vaio SVE1511D1EW
Compatible with these devices	Sony Vaio SVE1511N1ESI
Compatible with these devices	Sony Vaio SVE1511Y1ESI
Compatible with these devices	Sony Vaio SVE1512C5E
Compatible with these devices	Sony Vaio SVE1512J6ESI

Name	Description
Compatible with these devices	Sony Vaio SVE1512W1ESI
Compatible with these devices	Sony Vaio SVE1513C4E
Compatible with these devices	Sony Vaio SVE1513P1RSI
Compatible with these devices	Sony Vaio SVE17122CXB
Compatible with these devices	Sony Vaio SVE1713A4RB
Compatible with these devices	Sony Vaio VPCCA15FA
Compatible with these devices	Sony Vaio VPCCA3AJ
Compatible with these devices	Sony Vaio VPCCB290X
Compatible with these devices	Sony Vaio VPCCB3Z8E
Compatible with these devices	Sony Vaio VPCEG15EG
Compatible with these devices	Sony Vaio VPCEG38FG
Compatible with these devices	Sony Vaio VPCEH1DFX
Compatible with these devices	Sony Vaio VPCEH25
Compatible with these devices	Sony Vaio VPCEH2HFX
Compatible with these devices	Sony Vaio VPCEH3DOE
Compatible with these devices	Sony Vaio VPCEJ2AJ
Compatible with these devices	SONY VAIO SVE14122CV

Name	Description
Compatible with these devices	SONY VAIO SVE14A26CF
Compatible with these devices	Sony Vaio SVE14I22CXB
Compatible with these devices	Sony Vaio SVE14I3BCXP
Compatible with these devices	Sony Vaio SVE14A1S6EW
Compatible with these devices	Sony Vaio SVE14A26CHS
Compatible with these devices	Sony Vaio SVE14A2V2ES
Compatible with these devices	Sony Vaio SVE14A3X1EB
Compatible with these devices	Sony Vaio SVE15I1A1EB
Compatible with these devices	Sony Vaio SVE15I1GFXW
Compatible with these devices	Sony Vaio SVE15I1R9E
Compatible with these devices	Sony Vaio SVE15I22CXB
Compatible with these devices	Sony Vaio SVE15I2E6EW
Compatible with these devices	Sony Vaio SVE15I2MPXS
Compatible with these devices	Sony Vaio SVE15I3SCXS
Compatible with these devices	Sony Vaio SVE15I3I4E
Compatible with these devices	Sony Vaio SVE15I3Z1EB
Compatible with these devices	Sony Vaio SVE17I2AJ

Name	Description
Compatible with these devices	Sony Vaio SVE1713M4E
Compatible with these devices	Sony Vaio VPCCA1C
Compatible with these devices	Sony Vaio VPCCA4E1E
Compatible with these devices	Sony Vaio VPCCB15FDW
Compatible with these devices	Sony Vaio VPCCB2S1R
Compatible with these devices	Sony Vaio VPCCB4P1E
Compatible with these devices	Sony Vaio VPCEG1AJ
Compatible with these devices	Sony Vaio VPCEG3WFX
Compatible with these devices	Sony Vaio VPCEH1L9E
Compatible with these devices	Sony Vaio VPCEH2B4E
Compatible with these devices	Sony Vaio VPCEH2JFX
Compatible with these devices	Sony Vaio VPCEH3JFX
Compatible with these devices	Sony Vaio VPCEJ2J1E
Protection against overheating	Yes
Compatible with these devices	SONY VAIO SVE14A15FF
Compatible with these devices	SONY VAIO SVE14A29CC
Compatible with these devices	Sony Vaio SVE14128CHB

Name	Description
Compatible with these devices	Sony Vaio SVE14A15FAB
Compatible with these devices	Sony Vaio SVE14A1V6EP
Compatible with these devices	Sony Vaio SVE14A28CJB
Compatible with these devices	Sony Vaio SVE14A3M1EB
Compatible with these devices	Sony Vaio SVE15115EGB
Compatible with these devices	Sony Vaio SVE1511B1RW
Compatible with these devices	Sony Vaio SVE1511K1ESI
Compatible with these devices	Sony Vaio SVE1511W1E
Compatible with these devices	Sony Vaio SVE15125CJW
Compatible with these devices	Sony Vaio SVE1512H1RB
Compatible with these devices	Sony Vaio SVE1512R1RW
Compatible with these devices	Sony Vaio SVE15138CXW
Compatible with these devices	Sony Vaio SVE1513M1EW
Compatible with these devices	Sony Vaio SVE1711B4E
Compatible with these devices	Sony Vaio SVE1712Q1EW
Compatible with these devices	Sony Vaio SVE1713S1RW
Compatible with these devices	Sony Vaio VPCCA28EC

Name	Description
Compatible with these devices	Sony Vaio VPCCB18EC
Compatible with these devices	Sony Vaio VPCCB37FDW
Compatible with these devices	Sony Vaio VPCCB4Z1E
Compatible with these devices	Sony Vaio VPCEG2AEN
Compatible with these devices	Sony Vaio VPCEH16EC
Compatible with these devices	Sony Vaio VPCEH1S9E
Compatible with these devices	Sony Vaio VPCEH2E4E
Compatible with these devices	Sony Vaio VPCEH2M4E
Compatible with these devices	Sony Vaio VPCEJ1L1R
Compatible with these devices	Sony Vaio VPCEL1E1E
Gamintojas	Greencell
Compatible with these devices	SONY VAIO SVE14A19FJ
Compatible with these devices	Sony Vaio SVE11125CXB
Compatible with these devices	Sony Vaio SVE14135CXB
Compatible with these devices	Sony Vaio SVE14A16FNH
Compatible with these devices	Sony Vaio SVE14A25CGWI
Compatible with these devices	Sony Vaio SVE14A2M6EP

Name	Description
Compatible with these devices	Sony Vaio SVE14A3S6EB
Compatible with these devices	Sony Vaio SVE15118FG
Compatible with these devices	Sony Vaio SVE1511D4E
Compatible with these devices	Sony Vaio SVE1511N1RB
Compatible with these devices	Sony Vaio SVE1511Z1E
Compatible with these devices	Sony Vaio SVE1512C6EB
Compatible with these devices	Sony Vaio SVE1512J6EW
Compatible with these devices	Sony Vaio SVE1512W1RB
Compatible with these devices	Sony Vaio SVE1513C5E
Compatible with these devices	Sony Vaio SVE1513P1RW
Compatible with these devices	Sony Vaio SVE17125CG
Compatible with these devices	Sony Vaio SVE1713E1RW
Compatible with these devices	Sony Vaio VPCCA15FF
Compatible with these devices	Sony Vaio VPCCA3C5E
Compatible with these devices	Sony Vaio VPCCB2AFDB
Compatible with these devices	Sony Vaio VPCCB45FN
Compatible with these devices	Sony Vaio VPCEG15EH

Name	Description
Compatible with these devices	Sony Vaio VPCEG38FH
Compatible with these devices	Sony Vaio VPCEH1E1E
Compatible with these devices	Sony Vaio VPCEH25EG
Compatible with these devices	Sony Vaio VPCEH2HFXL
Compatible with these devices	Sony Vaio VPCEH3DGX
Compatible with these devices	Sony Vaio VPCEJ2B1E
Compatible with these devices	SONY VAIO SVE14123CN
Compatible with these devices	SONY VAIO SVE14A26CG
Compatible with these devices	Sony Vaio SVE14122CXP
Compatible with these devices	Sony Vaio SVE1413BCXW
Compatible with these devices	Sony Vaio SVE14A1S6RB
Compatible with these devices	Sony Vaio SVE14A26CVH
Compatible with these devices	Sony Vaio SVE14A2V2RS
Compatible with these devices	Sony Vaio SVE14A3X1EP
Compatible with these devices	Sony Vaio SVE1511A1EW
Compatible with these devices	Sony Vaio SVE1511H1EW
Compatible with these devices	Sony Vaio SVE1511R9EB

Name	Description
Compatible with these devices	Sony Vaio SVE15122CXP
Compatible with these devices	Sony Vaio SVE1512F1RW
Compatible with these devices	Sony Vaio SVE1512N1EB
Compatible with these devices	Sony Vaio SVE15135CXW
Compatible with these devices	Sony Vaio SVE1513J1EB
Compatible with these devices	Sony Vaio SVE1513Z1RB
Compatible with these devices	Sony Vaio SVE1712B4E
Compatible with these devices	Sony Vaio SVE1713N4E
Compatible with these devices	Sony Vaio VPCCA1C5E
Compatible with these devices	Sony Vaio VPCCA4S1E
Compatible with these devices	Sony Vaio VPCCB15FF
Compatible with these devices	Sony Vaio VPCCB2S2C
Compatible with these devices	Sony Vaio VPCCB4Q1E
Compatible with these devices	Sony Vaio VPCEG1BFX
Compatible with these devices	Sony Vaio VPCEH1
Compatible with these devices	Sony Vaio VPCEH1M0E
Compatible with these devices	Sony Vaio VPCEH2BFX

Name	Description
Compatible with these devices	Sony Vaio VPCEH2K1E
Compatible with these devices	Sony Vaio VPCEH3L1E
Compatible with these devices	Sony Vaio VPCEJ2L1E
Overload protection	Yes
Compatible with these devices	SONY VAIO SVE14A15FG
Compatible with these devices	SONY VAIO SVE14A2A4E
Compatible with these devices	Sony Vaio SVE14I28CVW
Compatible with these devices	Sony Vaio SVE14A15FFB
Compatible with these devices	Sony Vaio SVE14A1V6EW
Compatible with these devices	Sony Vaio SVE14A28CJP
Compatible with these devices	Sony Vaio SVE14A3M1EP
Compatible with these devices	Sony Vaio SVE15I15EH
Compatible with these devices	Sony Vaio SVE15I1B4E
Compatible with these devices	Sony Vaio SVE15I1K1EW
Compatible with these devices	Sony Vaio SVE15I1W1EB
Compatible with these devices	Sony Vaio SVE15I25CN
Compatible with these devices	Sony Vaio SVE15I2H1RSI

Name	Description
Compatible with these devices	Sony Vaio SVE1512S
Compatible with these devices	Sony Vaio SVE151390X
Compatible with these devices	Sony Vaio SVE1513M1RW
Compatible with these devices	Sony Vaio SVE1711C5E
Compatible with these devices	Sony Vaio SVE1712S1EB
Compatible with these devices	Sony Vaio SVE1713T1EB
Compatible with these devices	Sony Vaio VPCCA2AJ
Compatible with these devices	Sony Vaio VPCCB1S2C
Compatible with these devices	Sony Vaio VPCCB390X
Compatible with these devices	Sony Vaio VPCEG100C
Compatible with these devices	Sony Vaio VPCEG2AGX
Compatible with these devices	Sony Vaio VPCEH17FG
Compatible with these devices	Sony Vaio VPCEH1Z1E
Compatible with these devices	Sony Vaio VPCEH2EFX
Compatible with these devices	Sony Vaio VPCEH2M9E
Compatible with these devices	Sony Vaio VPCEJ1M1E
COLOUR	

Name	Description
Compatible with these devices	SONY VAIO SVE14A1S1E
Compatible with these devices	Sony Vaio SVE11125CXW
Compatible with these devices	Sony Vaio SVE14135CXP
Compatible with these devices	Sony Vaio SVE14A1M6EW
Compatible with these devices	Sony Vaio SVE14A25CHPI
Compatible with these devices	Sony Vaio SVE14A2M6EW
Compatible with these devices	Sony Vaio SVE14A3S6EP
Compatible with these devices	Sony Vaio SVE15118FGB
Compatible with these devices	Sony Vaio SVE1511DFYS
Compatible with these devices	Sony Vaio SVE1511N1RSI
Compatible with these devices	Sony Vaio SVE1511Z1EB
Compatible with these devices	Sony Vaio SVE1512C6EW
Compatible with these devices	Sony Vaio SVE1512JCXW
Compatible with these devices	Sony Vaio SVE1512X1ESI
Compatible with these devices	Sony Vaio SVE1513D1EW
Compatible with these devices	Sony Vaio SVE1513U1ESI
Compatible with these devices	Sony Vaio SVE17125CGB

Name	Description
Compatible with these devices	Sony Vaio SVE1713E4E
Compatible with these devices	Sony Vaio VPCCA16
Compatible with these devices	Sony Vaio VPCCA3E1E
Compatible with these devices	Sony Vaio VPCCB2AFDW
Compatible with these devices	Sony Vaio VPCCB46EC
Compatible with these devices	Sony Vaio VPCEG15EN
Compatible with these devices	Sony Vaio VPCEG38FN
Compatible with these devices	Sony Vaio VPCEH1E1R
Compatible with these devices	Sony Vaio VPCEH25EN
Compatible with these devices	Sony Vaio VPCEH2HFXP
Compatible with these devices	Sony Vaio VPCEH3E0E
Compatible with these devices	Sony Vaio VPCEJ2B4E
Compatible with these devices	SONY VAIO SVE14125CN
Compatible with these devices	SONY VAIO SVE14A26CH
Compatible with these devices	Sony Vaio SVE14122CXW
Compatible with these devices	Sony Vaio SVE1413CCXP
Compatible with these devices	Sony Vaio SVE14A1S6RP

Name	Description
Compatible with these devices	Sony Vaio SVE14A27CAS
Compatible with these devices	Sony Vaio SVE14A2V6RB
Compatible with these devices	Sony Vaio SVE14A3X1EW
Compatible with these devices	Sony Vaio SVE1511A4E
Compatible with these devices	Sony Vaio SVE1511H4E
Compatible with these devices	Sony Vaio SVE1511R9ESI
Compatible with these devices	Sony Vaio SVE15122CXW
Compatible with these devices	Sony Vaio SVE1512F4E
Compatible with these devices	Sony Vaio SVE1512N1ESI
Compatible with these devices	Sony Vaio SVE15137CG
Compatible with these devices	Sony Vaio SVE1513J1EW
Compatible with these devices	Sony Vaio SVE151E11M
Compatible with these devices	Sony Vaio SVE1712BCXB
Compatible with these devices	Sony Vaio SVE1713N9EB
Compatible with these devices	Sony Vaio VPCCA1S1C
Compatible with these devices	Sony Vaio VPCCA4S1R
Compatible with these devices	Sony Vaio VPCCB15FG

Name	Description
Compatible with these devices	Sony Vaio VPCCB2S8E
Compatible with these devices	Sony Vaio VPCCB4S1C
Compatible with these devices	Sony Vaio VPCEG1DGX
Compatible with these devices	Sony Vaio VPCEH100C
Compatible with these devices	Sony Vaio VPCEH1M1E
Compatible with these devices	Sony Vaio VPCEH2BGA
Compatible with these devices	Sony Vaio VPCEH2K4E
Compatible with these devices	Sony Vaio VPCEH3LFX
Compatible with these devices	Sony Vaio VPCEJ2L1R
A popular model	Yes
Compatible with these devices	SONY VAIO SVE14A15FH
Compatible with these devices	SONY VAIO SVE14A2AJ
Compatible with these devices	Sony Vaio SVE14I2E1RW
Compatible with these devices	Sony Vaio SVE14A15FGB
Compatible with these devices	Sony Vaio SVE14A1V6RB
Compatible with these devices	Sony Vaio SVE14A28CJW
Compatible with these devices	Sony Vaio SVE14A3M1EW

Name	Description
Compatible with these devices	Sony Vaio SVE15115EHW
Compatible with these devices	Sony Vaio SVE1511BGXS
Compatible with these devices	Sony Vaio SVE1511KFXW
Compatible with these devices	Sony Vaio SVE1511W1ESI
Compatible with these devices	Sony Vaio SVE15125CNB
Compatible with these devices	Sony Vaio SVE1512H1RW
Compatible with these devices	Sony Vaio SVE1512S1EW
Compatible with these devices	Sony Vaio SVE1513A1ESI
Compatible with these devices	Sony Vaio SVE1513MCXB
Compatible with these devices	Sony Vaio SVE1711F1E
Compatible with these devices	Sony Vaio SVE1712S1RB
Compatible with these devices	Sony Vaio SVE1713U1EB
Compatible with these devices	Sony Vaio VPCCA2C5E
Compatible with these devices	Sony Vaio VPCCB1S3C
Compatible with these devices	Sony Vaio VPCCB3AFX
Compatible with these devices	Sony Vaio VPCEG11FX
Compatible with these devices	Sony Vaio VPCEG2AJ

Name	Description
Compatible with these devices	Sony Vaio VPCEH17FGL
Compatible with these devices	Sony Vaio VPCEH1Z1R
Compatible with these devices	Sony Vaio VPCEH2EFXB
Compatible with these devices	Sony Vaio VPCEH2N1E
Compatible with these devices	Sony Vaio VPCEJ1M1R
Compatible with these devices	Sony Vaio PCG
Compatible with these devices	SONY VAIO SVE14A23CW
Compatible with these devices	Sony Vaio SVE14118FXW
Compatible with these devices	Sony Vaio SVE14135CXW
Compatible with these devices	Sony Vaio SVE14A1S1EB
Compatible with these devices	Sony Vaio SVE14A25CVPI
Compatible with these devices	Sony Vaio SVE14A2V1EB
Compatible with these devices	Sony Vaio SVE14A3S6EW
Compatible with these devices	Sony Vaio SVE15118FN
Compatible with these devices	Sony Vaio SVE1511E4E
Compatible with these devices	Sony Vaio SVE1511N1RW
Compatible with these devices	Sony Vaio SVE15121CA

Name	Description
Compatible with these devices	Sony Vaio SVE1512D1RB
Compatible with these devices	Sony Vaio SVE1512K1ESI
Compatible with these devices	Sony Vaio SVE1512X9EB
Compatible with these devices	Sony Vaio SVE1513D4E
Compatible with these devices	Sony Vaio SVE1513U1RB
Compatible with these devices	Sony Vaio SVE17125CV
Compatible with these devices	Sony Vaio SVE1713ECXB
Compatible with these devices	Sony Vaio VPCCA16EC
Compatible with these devices	Sony Vaio VPCCA3S
Compatible with these devices	Sony Vaio VPCCB2AFX
Compatible with these devices	Sony Vaio VPCCB46FA
Compatible with these devices	Sony Vaio VPCEG15FX
Compatible with these devices	Sony Vaio VPCEG38FW
Compatible with these devices	Sony Vaio VPCEH1EGX
Compatible with these devices	Sony Vaio VPCEH25FDB
Compatible with these devices	Sony Vaio VPCEH2HFXW
Compatible with these devices	Sony Vaio VPCEH3EGX

Name	Description
Compatible with these devices	Sony Vaio VPCEJ2B9E
Compatible with these devices	SONY VAIO SVE14127CC
Compatible with these devices	SONY VAIO SVE14A26CV
Compatible with these devices	Sony Vaio SVE14123CNB
Compatible with these devices	Sony Vaio SVE1413CCXW
Compatible with these devices	Sony Vaio SVE14A1S6RW
Compatible with these devices	Sony Vaio SVE14A27CCP
Compatible with these devices	Sony Vaio SVE14A2V6RP
Compatible with these devices	Sony Vaio SVE15113FXS
Compatible with these devices	Sony Vaio SVE1511AEN
Compatible with these devices	Sony Vaio SVE1511HFXW
Compatible with these devices	Sony Vaio SVE1511RFXB
Compatible with these devices	Sony Vaio SVE15123CJW
Compatible with these devices	Sony Vaio SVE1512G1RB
Compatible with these devices	Sony Vaio SVE1512N1RB
Compatible with these devices	Sony Vaio SVE15137CGB
Compatible with these devices	Sony Vaio SVE1513JCXW

Name	Description
Compatible with these devices	Sony Vaio SVE151E11T
Compatible with these devices	Sony Vaio SVE1712C1EB
Compatible with these devices	Sony Vaio SVE1713O4E
Compatible with these devices	Sony Vaio VPCCA1S1E
Compatible with these devices	Sony Vaio VPCCA4X1R
Compatible with these devices	Sony Vaio VPCCB15FGD
Compatible with these devices	Sony Vaio VPCCB2SFX
Compatible with these devices	Sony Vaio VPCCB4S1R
Compatible with these devices	Sony Vaio VPCEG1EGX
Compatible with these devices	Sony Vaio VPCEH11FX
Compatible with these devices	Sony Vaio VPCEH1M1R
Compatible with these devices	Sony Vaio VPCEH2BGG
Compatible with these devices	Sony Vaio VPCEH2KFX
Compatible with these devices	Sony Vaio VPCEH3M1E
Compatible with these devices	Sony Vaio VPCEJ2Z1E
Number of cells	6
Compatible with these devices	SONY VAIO SVE14A15FN

Name	Description
Compatible with these devices	SONY VAIO SVE14A2B4E
Compatible with these devices	Sony Vaio SVE1412ECXB
Compatible with these devices	Sony Vaio SVE14A15FGW
Compatible with these devices	Sony Vaio SVE14A1V6RP
Compatible with these devices	Sony Vaio SVE14A29CCH
Compatible with these devices	Sony Vaio SVE14A3M1RB
Compatible with these devices	Sony Vaio SVE15115EN
Compatible with these devices	Sony Vaio SVE1511C1RB
Compatible with these devices	Sony Vaio SVE1511L1E
Compatible with these devices	Sony Vaio SVE1511X1E
Compatible with these devices	Sony Vaio SVE151290X
Compatible with these devices	Sony Vaio SVE1512H4E
Compatible with these devices	Sony Vaio SVE1512S1RW
Compatible with these devices	Sony Vaio SVE1513A4E
Compatible with these devices	Sony Vaio SVE1513MCXS
Compatible with these devices	Sony Vaio SVE1711L1EW
Compatible with these devices	Sony Vaio SVE1712S1RW

Name	Description
Compatible with these devices	Sony Vaio SVE1713V1EB
Compatible with these devices	Sony Vaio VPCCA2S0E
Compatible with these devices	Sony Vaio VPCCB1S4C
Compatible with these devices	Sony Vaio VPCCB3AJ
Compatible with these devices	Sony Vaio VPCEG12FX
Compatible with these devices	Sony Vaio VPCEG2BGX
Compatible with these devices	Sony Vaio VPCEH18FGL
Compatible with these devices	Sony Vaio VPCEH1Z8E
Compatible with these devices	Sony Vaio VPCEH2F1E
Compatible with these devices	Sony Vaio VPCEH2P0E
Compatible with these devices	Sony Vaio VPCEJ1M9E
Compatible with these devices	Sony Vaio VPCEA46FGW
Compatible with these devices	SONY VAIO SVE14A25CA
Compatible with these devices	Sony Vaio SVE14119FJB
Compatible with these devices	Sony Vaio SVE14137CCP
Compatible with these devices	Sony Vaio SVE14A1S1EP
Compatible with these devices	Sony Vaio SVE14A25CXH

Name	Description
Compatible with these devices	Sony Vaio SVE14A2V1EP
Compatible with these devices	Sony Vaio SVE14A3V1EB
Compatible with these devices	Sony Vaio SVE15118FNB
Compatible with these devices	Sony Vaio SVE1511F1E
Compatible with these devices	Sony Vaio SVE1511NFXS
Compatible with these devices	Sony Vaio SVE15121CAB
Compatible with these devices	Sony Vaio SVE1512D1RW
Compatible with these devices	Sony Vaio SVE1512K1RW
Compatible with these devices	Sony Vaio SVE1512Y1ESI
Compatible with these devices	Sony Vaio SVE1513E1RB
Compatible with these devices	Sony Vaio SVE1513U1RW
Compatible with these devices	Sony Vaio SVE17125CVB
Compatible with these devices	Sony Vaio SVE1713F1EB
Compatible with these devices	Sony Vaio VPCCA16FW
Compatible with these devices	Sony Vaio VPCCA3S1E
Compatible with these devices	Sony Vaio VPCCB2AJ
Compatible with these devices	Sony Vaio VPCCB46FG

Name	Description
Compatible with these devices	Sony Vaio VPCEG15YC
Compatible with these devices	Sony Vaio VPCEG390X
Compatible with these devices	Sony Vaio VPCEH1FGX
Compatible with these devices	Sony Vaio VPCEH25FDL
Compatible with these devices	Sony Vaio VPCEH2IFX
Compatible with these devices	Sony Vaio VPCEH3F1E
Compatible with these devices	Sony Vaio VPCEJ2BFX
Compatible with these devices	SONY VAIO SVE14127CN
Compatible with these devices	SONY VAIO SVE14A26CW
Compatible with these devices	Sony Vaio SVE14125CNB
Compatible with these devices	Sony Vaio SVE1413E1RB
Compatible with these devices	Sony Vaio SVE14A1V1EB
Compatible with these devices	Sony Vaio SVE14A27CCW
Compatible with these devices	Sony Vaio SVE14A2V6RW
Compatible with these devices	Sony Vaio SVE15114FJB
Compatible with these devices	Sony Vaio SVE1511AENB
Compatible with these devices	Sony Vaio SVE1511J1E

Name	Description
Compatible with these devices	Sony Vaio SVE1511RFXW
Compatible with these devices	Sony Vaio SVE15123CN
Compatible with these devices	Sony Vaio SVE1512G1RW
Compatible with these devices	Sony Vaio SVE1512N1RW
Compatible with these devices	Sony Vaio SVE15137CGP
Compatible with these devices	Sony Vaio SVE1513K1ESI
Compatible with these devices	Sony Vaio SVE151E13T
Compatible with these devices	Sony Vaio SVE1712C1EW
Compatible with these devices	Sony Vaio SVE1713P1EB
Compatible with these devices	Sony Vaio VPCCA1S1R
Compatible with these devices	Sony Vaio VPCCB100C