

Green Cell Battery VGP-BPS24 VGP-BPL24 VGP-BPSC24 for Sony Vaio

Generuota 2026-08-27



Name	Description
Compatible with these devices	Sony Vaio SVS1513Z
Cell technology	Lithium ion
Compatible with these devices	Sony Vaio VPCSA26
Compatible with these devices	Sony Vaio VPCSA2S9RBI
Compatible with these devices	Sony Vaio VPCSA390X
Compatible with these devices	Sony Vaio VPCSA3T9EXI
Compatible with these devices	Sony Vaio VPCSA4JFX
Compatible with these devices	Sony Vaio VPCSB16FWB
Compatible with these devices	Sony Vaio VPCSB19GWB
Compatible with these devices	Sony Vaio VPCSB1X9EB
Compatible with these devices	Sony Vaio VPCSB26FF
Compatible with these devices	Sony Vaio VPCSB28GGS

Name	Description
Compatible with these devices	Sony Vaio VPCSB2S9E
Compatible with these devices	Sony Vaio VPCSB35FW
Compatible with these devices	Sony Vaio VPCSB37GHB
Compatible with these devices	Sony Vaio VPCSB3M1RW
Compatible with these devices	Sony Vaio VPCSB48GJ
Compatible with these devices	Sony Vaio VPCSB4Q9EB
Compatible with these devices	Sony Vaio VPCSD18ECB
Compatible with these devices	Sony Vaio VPCSE1
Compatible with these devices	Sony Vaio VPCSE1BFX
Compatible with these devices	Sony Vaio VPCSE1X9ES
Compatible with these devices	Sony Vaio VPCSE2HFX
Compatible with these devices	Sony Vaio VPCSE2SFX
Compatible with these devices	Sony Vaio SVS13116FAB
Compatible with these devices	Sony Vaio SVS1311C5E
Compatible with these devices	Sony Vaio SVS1311K9EB
Compatible with these devices	Sony Vaio SVS1311S9R
Compatible with these devices	Sony Vaio SVS13125CHB

Name	Description
Compatible with these devices	Sony Vaio SVS13128CCB
Compatible with these devices	Sony Vaio SVS1312K3E
Compatible with these devices	Sony Vaio SVS13133CVW
Compatible with these devices	Sony Vaio SVS1313K1E
Compatible with these devices	Sony Vaio SVS13A
Compatible with these devices	Sony Vaio SVS13A1T
Compatible with these devices	Sony Vaio SVS13A1Z9RN
Compatible with these devices	Sony Vaio SVS13A2Z9R
Compatible with these devices	Sony Vaio SVS15112C5E
Compatible with these devices	Sony Vaio SVS1511BFXB
Compatible with these devices	Sony Vaio SVS1511S3R
Compatible with these devices	Sony Vaio SVS15125CHB
Compatible with these devices	Sony Vaio SVS1512E
Compatible with these devices	Sony Vaio SVS15136PA
Compatible with these devices	Sony Vaio SVS1513C4E
Compatible with these devices	Sony Vaio PCG
Compatible with these devices	Sony Vaio VPCSA28GG

Name	Description
Compatible with these devices	Sony Vaio VPCSA31FX
Compatible with these devices	Sony Vaio VPCSA3DGX
Compatible with these devices	Sony Vaio VPCSA43FX
Compatible with these devices	Sony Vaio VPCSB11FX
Compatible with these devices	Sony Vaio VPCSB18FJB
Compatible with these devices	Sony Vaio VPCSB1AHJ
Compatible with these devices	Sony Vaio VPCSB25FAW
Compatible with these devices	Sony Vaio VPCSB27GA
Compatible with these devices	Sony Vaio VPCSB2BGJ
Compatible with these devices	Sony Vaio VPCSB2ZDZB
Compatible with these devices	Sony Vaio VPCSB35FXR
Compatible with these devices	Sony Vaio VPCSB38GG
Compatible with these devices	Sony Vaio VPCSB3S9E
Compatible with these devices	Sony Vaio VPCSB4CFX
Compatible with these devices	Sony Vaio VPCSB4V9RB
Compatible with these devices	Sony Vaio VPCSD1S4C
Compatible with these devices	Sony Vaio VPCSE16FWB

Name	Description
Compatible with these devices	Sony Vaio VPCSE1E1ES
Compatible with these devices	Sony Vaio VPCSE25FXS
Compatible with these devices	Sony Vaio VPCSE2L9E
Compatible with these devices	Sony Vaio VPCSE2X9ES
Compatible with these devices	Sony Vaio SVS13118FJ
Compatible with these devices	Sony Vaio SVS1311E3RW
Compatible with these devices	Sony Vaio SVS1311M9R
Compatible with these devices	Sony Vaio SVS13122CXS
Compatible with these devices	Sony Vaio SVS13126PN
Compatible with these devices	Sony Vaio SVS1312ACXP
Compatible with these devices	Sony Vaio SVS1312Q
Compatible with these devices	Sony Vaio SVS1313A
Compatible with these devices	Sony Vaio SVS1313M9EB
Compatible with these devices	Sony Vaio SVS13A16GGB
Compatible with these devices	Sony Vaio SVS13A1V9E
Compatible with these devices	Sony Vaio SVS13A290X
Compatible with these devices	Sony Vaio SVS13A3M9R

Name	Description
Compatible with these devices	Sony Vaio SVS15116FXB
Compatible with these devices	Sony Vaio SVS1511GFYB
Compatible with these devices	Sony Vaio SVS1511V
Compatible with these devices	Sony Vaio SVS15126PAB
Compatible with these devices	Sony Vaio SVS1512V
Compatible with these devices	Sony Vaio SVS1513V
Compatible with these devices	Sony Vaio VPCSA23GWT
Compatible with these devices	Sony Vaio VPCSA2DGXBI
Compatible with these devices	Sony Vaio VPCSA36GABI
Compatible with these devices	Sony Vaio VPCSA3N9EXI
Compatible with these devices	Sony Vaio VPCSA4AJ
Compatible with these devices	Sony Vaio VPCSB16FGB
Compatible with these devices	Sony Vaio VPCSB18GWB
Compatible with these devices	Sony Vaio VPCSB1Q1ES
Compatible with these devices	Sony Vaio VPCSB25FHW
Compatible with these devices	Sony Vaio VPCSB28FJB
Compatible with these devices	Sony Vaio VPCSB2L1EW

Name	Description
Compatible with these devices	Sony Vaio VPCSB33GXP
Compatible with these devices	Sony Vaio VPCSB36FW
Compatible with these devices	Sony Vaio VPCSB3AFXWC
Compatible with these devices	Sony Vaio VPCSB3Z9E
Compatible with these devices	Sony Vaio VPCSB4M1RP
Compatible with these devices	Sony Vaio VPCSC1AFMS
Compatible with these devices	Sony Vaio VPCSD28ECW
Compatible with these devices	Sony Vaio VPCSE17GG
Compatible with these devices	Sony Vaio VPCSE1S4C
Compatible with these devices	Sony Vaio VPCSE2AGXB
Compatible with these devices	Sony Vaio VPCSE2NFX
Compatible with these devices	Sony Vaio SVS13112FXS
Compatible with these devices	Sony Vaio SVS13119GJ
Compatible with these devices	Sony Vaio SVS1311G4E
Compatible with these devices	Sony Vaio SVS1311Q9E
Compatible with these devices	Sony Vaio SVS13125C
Compatible with these devices	Sony Vaio SVS13127PG

Name	Description
Compatible with these devices	Sony Vaio SVS1312G3E
Compatible with these devices	Sony Vaio SVS13133
Compatible with these devices	Sony Vaio SVS1313E
Compatible with these devices	Sony Vaio SVS1313S9E
Compatible with these devices	Sony Vaio SVS13A1C5E
Compatible with these devices	Sony Vaio SVS13A1X9S
Compatible with these devices	Sony Vaio SVS13A2W9E
Compatible with these devices	Sony Vaio SVS13A3X9R
Compatible with these devices	Sony Vaio SVS15119
Compatible with these devices	Sony Vaio SVS1511M3E
Compatible with these devices	Sony Vaio SVS1511X9E
Compatible with these devices	Sony Vaio SVS151290X
Compatible with these devices	Sony Vaio SVS1512X9EB
Compatible with these devices	Sony Vaio SVS1513Z9E
Voltage	11.1V (10.8V)
Compatible with these devices	Sony Vaio VPCSA26GABl
Compatible with these devices	Sony Vaio VPCSA2SGX

Name	Description
Compatible with these devices	Sony Vaio VPCSA3AFX
Compatible with these devices	Sony Vaio VPCSA3V9E
Compatible with these devices	Sony Vaio VPCSA4MFY
Compatible with these devices	Sony Vaio VPCSB16FWS
Compatible with these devices	Sony Vaio VPCSB1A7E
Compatible with these devices	Sony Vaio VPCSB1X9ES
Compatible with these devices	Sony Vaio VPCSB26FFB
Compatible with these devices	Sony Vaio VPCSB28GW
Compatible with these devices	Sony Vaio VPCSB2S9EB
Compatible with these devices	Sony Vaio VPCSB35FWB
Compatible with these devices	Sony Vaio VPCSB37GW
Compatible with these devices	Sony Vaio VPCSB3M9E
Compatible with these devices	Sony Vaio VPCSB48GJB
Compatible with these devices	Sony Vaio VPCSB4Q9ES
Compatible with these devices	Sony Vaio VPCSD18ECL
Compatible with these devices	Sony Vaio VPCSE13FX
Compatible with these devices	Sony Vaio VPCSE1C5E

Name	Description
Compatible with these devices	Sony Vaio VPCSE1Z9E
Compatible with these devices	Sony Vaio VPCSE2HFXB
Compatible with these devices	Sony Vaio VPCSE2SFXS
Compatible with these devices	Sony Vaio SVS13116FFB
Compatible with these devices	Sony Vaio SVS1311CGXB
Compatible with these devices	Sony Vaio SVS1311L
Compatible with these devices	Sony Vaio SVS1311S9RB
Compatible with these devices	Sony Vaio SVS13125CN
Compatible with these devices	Sony Vaio SVS13129
Compatible with these devices	Sony Vaio SVS1312K3EW
Compatible with these devices	Sony Vaio SVS13136
Compatible with these devices	Sony Vaio SVS1313K1EW
Compatible with these devices	Sony Vaio SVS13A12
Compatible with these devices	Sony Vaio SVS13A1T9E
Compatible with these devices	Sony Vaio SVS13A25
Compatible with these devices	Sony Vaio SVS13A2Z9RS
Compatible with these devices	Sony Vaio SVS15113

Name	Description
Compatible with these devices	Sony Vaio SVS1511C
Compatible with these devices	Sony Vaio SVS1511S9E
Compatible with these devices	Sony Vaio SVS15125CN
Compatible with these devices	Sony Vaio SVS1512EPXB
Compatible with these devices	Sony Vaio SVS15136PAB
Compatible with these devices	Sony Vaio SVS1513C5E
Compatible with the following battery models	VGPBPSC24
Compatible with these devices	Sony Vaio VPCSA28GGBI
Compatible with these devices	Sony Vaio VPCSA31GX
Compatible with these devices	Sony Vaio VPCSA3DGXBI
Compatible with these devices	Sony Vaio VPCSA45
Compatible with these devices	Sony Vaio VPCSB11FXB
Compatible with these devices	Sony Vaio VPCSB18FJP
Compatible with these devices	Sony Vaio VPCSB1B7E
Compatible with these devices	Sony Vaio VPCSB25FG
Compatible with these devices	Sony Vaio VPCSB27GAB
Compatible with these devices	Sony Vaio VPCSB2BGJB

Name	Description
Compatible with these devices	Sony Vaio VPCSB3
Compatible with these devices	Sony Vaio VPCSB35FXW
Compatible with these devices	Sony Vaio VPCSB38GGB
Compatible with these devices	Sony Vaio VPCSB3S9EB
Compatible with these devices	Sony Vaio VPCSB4CFXP
Compatible with these devices	Sony Vaio VPCSB4V9RS
Compatible with these devices	Sony Vaio VPCSD1S5C
Compatible with these devices	Sony Vaio VPCSE16FWS
Compatible with these devices	Sony Vaio VPCSE1J1E
Compatible with these devices	Sony Vaio VPCSE26FW
Compatible with these devices	Sony Vaio VPCSE2L9EB
Compatible with these devices	Sony Vaio VPCSE2Z9R
Compatible with these devices	Sony Vaio SVS13118FJB
Compatible with these devices	Sony Vaio SVS1311E4B
Compatible with these devices	Sony Vaio SVS1311M9RB
Compatible with these devices	Sony Vaio SVS13122CXW
Compatible with these devices	Sony Vaio SVS13126PNB

Name	Description
Compatible with these devices	Sony Vaio SVS1312ACXW
Compatible with these devices	Sony Vaio SVS1312Q9E
Compatible with these devices	Sony Vaio SVS1313A4E
Compatible with these devices	Sony Vaio SVS1313N
Compatible with these devices	Sony Vaio SVS13A16GNB
Compatible with these devices	Sony Vaio SVS13A1V9EB
Compatible with these devices	Sony Vaio SVS13A2A
Compatible with these devices	Sony Vaio SVS13A3M9RS
Compatible with these devices	Sony Vaio SVS15116FXS
Compatible with these devices	Sony Vaio SVS1511H
Compatible with these devices	Sony Vaio SVS1511V9B
Compatible with these devices	Sony Vaio SVS15126PG
Compatible with these devices	Sony Vaio SVS1512V1E
Compatible with these devices	Sony Vaio SVS1513V9E
Compatible with these devices	Sony Vaio VPCSA23GX
Compatible with these devices	Sony Vaio VPCSA2EGX
Compatible with these devices	Sony Vaio VPCSA36GG

Name	Description
Compatible with these devices	Sony Vaio VPCSA3Q9E
Compatible with these devices	Sony Vaio VPCSA4B4E
Compatible with these devices	Sony Vaio VPCSB16FGL
Compatible with these devices	Sony Vaio VPCSB19
Compatible with these devices	Sony Vaio VPCSB1S1E
Compatible with these devices	Sony Vaio VPCSB25FW
Compatible with these devices	Sony Vaio VPCSB28FJL
Compatible with these devices	Sony Vaio VPCSB2L1R
Compatible with these devices	Sony Vaio VPCSB33GXR
Compatible with these devices	Sony Vaio VPCSB36FWB
Compatible with these devices	Sony Vaio VPCSB3C5E
Compatible with these devices	Sony Vaio VPCSB3Z9EB
Compatible with these devices	Sony Vaio VPCSB4M1RR
Compatible with these devices	Sony Vaio VPCSC31FM
Compatible with these devices	Sony Vaio VPCSD29
Compatible with these devices	Sony Vaio VPCSE17GGB
Compatible with these devices	Sony Vaio VPCSE1S9E

Name	Description
Compatible with these devices	Sony Vaio VPCSE2C5E
Compatible with these devices	Sony Vaio VPCSE2NFXB
Compatible with these devices	Sony Vaio SVS13112FXW
Compatible with these devices	Sony Vaio SVS13119GJB
Compatible with these devices	Sony Vaio SVS1311H
Compatible with these devices	Sony Vaio SVS1311Q9EB
Compatible with these devices	Sony Vaio SVS13125CA
Compatible with these devices	Sony Vaio SVS13127PGB
Compatible with these devices	Sony Vaio SVS1312G3ER
Compatible with these devices	Sony Vaio SVS13133C
Compatible with these devices	Sony Vaio SVS1313E4E
Compatible with these devices	Sony Vaio SVS1313S9EB
Compatible with these devices	Sony Vaio SVS13A1CGXB
Compatible with these devices	Sony Vaio SVS13A1Y
Compatible with these devices	Sony Vaio SVS13A2W9ES
Compatible with these devices	Sony Vaio SVS13A3X9RS
Compatible with these devices	Sony Vaio SVS151190X

Name	Description
Compatible with these devices	Sony Vaio SVS1511M3EW
Compatible with these devices	Sony Vaio SVS1511X9EB
Compatible with these devices	Sony Vaio SVS15129CJB
Compatible with these devices	Sony Vaio SVS1512Z
Delivery from	0 PLN
Item code	SY13
Compatible with these devices	Sony Vaio VPCSA26GGBI
Compatible with these devices	Sony Vaio VPCSA2SGXT
Compatible with these devices	Sony Vaio VPCSA3AFXBI
Compatible with these devices	Sony Vaio VPCSA3V9EXI
Compatible with these devices	Sony Vaio VPCSA4S
Compatible with these devices	Sony Vaio VPCSB16FWW
Compatible with these devices	Sony Vaio VPCSB1A9E
Compatible with these devices	Sony Vaio VPCSB1Z9E
Compatible with these devices	Sony Vaio VPCSB26FG
Compatible with these devices	Sony Vaio VPCSB28GWB
Compatible with these devices	Sony Vaio VPCSB2S9EW

Name	Description
Compatible with these devices	Sony Vaio VPCSB35FWL
Compatible with these devices	Sony Vaio VPCSB37GWS
Compatible with these devices	Sony Vaio VPCSB3M9EB
Compatible with these devices	Sony Vaio VPCSB490X
Compatible with these devices	Sony Vaio VPCSB4S9E
Compatible with these devices	Sony Vaio VPCSD18ECP
Compatible with these devices	Sony Vaio VPCSE13FXB
Compatible with these devices	Sony Vaio VPCSE1C9E
Compatible with these devices	Sony Vaio VPCSE1Z9EB
Compatible with these devices	Sony Vaio VPCSE2J9E
Compatible with these devices	Sony Vaio VPCSE2V9E
Compatible with these devices	Sony Vaio SVS13116FG
Compatible with these devices	Sony Vaio SVS1311D
Compatible with these devices	Sony Vaio SVS1311L9E
Compatible with these devices	Sony Vaio SVS1311ZDZB
Compatible with these devices	Sony Vaio SVS13125CNW
Compatible with these devices	Sony Vaio SVS131290X

Name	Description
Compatible with these devices	Sony Vaio SVS1312M
Compatible with these devices	Sony Vaio SVS13136P
Compatible with these devices	Sony Vaio SVS1313L
Compatible with these devices	Sony Vaio SVS13A12FXB
Compatible with these devices	Sony Vaio SVS13A1T9ES
Compatible with these devices	Sony Vaio SVS13A25PG
Compatible with these devices	Sony Vaio SVS13A36
Compatible with these devices	Sony Vaio SVS15113FXB
Compatible with these devices	Sony Vaio SVS1511C5E
Compatible with these devices	Sony Vaio SVS1511S9S
Compatible with these devices	Sony Vaio SVS15125CNB
Compatible with these devices	Sony Vaio SVS1512G
Compatible with these devices	Sony Vaio SVS15136PG
Compatible with these devices	Sony Vaio SVS1513D
Compatible with these devices	Sony Vaio VPCSA
Compatible with these devices	Sony Vaio VPCSA28GWT
Compatible with these devices	Sony Vaio VPCSA33

Name	Description
Compatible with these devices	Sony Vaio VPCSA3EGX
Compatible with these devices	Sony Vaio VPCSA45EC
Compatible with these devices	Sony Vaio VPCSB11FXL
Compatible with these devices	Sony Vaio VPCSB18FJW
Compatible with these devices	Sony Vaio VPCSB1B9E
Compatible with these devices	Sony Vaio VPCSB25FGB
Compatible with these devices	Sony Vaio VPCSB27GG
Compatible with these devices	Sony Vaio VPCSB2C5021B
Compatible with these devices	Sony Vaio VPCSB31FX
Compatible with these devices	Sony Vaio VPCSB36
Compatible with these devices	Sony Vaio VPCSB38GH
Compatible with these devices	Sony Vaio VPCSB3T9E
Compatible with these devices	Sony Vaio VPCSB4DFX
Compatible with these devices	Sony Vaio VPCSB4X9E
Compatible with these devices	Sony Vaio VPCSD27
Compatible with these devices	Sony Vaio VPCSE16FX
Compatible with these devices	Sony Vaio VPCSE1J1ES

Name	Description
Compatible with these devices	Sony Vaio VPCSE27FX
Compatible with these devices	Sony Vaio VPCSE2L9ES
Compatible with these devices	Sony Vaio VPCSE2Z9RB
Compatible with these devices	Sony Vaio SVS13118FJP
Compatible with these devices	Sony Vaio SVS1311E4E
Compatible with these devices	Sony Vaio SVS1311N
Compatible with these devices	Sony Vaio SVS13123
Compatible with these devices	Sony Vaio SVS13126PW
Compatible with these devices	Sony Vaio SVS1312AJ
Compatible with these devices	Sony Vaio SVS1312Q9ES
Compatible with these devices	Sony Vaio SVS1313AGXB
Compatible with these devices	Sony Vaio SVS1313N9E
Compatible with these devices	Sony Vaio SVS13A18
Compatible with these devices	Sony Vaio SVS13A1W
Compatible with these devices	Sony Vaio SVS13A2AJ
Compatible with these devices	Sony Vaio SVS13A3V
Compatible with these devices	Sony Vaio SVS15116GAB

Name	Description
Compatible with these devices	Sony Vaio SVS1511HGXB
Compatible with these devices	Sony Vaio SVS1511V9E
Compatible with these devices	Sony Vaio SVS15126PGB
Compatible with these devices	Sony Vaio SVS1512V1ES
Compatible with these devices	Sony Vaio SVS1513V9EB
Compatible with these devices	Sony Vaio VPCSA24GX
Compatible with these devices	Sony Vaio VPCSA2EGXBI
Compatible with these devices	Sony Vaio VPCSA36GGBI
Compatible with these devices	Sony Vaio VPCSA3Q9EXI
Compatible with these devices	Sony Vaio VPCSA4BGX
Compatible with these devices	Sony Vaio VPCSB16FGP
Compatible with these devices	Sony Vaio VPCSB190
Compatible with these devices	Sony Vaio VPCSB1S1ES
Compatible with these devices	Sony Vaio VPCSB25FWB
Compatible with these devices	Sony Vaio VPCSB28FJP
Compatible with these devices	Sony Vaio VPCSB2L1RL
Compatible with these devices	Sony Vaio VPCSB33GXW

Name	Description
Compatible with these devices	Sony Vaio VPCSB36FWP
Compatible with these devices	Sony Vaio VPCSB3L9E
Compatible with these devices	Sony Vaio VPCSB3Z9R
Compatible with these devices	Sony Vaio VPCSB4M1RW
Compatible with these devices	Sony Vaio VPCSC31FMS
Compatible with these devices	Sony Vaio VPCSD29GC
Compatible with these devices	Sony Vaio VPCSE17GW
Compatible with these devices	Sony Vaio VPCSE1S9EB
Compatible with these devices	Sony Vaio VPCSE2DGX
Compatible with these devices	Sony Vaio VPCSE2RFX
Compatible with these devices	Sony Vaio SVS13113
Compatible with these devices	Sony Vaio SVS1311A
Compatible with these devices	Sony Vaio SVS1311H3E
Compatible with these devices	Sony Vaio SVS1311R
Compatible with these devices	Sony Vaio SVS13125CAB
Compatible with these devices	Sony Vaio SVS13127PN
Compatible with these devices	Sony Vaio SVS1312G3EW

Name	Description
Compatible with these devices	Sony Vaio SVS13133CA
Compatible with these devices	Sony Vaio SVS1313H
Compatible with these devices	Sony Vaio SVS1313V
Compatible with these devices	Sony Vaio SVS13A1D
Compatible with these devices	Sony Vaio SVS13A1Y9E
Compatible with these devices	Sony Vaio SVS13A2X
Compatible with these devices	Sony Vaio SVS13A3Z
Compatible with these devices	Sony Vaio SVS15119FJ
Compatible with these devices	Sony Vaio SVS1511N3E
Compatible with these devices	Sony Vaio SVS1511X9R
Compatible with these devices	Sony Vaio SVS15129CJS
Compatible with these devices	Sony Vaio SVS1512Z1E
Compatible with these devices	Sony Vaio SVS1513Z9EB
Compatible with the following battery models	VGP-BPL24
Compatible with these devices	Sony Vaio VPCSA26GGT
Compatible with these devices	Sony Vaio VPCSA2V9R
Compatible with these devices	Sony Vaio VPCSA3AFXSI

Name	Description
Compatible with these devices	Sony Vaio VPCSA3X9E
Compatible with these devices	Sony Vaio VPCSA4S1C
Compatible with these devices	Sony Vaio VPCSB17
Compatible with these devices	Sony Vaio VPCSB1A9EB
Compatible with these devices	Sony Vaio VPCSB1Z9EB
Compatible with these devices	Sony Vaio VPCSB26FGB
Compatible with these devices	Sony Vaio VPCSB29FJ
Compatible with these devices	Sony Vaio VPCSB2V9E
Compatible with these devices	Sony Vaio VPCSB35FWP
Compatible with these devices	Sony Vaio VPCSB38
Compatible with these devices	Sony Vaio VPCSB3M9ES
Compatible with these devices	Sony Vaio VPCSB49FJ
Compatible with these devices	Sony Vaio VPCSB4S9EB
Compatible with these devices	Sony Vaio VPCSD18ECW
Compatible with these devices	Sony Vaio VPCSE13FXS
Compatible with these devices	Sony Vaio VPCSE1CFX
Compatible with these devices	Sony Vaio VPCSE1Z9R

Name	Description
Compatible with these devices	Sony Vaio VPCSE2J9EB
Compatible with these devices	Sony Vaio VPCSE2V9EB
Compatible with these devices	Sony Vaio SVS13116FGB
Compatible with these devices	Sony Vaio SVS1311D4B
Compatible with these devices	Sony Vaio SVS1311L9ES
Compatible with these devices	Sony Vaio SVS1312
Compatible with these devices	Sony Vaio SVS13125CV
Compatible with these devices	Sony Vaio SVS13129C
Compatible with these devices	Sony Vaio SVS1312M9R
Compatible with these devices	Sony Vaio SVS13136PA
Compatible with these devices	Sony Vaio SVS1313L9E
Compatible with these devices	Sony Vaio SVS13A12FXS
Compatible with these devices	Sony Vaio SVS13A1T9S
Compatible with these devices	Sony Vaio SVS13A25PGB
Compatible with these devices	Sony Vaio SVS13A36PG
Compatible with these devices	Sony Vaio SVS15113FXS
Compatible with these devices	Sony Vaio SVS1511CFXB

Name	Description
Compatible with these devices	Sony Vaio SVS1511T
Compatible with these devices	Sony Vaio SVS15125CV
Compatible with these devices	Sony Vaio SVS1512GPXB
Compatible with these devices	Sony Vaio SVS15136PGB
Compatible with these devices	Sony Vaio SVS1513D4E
Compatible with these devices	Sony Vaio VPCSA1A7E
Compatible with these devices	Sony Vaio VPCSA290X
Compatible with these devices	Sony Vaio VPCSA33GWBI
Compatible with these devices	Sony Vaio VPCSA3EGXSI
Compatible with these devices	Sony Vaio VPCSA45ECXI
Compatible with these devices	Sony Vaio VPCSB11FXP
Compatible with these devices	Sony Vaio VPCSB18GA
Compatible with these devices	Sony Vaio VPCSB1B9EB
Compatible with these devices	Sony Vaio VPCSB25FGL
Compatible with these devices	Sony Vaio VPCSB27GGB
Compatible with these devices	Sony Vaio VPCSB2C5023W
Compatible with these devices	Sony Vaio VPCSB31FXB

Name	Description
Compatible with these devices	Sony Vaio VPCSB36FA
Compatible with these devices	Sony Vaio VPCSB38GHB
Compatible with these devices	Sony Vaio VPCSB3T9ER
Compatible with these devices	Sony Vaio VPCSB4DFXB
Compatible with these devices	Sony Vaio VPCSB4X9EB
Compatible with these devices	Sony Vaio VPCSD27EC
Compatible with these devices	Sony Vaio VPCSE16FXB
Compatible with these devices	Sony Vaio VPCSE1L1E
Compatible with these devices	Sony Vaio VPCSE27FXB
Compatible with these devices	Sony Vaio VPCSE2LFX
Compatible with these devices	Sony Vaio SVS13
Compatible with these devices	Sony Vaio SVS13118FJS
Compatible with these devices	Sony Vaio SVS1311F
Compatible with these devices	Sony Vaio SVS1311N9E
Compatible with these devices	Sony Vaio SVS13123C
Compatible with these devices	Sony Vaio SVS13126PWR
Compatible with these devices	Sony Vaio SVS1312C

Name	Description
Compatible with these devices	Sony Vaio SVS1312R
Compatible with these devices	Sony Vaio SVS1313B
Compatible with these devices	Sony Vaio SVS1313N9EB
Compatible with these devices	Sony Vaio SVS13A18GXB
Compatible with these devices	Sony Vaio SVS13A1W9E
Compatible with these devices	Sony Vaio SVS13A2APXB
Compatible with these devices	Sony Vaio SVS13A3V9R
Compatible with these devices	Sony Vaio SVS15116GG
Compatible with these devices	Sony Vaio SVS1511J
Compatible with these devices	Sony Vaio SVS1511V9EB
Compatible with these devices	Sony Vaio SVS15126PW
Compatible with these devices	Sony Vaio SVS1512V1R
Compatible with these devices	Sony Vaio SVS1513V9R
Compatible with these devices	Sony Vaio VPCSA25
Compatible with these devices	Sony Vaio VPCSA2FGX
Compatible with these devices	Sony Vaio VPCSA36GHBI
Compatible with these devices	Sony Vaio VPCSA3S9E

Name	Description
Compatible with these devices	Sony Vaio VPCSA4C5E
Compatible with these devices	Sony Vaio VPCSB16FGS
Compatible with these devices	Sony Vaio VPCSB190S
Compatible with these devices	Sony Vaio VPCSB1S1EW
Compatible with these devices	Sony Vaio VPCSB25FWL
Compatible with these devices	Sony Vaio VPCSB28FJW
Compatible with these devices	Sony Vaio VPCSB2L1RP
Compatible with these devices	Sony Vaio VPCSB35
Compatible with these devices	Sony Vaio VPCSB36FWW
Compatible with these devices	Sony Vaio VPCSB3L9ER
Compatible with these devices	Sony Vaio VPCSB3Z9RB
Compatible with these devices	Sony Vaio VPCSB4M9E
Compatible with these devices	Sony Vaio VPCSC41FM
Compatible with these devices	Sony Vaio VPCSD29GCB
Compatible with these devices	Sony Vaio VPCSE17GWB
Compatible with these devices	Sony Vaio VPCSE1V9E
Compatible with these devices	Sony Vaio VPCSE2DGXB

Name	Description
Compatible with these devices	Sony Vaio VPCSE2RFXB
Compatible with these devices	Sony Vaio SVS13113FW
Compatible with these devices	Sony Vaio SVS1311A4E
Compatible with these devices	Sony Vaio SVS1311H3EW
Compatible with these devices	Sony Vaio SVS1311R9B
Compatible with these devices	Sony Vaio SVS13125CAR
Compatible with these devices	Sony Vaio SVS13127PNB
Compatible with these devices	Sony Vaio SVS1312H
Compatible with these devices	Sony Vaio SVS13133CAB
Compatible with these devices	Sony Vaio SVS1313H1E
Compatible with these devices	Sony Vaio SVS1313V9R
Compatible with these devices	Sony Vaio SVS13A1DGXB
Compatible with these devices	Sony Vaio SVS13A1Y9ES
Compatible with these devices	Sony Vaio SVS13A2X9E
Compatible with these devices	Sony Vaio SVS13A3Z9E
Compatible with these devices	Sony Vaio SVS15119FJB
Compatible with these devices	Sony Vaio SVS1511Q

Name	Description
Compatible with these devices	Sony Vaio SVS1511X9RB
Compatible with these devices	Sony Vaio SVS1512A
Compatible with these devices	Sony Vaio SVS1512Z1ES
Compatible with these devices	Sony Vaio SVS1513Z9ES
Compatible with the following battery models	VGP-BPS24
Compatible with these devices	Sony Vaio VPCSA26GWT
Compatible with these devices	Sony Vaio VPCSA2V9RBI
Compatible with these devices	Sony Vaio VPCSA3AGX
Compatible with these devices	Sony Vaio VPCSA3X9EXI
Compatible with these devices	Sony Vaio VPCSA4S9R
Compatible with these devices	Sony Vaio VPCSB17GG
Compatible with these devices	Sony Vaio VPCSB1A9R
Compatible with these devices	Sony Vaio VPCSB1Z9R
Compatible with these devices	Sony Vaio VPCSB26FGL
Compatible with these devices	Sony Vaio VPCSB29FJB
Compatible with these devices	Sony Vaio VPCSB2V9EB
Compatible with these devices	Sony Vaio VPCSB35FWR

Name	Description
Compatible with these devices	Sony Vaio VPCSB38FJ
Compatible with these devices	Sony Vaio VPCSB3N9E
Compatible with these devices	Sony Vaio VPCSB49FJB
Compatible with these devices	Sony Vaio VPCSB4S9ES
Compatible with these devices	Sony Vaio VPCSD19
Compatible with these devices	Sony Vaio VPCSE15
Compatible with these devices	Sony Vaio VPCSE1CFXB
Compatible with these devices	Sony Vaio VPCSE1Z9RB
Compatible with these devices	Sony Vaio VPCSE2JFX
Compatible with these devices	Sony Vaio VPCSE2V9ES
Compatible with these devices	Sony Vaio SVS13117
Compatible with these devices	Sony Vaio SVS1311D4E
Compatible with these devices	Sony Vaio SVS1311L9R
Compatible with these devices	Sony Vaio SVS13120
Compatible with these devices	Sony Vaio SVS13125CVB
Compatible with these devices	Sony Vaio SVS13129CC
Compatible with these devices	Sony Vaio SVS1312M9RB

Name	Description
Compatible with these devices	Sony Vaio SVS13136PAB
Compatible with these devices	Sony Vaio SVS1313L9EB
Compatible with these devices	Sony Vaio SVS13A15
Compatible with these devices	Sony Vaio SVS13A1U
Compatible with these devices	Sony Vaio SVS13A25PW
Compatible with these devices	Sony Vaio SVS13A3A
Compatible with these devices	Sony Vaio SVS15115
Compatible with these devices	Sony Vaio SVS1511D
Compatible with these devices	Sony Vaio SVS1511T9B
Compatible with these devices	Sony Vaio SVS15125CVB
Compatible with these devices	Sony Vaio SVS1512S
Compatible with these devices	Sony Vaio SVS1513A
Compatible with these devices	Sony Vaio SVS1513L1E
Compatible with these devices	Sony Vaio VPCSA1B7E
Compatible with these devices	Sony Vaio VPCSA2AJ
Compatible with these devices	Sony Vaio VPCSA33GWT
Compatible with these devices	Sony Vaio VPCSA3J1E

Name	Description
Compatible with these devices	Sony Vaio VPCSA45GX
Compatible with these devices	Sony Vaio VPCSB11FXW
Compatible with these devices	Sony Vaio VPCSB18GAB
Compatible with these devices	Sony Vaio VPCSB1BGX
Compatible with these devices	Sony Vaio VPCSB25FGP
Compatible with these devices	Sony Vaio VPCSB27GGS
Compatible with these devices	Sony Vaio VPCSB2C5E
Compatible with these devices	Sony Vaio VPCSB31FXL
Compatible with these devices	Sony Vaio VPCSB36FAR
Compatible with these devices	Sony Vaio VPCSB38GW
Compatible with these devices	Sony Vaio VPCSB3V9E
Compatible with these devices	Sony Vaio VPCSB4DFXL
Compatible with these devices	Sony Vaio VPCSB4Y9E
Compatible with these devices	Sony Vaio VPCSD27ECB
Compatible with these devices	Sony Vaio VPCSE16FXS
Compatible with these devices	Sony Vaio VPCSE1L1ES
Compatible with these devices	Sony Vaio VPCSE27FXS

Name	Description
Compatible with these devices	Sony Vaio VPCSE2LFXB
Compatible with these devices	Sony Vaio SVS1311
Compatible with these devices	Sony Vaio SVS13118FXB
Compatible with these devices	Sony Vaio SVS1311F3E
Compatible with these devices	Sony Vaio SVS1311N9ES
Compatible with these devices	Sony Vaio SVS13123CH
Compatible with these devices	Sony Vaio SVS13127
Compatible with these devices	Sony Vaio SVS1312C5E
Compatible with these devices	Sony Vaio SVS1312R9E
Compatible with these devices	Sony Vaio SVS1313B4E
Compatible with these devices	Sony Vaio SVS1313P
Compatible with these devices	Sony Vaio SVS13A19
Compatible with these devices	Sony Vaio SVS13A1W9ES
Compatible with these devices	Sony Vaio SVS13A2APXS
Compatible with these devices	Sony Vaio SVS13A3V9RS
Compatible with these devices	Sony Vaio SVS15116GGB
Compatible with these devices	Sony Vaio SVS1511JFXB

Name	Description
Compatible with these devices	Sony Vaio SVS1511V9ES
Compatible with these devices	Sony Vaio SVS15126PWB
Compatible with these devices	Sony Vaio SVS1512V1RB
Compatible with these devices	Sony Vaio SVS1513V9RB
Compatible with these devices	Sony Vaio VPCSA25EC
Compatible with these devices	Sony Vaio VPCSA2FGXBI
Compatible with these devices	Sony Vaio VPCSA36GWBI
Compatible with these devices	Sony Vaio VPCSA3S9EXI
Compatible with these devices	Sony Vaio VPCSA4CFX
Compatible with these devices	Sony Vaio VPCSB16FGW
Compatible with these devices	Sony Vaio VPCSB190X
Compatible with these devices	Sony Vaio VPCSB1V9E
Compatible with these devices	Sony Vaio VPCSB25FWP
Compatible with these devices	Sony Vaio VPCSB28GA
Compatible with these devices	Sony Vaio VPCSB2L1RW
Compatible with these devices	Sony Vaio VPCSB35FA
Compatible with these devices	Sony Vaio VPCSB37

Name	Description
Compatible with these devices	Sony Vaio VPCSB3L9ES
Compatible with these devices	Sony Vaio VPCSB4
Compatible with these devices	Sony Vaio VPCSB4M9EB
Compatible with these devices	Sony Vaio VPCSC41FMS
Compatible with these devices	Sony Vaio VPCSD29GCP
Compatible with these devices	Sony Vaio VPCSE190X
Compatible with these devices	Sony Vaio VPCSE1V9EB
Compatible with these devices	Sony Vaio VPCSE2E1E
Compatible with these devices	Sony Vaio VPCSE2S1C
Compatible with these devices	Sony Vaio SVS13115
Compatible with these devices	Sony Vaio SVS1311AGXB
Compatible with these devices	Sony Vaio SVS1311H4E
Compatible with these devices	Sony Vaio SVS1311R9E
Compatible with these devices	Sony Vaio SVS13125CAW
Compatible with these devices	Sony Vaio SVS13127PW
Compatible with these devices	Sony Vaio SVS1312H3E
Compatible with these devices	Sony Vaio SVS13133CAW

Name	Description
Compatible with these devices	Sony Vaio SVS1313H1ES
Compatible with these devices	Sony Vaio SVS1313V9RB
Compatible with these devices	Sony Vaio SVS13A1E
Compatible with these devices	Sony Vaio SVS13A1Y9ESPR
Compatible with these devices	Sony Vaio SVS13A2X9ES
Compatible with these devices	Sony Vaio SVS13A3Z9ES
Compatible with these devices	Sony Vaio SVS15119FJS
Compatible with these devices	Sony Vaio SVS1511Q9E
Compatible with these devices	Sony Vaio SVS1512
Compatible with these devices	Sony Vaio SVS1512ACXS
Compatible with these devices	Sony Vaio SVS1512Z9E
Compatible with these devices	Sony Vaio SVS151A
Compatible with the following battery models	VGP-BPSC24
Compatible with these devices	Sony Vaio VPCSA27
Compatible with these devices	Sony Vaio VPCSA2Z9E
Compatible with these devices	Sony Vaio VPCSA3AGXBI
Compatible with these devices	Sony Vaio VPCSA3X9R

Name	Description
Compatible with these devices	Sony Vaio VPCSA4SGX
Compatible with these devices	Sony Vaio VPCSB17GGB
Compatible with these devices	Sony Vaio VPCSB1A9RB
Compatible with these devices	Sony Vaio VPCSB1Z9RB
Compatible with these devices	Sony Vaio VPCSB26FGP
Compatible with these devices	Sony Vaio VPCSB2A7E
Compatible with these devices	Sony Vaio VPCSB2X9R
Compatible with these devices	Sony Vaio VPCSB35FWS
Compatible with these devices	Sony Vaio VPCSB38FJB
Compatible with these devices	Sony Vaio VPCSB3N9EB
Compatible with these devices	Sony Vaio VPCSB4A4E
Compatible with these devices	Sony Vaio VPCSB4T9E
Compatible with these devices	Sony Vaio VPCSD19EC
Compatible with these devices	Sony Vaio VPCSE15FG
Compatible with these devices	Sony Vaio VPCSE1CGX
Compatible with these devices	Sony Vaio VPCSE2
Compatible with these devices	Sony Vaio VPCSE2JFXB

Name	Description
Compatible with these devices	Sony Vaio VPCSE2V9R
Compatible with these devices	Sony Vaio SVS13117EC
Compatible with these devices	Sony Vaio SVS1311DGXB
Compatible with these devices	Sony Vaio SVS1311L9RB
Compatible with these devices	Sony Vaio SVS131200C
Compatible with these devices	Sony Vaio SVS13125CVW
Compatible with these devices	Sony Vaio SVS13129CCB
Compatible with these devices	Sony Vaio SVS1312N
Compatible with these devices	Sony Vaio SVS13137
Compatible with these devices	Sony Vaio SVS1313M
Compatible with these devices	Sony Vaio SVS13A15GGB
Compatible with these devices	Sony Vaio SVS13A1U9E
Compatible with these devices	Sony Vaio SVS13A25PWB
Compatible with these devices	Sony Vaio SVS13A3A4E
Compatible with these devices	Sony Vaio SVS15115FGB
Compatible with these devices	Sony Vaio SVS1511DGXB
Compatible with these devices	Sony Vaio SVS1511T9E

Name	Description
Compatible with these devices	Sony Vaio SVS15125CW
Compatible with these devices	Sony Vaio SVS1512S1C
Compatible with these devices	Sony Vaio SVS1513A4E
Compatible with these devices	Sony Vaio SVS1513M
Compatible with these devices	Sony Vaio VPCSA1Z9E
Compatible with these devices	Sony Vaio VPCSA2BGX
Compatible with these devices	Sony Vaio VPCSA33GX
Compatible with these devices	Sony Vaio VPCSA3J1EXI
Compatible with these devices	Sony Vaio VPCSA47
Compatible with these devices	Sony Vaio VPCSB16
Compatible with these devices	Sony Vaio VPCSB18GG
Compatible with these devices	Sony Vaio VPCSB1BGXB
Compatible with these devices	Sony Vaio VPCSB25FGS
Compatible with these devices	Sony Vaio VPCSB27GH
Compatible with these devices	Sony Vaio VPCSB2C7E
Compatible with these devices	Sony Vaio VPCSB31FXP
Compatible with these devices	Sony Vaio VPCSB36FG

Name	Description
Compatible with these devices	Sony Vaio VPCSB38GWB
Compatible with these devices	Sony Vaio VPCSB3V9EB
Compatible with these devices	Sony Vaio VPCSB4L1E
Compatible with these devices	Sony Vaio VPCSB4Y9EB
Compatible with these devices	Sony Vaio VPCSD27ECL
Compatible with these devices	Sony Vaio VPCSE17
Compatible with these devices	Sony Vaio VPCSE1M1E
Compatible with these devices	Sony Vaio VPCSE28FJ
Compatible with these devices	Sony Vaio VPCSE2M9E
Compatible with these devices	Sony Vaio SVS13112
Compatible with these devices	Sony Vaio SVS13118GG
Compatible with these devices	Sony Vaio SVS1311F3ES
Compatible with these devices	Sony Vaio SVS1311N9S
Compatible with these devices	Sony Vaio SVS13123CHW
Compatible with these devices	Sony Vaio SVS13127C
Compatible with these devices	Sony Vaio SVS1312E
Compatible with these devices	Sony Vaio SVS1312R9EB

Name	Description
Compatible with these devices	Sony Vaio SVS1313BGXB
Compatible with these devices	Sony Vaio SVS1313P9E
Compatible with these devices	Sony Vaio SVS13A190S
Compatible with these devices	Sony Vaio SVS13A1W9S
Compatible with these devices	Sony Vaio SVS13A2C
Compatible with these devices	Sony Vaio SVS13A3W
Compatible with these devices	Sony Vaio SVS15116GNB
Compatible with these devices	Sony Vaio SVS1511L
Compatible with these devices	Sony Vaio SVS1511V9R
Compatible with these devices	Sony Vaio SVS15127PXB
Compatible with these devices	Sony Vaio SVS1512V9E
Compatible with these devices	Sony Vaio SVS1513X
Warranty	12 months
Compatible with these devices	Sony Vaio VPCSA25ECI
Compatible with these devices	Sony Vaio VPCSA2GGX
Compatible with these devices	Sony Vaio VPCSA38
Compatible with these devices	Sony Vaio VPCSA3S9R

Name	Description
Compatible with these devices	Sony Vaio VPCSA4DFX
Compatible with these devices	Sony Vaio VPCSB16FH
Compatible with these devices	Sony Vaio VPCSB19FJ
Compatible with these devices	Sony Vaio VPCSB1V9EB
Compatible with these devices	Sony Vaio VPCSB25FWS
Compatible with these devices	Sony Vaio VPCSB28GAB
Compatible with these devices	Sony Vaio VPCSB2M9E
Compatible with these devices	Sony Vaio VPCSB35FAL
Compatible with these devices	Sony Vaio VPCSB37GA
Compatible with these devices	Sony Vaio VPCSB3L9EW
Compatible with these devices	Sony Vaio VPCSB47
Compatible with these devices	Sony Vaio VPCSB4M9ES
Compatible with these devices	Sony Vaio VPCSC4AFM
Compatible with these devices	Sony Vaio VPCSD400
Compatible with these devices	Sony Vaio VPCSE19FJ
Compatible with these devices	Sony Vaio VPCSE1V9R
Compatible with these devices	Sony Vaio VPCSE2E1ES

Name	Description
Compatible with these devices	Sony Vaio VPCSE2S1E
Compatible with these devices	Sony Vaio SVS13115FXB
Compatible with these devices	Sony Vaio SVS1311AJ
Compatible with these devices	Sony Vaio SVS1311J
Compatible with these devices	Sony Vaio SVS1311R9EB
Compatible with these devices	Sony Vaio SVS13125CF
Compatible with these devices	Sony Vaio SVS13127PWR
Compatible with these devices	Sony Vaio SVS1312H3ES
Compatible with these devices	Sony Vaio SVS13133CF
Compatible with these devices	Sony Vaio SVS1313H1EW
Compatible with these devices	Sony Vaio SVS1313X
Compatible with these devices	Sony Vaio SVS13A1EGXB
Compatible with these devices	Sony Vaio SVS13A1Z
Compatible with these devices	Sony Vaio SVS13A2X9R
Compatible with these devices	Sony Vaio SVS15
Compatible with these devices	Sony Vaio SVS1511A
Compatible with these devices	Sony Vaio SVS1511R9E

Name	Description
Compatible with these devices	Sony Vaio SVS15123
Compatible with these devices	Sony Vaio SVS1512AJ
Compatible with these devices	Sony Vaio SVS1512Z9EB
Compatible with these devices	Sony Vaio SVS151A1
Compatible with the following battery models	VGPBPL24
Compatible with these devices	Sony Vaio VPCSA27GC
Compatible with these devices	Sony Vaio VPCSA2Z9EBI
Compatible with these devices	Sony Vaio VPCSA3BGX
Compatible with these devices	Sony Vaio VPCSA3Z9E
Compatible with these devices	Sony Vaio VPCSA4T9E
Compatible with these devices	Sony Vaio VPCSB17GGS
Compatible with these devices	Sony Vaio VPCSB1AFJ
Compatible with these devices	Sony Vaio VPCSB2
Compatible with these devices	Sony Vaio VPCSB26FGS
Compatible with these devices	Sony Vaio VPCSB2A7R
Compatible with these devices	Sony Vaio VPCSB2X9RB
Compatible with these devices	Sony Vaio VPCSB35FWW

Name	Description
Compatible with these devices	Sony Vaio VPCSB38FJL
Compatible with these devices	Sony Vaio VPCSB3N9ES
Compatible with these devices	Sony Vaio VPCSB4AFX
Compatible with these devices	Sony Vaio VPCSB4T9ES
Compatible with these devices	Sony Vaio VPCSD19ECB
Compatible with these devices	Sony Vaio VPCSE15FGB
Compatible with these devices	Sony Vaio VPCSE1CGXB
Compatible with these devices	Sony Vaio VPCSE23FX
Compatible with these devices	Sony Vaio VPCSE2JFXS
Compatible with these devices	Sony Vaio VPCSE2V9RB
Compatible with these devices	Sony Vaio SVS13117GAB
Compatible with these devices	Sony Vaio SVS1311E
Compatible with these devices	Sony Vaio SVS1311L9RS
Compatible with these devices	Sony Vaio SVS13122
Compatible with these devices	Sony Vaio SVS13125CXB
Compatible with these devices	Sony Vaio SVS13129CJ
Compatible with these devices	Sony Vaio SVS1312N9E

Name	Description
Compatible with these devices	Sony Vaio SVS13137P
Compatible with these devices	Sony Vaio SVS1313M1R
Compatible with these devices	Sony Vaio SVS13A15GHB
Compatible with these devices	Sony Vaio SVS13A1U9ES
Compatible with these devices	Sony Vaio SVS13A25PXB
Compatible with these devices	Sony Vaio SVS13A3B
Compatible with these devices	Sony Vaio SVS15115FHB
Compatible with these devices	Sony Vaio SVS1511E
Compatible with these devices	Sony Vaio SVS1511T9EBPR
Compatible with these devices	Sony Vaio SVS15125CWB
Compatible with these devices	Sony Vaio SVS1512S1E
Compatible with these devices	Sony Vaio SVS1513AGXB
Compatible with these devices	Sony Vaio SVS1513M1E
Compatible with these devices	Sony Vaio VPCSA2
Compatible with these devices	Sony Vaio VPCSA2BGXBI
Compatible with these devices	Sony Vaio VPCSA35
Compatible with these devices	Sony Vaio VPCSA3L9E

Name	Description
Compatible with these devices	Sony Vaio VPCSA47GC
Compatible with these devices	Sony Vaio VPCSB16FA
Compatible with these devices	Sony Vaio VPCSB18GGB
Compatible with these devices	Sony Vaio VPCSB1C5E
Compatible with these devices	Sony Vaio VPCSB25FGW
Compatible with these devices	Sony Vaio VPCSB27GHB
Compatible with these devices	Sony Vaio VPCSB2J9E
Compatible with these devices	Sony Vaio VPCSB31FXR
Compatible with these devices	Sony Vaio VPCSB36FGR
Compatible with these devices	Sony Vaio VPCSB390X
Compatible with these devices	Sony Vaio VPCSB3V9R
Compatible with these devices	Sony Vaio VPCSB4L1ER
Compatible with these devices	Sony Vaio VPCSB4Z9E
Compatible with these devices	Sony Vaio VPCSD27ECP
Compatible with these devices	Sony Vaio VPCSE17FX
Compatible with these devices	Sony Vaio VPCSE1M1ES
Compatible with these devices	Sony Vaio VPCSE28FJS

Name	Description
Compatible with these devices	Sony Vaio VPCSE2M9EB
Compatible with these devices	Sony Vaio SVS13112EGB
Compatible with these devices	Sony Vaio SVS13118GGB
Compatible with these devices	Sony Vaio SVS1311F3EW
Compatible with these devices	Sony Vaio SVS1311P
Compatible with these devices	Sony Vaio SVS13123CV
Compatible with these devices	Sony Vaio SVS13127CC
Compatible with these devices	Sony Vaio SVS1312E3R
Compatible with these devices	Sony Vaio SVS1312S
Compatible with these devices	Sony Vaio SVS1313C
Compatible with these devices	Sony Vaio SVS1313P9EB
Compatible with these devices	Sony Vaio SVS13A190X
Compatible with these devices	Sony Vaio SVS13A1X
Compatible with these devices	Sony Vaio SVS13A2C5E
Compatible with these devices	Sony Vaio SVS13A3W9E
Compatible with these devices	Sony Vaio SVS15116GW
Compatible with these devices	Sony Vaio SVS1511L3E

Name	Description
Compatible with these devices	Sony Vaio SVS1511V9RB
Compatible with these devices	Sony Vaio SVS15128
Compatible with these devices	Sony Vaio SVS1512V9ES
Compatible with these devices	Sony Vaio SVS1513X9E
CAPACITY	4200 mAh
Compatible with these devices	Sony Vaio VPCSA25GGBI
Compatible with these devices	Sony Vaio VPCSA2GGXBI
Compatible with these devices	Sony Vaio VPCSA38GAX
Compatible with these devices	Sony Vaio VPCSA3S9RXI
Compatible with these devices	Sony Vaio VPCSA4EGX
Compatible with these devices	Sony Vaio VPCSB16FHL
Compatible with these devices	Sony Vaio VPCSB19FJB
Compatible with these devices	Sony Vaio VPCSB1V9R
Compatible with these devices	Sony Vaio VPCSB25FWW
Compatible with these devices	Sony Vaio VPCSB28GF
Compatible with these devices	Sony Vaio VPCSB2M9EB
Compatible with these devices	Sony Vaio VPCSB35FG

Name	Description
Compatible with these devices	Sony Vaio VPCSB37GAB
Compatible with these devices	Sony Vaio VPCSB3M1R
Compatible with these devices	Sony Vaio VPCSB47FJ
Compatible with these devices	Sony Vaio VPCSB4N9E
Compatible with these devices	Sony Vaio VPCSC4AFMS
Compatible with these devices	Sony Vaio VPCSD400C
Compatible with these devices	Sony Vaio VPCSE19FJB
Compatible with these devices	Sony Vaio VPCSE1V9RB
Compatible with these devices	Sony Vaio VPCSE2EFX
Compatible with these devices	Sony Vaio VPCSE2S1ES
Compatible with these devices	Sony Vaio SVS13115FXS
Compatible with these devices	Sony Vaio SVS1311B
Compatible with these devices	Sony Vaio SVS1311J3E
Compatible with these devices	Sony Vaio SVS1311R9ES
Compatible with these devices	Sony Vaio SVS13125CFB
Compatible with these devices	Sony Vaio SVS13127PXB
Compatible with these devices	Sony Vaio SVS1312J

Name	Description
Compatible with these devices	Sony Vaio SVS13133CFB
Compatible with these devices	Sony Vaio SVS1313J
Compatible with these devices	Sony Vaio SVS1313X9R
Compatible with these devices	Sony Vaio SVS13A1S
Compatible with these devices	Sony Vaio SVS13A1Z9E
Compatible with these devices	Sony Vaio SVS13A2X9RS
Compatible with these devices	Sony Vaio SVS151
Compatible with these devices	Sony Vaio SVS1511A4E
Compatible with these devices	Sony Vaio SVS1511S
Compatible with these devices	Sony Vaio SVS15123CXB
Compatible with these devices	Sony Vaio SVS1512C
Compatible with these devices	Sony Vaio SVS1512Z9R
Compatible with these devices	Sony Vaio SVS151A11M
Compatible with the following battery models	VGPBPS24
Compatible with these devices	Sony Vaio VPCSA27GCBI
Compatible with these devices	Sony Vaio VPCSA2Z9R
Compatible with these devices	Sony Vaio VPCSA3BGXSI

Name	Description
Compatible with these devices	Sony Vaio VPCSA3Z9R
Compatible with these devices	Sony Vaio VPCSA4W9E
Compatible with these devices	Sony Vaio VPCSB17GW
Compatible with these devices	Sony Vaio VPCSB1AGJ
Compatible with these devices	Sony Vaio VPCSB25
Compatible with these devices	Sony Vaio VPCSB26FGW
Compatible with these devices	Sony Vaio VPCSB2AGJ
Compatible with these devices	Sony Vaio VPCSB2X9RS
Compatible with these devices	Sony Vaio VPCSB35FX
Compatible with these devices	Sony Vaio VPCSB38FJP
Compatible with these devices	Sony Vaio VPCSB3Q9E
Compatible with these devices	Sony Vaio VPCSB4AFXB
Compatible with these devices	Sony Vaio VPCSB4T9EW
Compatible with these devices	Sony Vaio VPCSD19ECP
Compatible with these devices	Sony Vaio VPCSE15FH
Compatible with these devices	Sony Vaio VPCSE1D9E
Compatible with these devices	Sony Vaio VPCSE23FXB

Name	Description
Compatible with these devices	Sony Vaio VPCSE2K9E
Compatible with these devices	Sony Vaio VPCSE2X1R
Compatible with these devices	Sony Vaio SVS13117GGB
Compatible with these devices	Sony Vaio SVS1311E3E
Compatible with these devices	Sony Vaio SVS1311L9S
Compatible with these devices	Sony Vaio SVS13122C
Compatible with these devices	Sony Vaio SVS13126
Compatible with these devices	Sony Vaio SVS13129CJB
Compatible with these devices	Sony Vaio SVS1312N9EB
Compatible with these devices	Sony Vaio SVS13137PA
Compatible with these devices	Sony Vaio SVS1313M1RP
Compatible with these devices	Sony Vaio SVS13A15GNB
Compatible with these devices	Sony Vaio SVS13A1V
Compatible with these devices	Sony Vaio SVS13A26
Compatible with these devices	Sony Vaio SVS13A3B4E
Compatible with these devices	Sony Vaio SVS15115FNB
Compatible with these devices	Sony Vaio SVS1511EGXB

Name	Description
Compatible with these devices	Sony Vaio SVS1511T9ES
Compatible with these devices	Sony Vaio SVS15125CXB
Compatible with these devices	Sony Vaio SVS1512S1ES
Compatible with these devices	Sony Vaio SVS1513B
Compatible with these devices	Sony Vaio SVS1513M1EW
Compatible with these devices	Sony Vaio VPCSA21GX
Compatible with these devices	Sony Vaio VPCSA2C5E
Compatible with these devices	Sony Vaio VPCSA35GGT
Compatible with these devices	Sony Vaio VPCSA3L9EXI
Compatible with these devices	Sony Vaio VPCSA47GCSI
Compatible with these devices	Sony Vaio VPCSB16FAB
Compatible with these devices	Sony Vaio VPCSB18GGS
Compatible with these devices	Sony Vaio VPCSB1C7E
Compatible with these devices	Sony Vaio VPCSB25FH
Compatible with these devices	Sony Vaio VPCSB27GW
Compatible with these devices	Sony Vaio VPCSB2J9EP
Compatible with these devices	Sony Vaio VPCSB31FXW

Name	Description
Compatible with these devices	Sony Vaio VPCSB36FH
Compatible with these devices	Sony Vaio VPCSB39FJ
Compatible with these devices	Sony Vaio VPCSB3V9RB
Compatible with these devices	Sony Vaio VPCSB4L1ES
Compatible with these devices	Sony Vaio VPCSB4Z9EB
Compatible with these devices	Sony Vaio VPCSD27ECW
Compatible with these devices	Sony Vaio VPCSE17FXB
Compatible with these devices	Sony Vaio VPCSE1S1C
Compatible with these devices	Sony Vaio VPCSE290X
Compatible with these devices	Sony Vaio VPCSE2MFY
Compatible with these devices	Sony Vaio SVS13112EHW
Compatible with these devices	Sony Vaio SVS13118GNB
Compatible with these devices	Sony Vaio SVS1311F3W
Compatible with these devices	Sony Vaio SVS1311P9B
Compatible with these devices	Sony Vaio SVS13123CVB
Compatible with these devices	Sony Vaio SVS13127CCB
Compatible with these devices	Sony Vaio SVS1312E3RP

Name	Description
Compatible with these devices	Sony Vaio SVS1312S9E
Compatible with these devices	Sony Vaio SVS1313C4E
Compatible with these devices	Sony Vaio SVS1313R
Compatible with these devices	Sony Vaio SVS13A1A
Compatible with these devices	Sony Vaio SVS13A1X8R
Compatible with these devices	Sony Vaio SVS13A2V
Compatible with these devices	Sony Vaio SVS13A3W9ES
Compatible with these devices	Sony Vaio SVS15118
Compatible with these devices	Sony Vaio SVS1511L3ES
Compatible with these devices	Sony Vaio SVS1511W
Compatible with these devices	Sony Vaio SVS15128CC
Compatible with these devices	Sony Vaio SVS1512X
Compatible with these devices	Sony Vaio SVS1513X9EB
Overload protection	Yes
Compatible with these devices	Sony Vaio VPCSA25GGT
Compatible with these devices	Sony Vaio VPCSA2HGX
Compatible with these devices	Sony Vaio VPCSA38GG

Name	Description
Compatible with these devices	Sony Vaio VPCSA3SGX
Compatible with these devices	Sony Vaio VPCSA4FGX
Compatible with these devices	Sony Vaio VPCSB16FHP
Compatible with these devices	Sony Vaio VPCSB19GG
Compatible with these devices	Sony Vaio VPCSB1V9RB
Compatible with these devices	Sony Vaio VPCSB26
Compatible with these devices	Sony Vaio VPCSB28GFB
Compatible with these devices	Sony Vaio VPCSB2M9ES
Compatible with these devices	Sony Vaio VPCSB35FGB
Compatible with these devices	Sony Vaio VPCSB37GG
Compatible with these devices	Sony Vaio VPCSB3M1RL
Compatible with these devices	Sony Vaio VPCSB47FJB
Compatible with these devices	Sony Vaio VPCSB4N9EB
Compatible with these devices	Sony Vaio VPCSD1
Compatible with these devices	Sony Vaio VPCSD47EC
Compatible with these devices	Sony Vaio VPCSE1A9E
Compatible with these devices	Sony Vaio VPCSE1X1R

Name	Description
Compatible with these devices	Sony Vaio VPCSE2EFXB
Compatible with these devices	Sony Vaio VPCSE2S2C
Compatible with these devices	Sony Vaio SVS13115GGB
Compatible with these devices	Sony Vaio SVS1311B4E
Compatible with these devices	Sony Vaio SVS1311J3EW
Compatible with these devices	Sony Vaio SVS1311S
Compatible with these devices	Sony Vaio SVS13125CG
Compatible with these devices	Sony Vaio SVS13128
Compatible with these devices	Sony Vaio SVS1312J3E
Compatible with these devices	Sony Vaio SVS13133CG
Compatible with these devices	Sony Vaio SVS1313J1E
Compatible with these devices	Sony Vaio SVS1313X9RB
Compatible with these devices	Sony Vaio SVS13A1S9E
Compatible with these devices	Sony Vaio SVS13A1Z9ES
Compatible with these devices	Sony Vaio SVS13A2Z
Compatible with these devices	Sony Vaio SVS1511
Compatible with these devices	Sony Vaio SVS1511AGXB

Name	Description
Compatible with these devices	Sony Vaio SVS1511S1C
Compatible with these devices	Sony Vaio SVS15123CXS
Compatible with these devices	Sony Vaio SVS1512C5E
Compatible with these devices	Sony Vaio SVS1512Z9RB
Cell manufacturer	Greencell
Compatible with these devices	Sony Vaio VPCSA28
Compatible with these devices	Sony Vaio VPCSA2Z9RBI
Compatible with these devices	Sony Vaio VPCSA3C5E
Compatible with these devices	Sony Vaio VPCSA4
Compatible with these devices	Sony Vaio VPCSB
Compatible with these devices	Sony Vaio VPCSB17GWS
Compatible with these devices	Sony Vaio VPCSB1AGJA
Compatible with these devices	Sony Vaio VPCSB25FA
Compatible with these devices	Sony Vaio VPCSB26FW
Compatible with these devices	Sony Vaio VPCSB2AGJB
Compatible with these devices	Sony Vaio VPCSB2Z9R
Compatible with these devices	Sony Vaio VPCSB35FXB

Name	Description
Compatible with these devices	Sony Vaio VPCSB38FJW
Compatible with these devices	Sony Vaio VPCSB3Q9EP
Compatible with these devices	Sony Vaio VPCSB4AFXW
Compatible with these devices	Sony Vaio VPCSB4V9E
Compatible with these devices	Sony Vaio VPCSD1S1C
Compatible with these devices	Sony Vaio VPCSE15FHB
Compatible with these devices	Sony Vaio VPCSE1DGX
Compatible with these devices	Sony Vaio VPCSE23FXS
Compatible with these devices	Sony Vaio VPCSE2K9EB
Compatible with these devices	Sony Vaio VPCSE2X1RB
Compatible with these devices	Sony Vaio SVS13117GW
Compatible with these devices	Sony Vaio SVS1311E3EW
Compatible with these devices	Sony Vaio SVS1311M
Compatible with these devices	Sony Vaio SVS13122CXB
Compatible with these devices	Sony Vaio SVS13126P
Compatible with these devices	Sony Vaio SVS13129CJP
Compatible with these devices	Sony Vaio SVS1312P

Name	Description
Compatible with these devices	Sony Vaio SVS13137PAB
Compatible with these devices	Sony Vaio SVS1313M1RR
Compatible with these devices	Sony Vaio SVS13A15GW
Compatible with these devices	Sony Vaio SVS13A1V8R
Compatible with these devices	Sony Vaio SVS13A26PG
Compatible with these devices	Sony Vaio SVS13A3C
Compatible with these devices	Sony Vaio SVS15115FW
Compatible with these devices	Sony Vaio SVS1511F
Compatible with these devices	Sony Vaio SVS1511U
Compatible with these devices	Sony Vaio SVS15125CXW
Compatible with these devices	Sony Vaio SVS1512U
Compatible with these devices	Sony Vaio SVS1513B4E
Compatible with these devices	Sony Vaio SVS1513M1R
Compatible with these devices	Sony Vaio VPCSA22GX
Compatible with these devices	Sony Vaio VPCSA2CFX
Compatible with these devices	Sony Vaio VPCSA35GHT
Compatible with these devices	Sony Vaio VPCSA3M9E

Name	Description
Compatible with these devices	Sony Vaio VPCSA490X
Compatible with these devices	Sony Vaio VPCSB16FF
Compatible with these devices	Sony Vaio VPCSB18GH
Compatible with these devices	Sony Vaio VPCSB1D7E
Compatible with these devices	Sony Vaio VPCSB25FHL
Compatible with these devices	Sony Vaio VPCSB27GWS
Compatible with these devices	Sony Vaio VPCSB2J9EW
Compatible with these devices	Sony Vaio VPCSB33GX
Compatible with these devices	Sony Vaio VPCSB36FHR
Compatible with these devices	Sony Vaio VPCSB39FJB
Compatible with these devices	Sony Vaio VPCSB3V9RS
Compatible with these devices	Sony Vaio VPCSB4L1EW
Compatible with these devices	Sony Vaio VPCSB4Z9R
Compatible with these devices	Sony Vaio VPCSD28
Compatible with these devices	Sony Vaio VPCSE17FXS
Compatible with these devices	Sony Vaio VPCSE1S2C
Compatible with these devices	Sony Vaio VPCSE29FJ

Name	Description
Compatible with these devices	Sony Vaio VPCSE2MFYB
Compatible with these devices	Sony Vaio SVS13112ENB
Compatible with these devices	Sony Vaio SVS13118GW
Compatible with these devices	Sony Vaio SVS1311G
Compatible with these devices	Sony Vaio SVS1311P9E
Compatible with these devices	Sony Vaio SVS13123CW
Compatible with these devices	Sony Vaio SVS13127P
Compatible with these devices	Sony Vaio SVS1312E3RR
Compatible with these devices	Sony Vaio SVS1312S9EB
Compatible with these devices	Sony Vaio SVS1313C5E
Compatible with these devices	Sony Vaio SVS1313R9E
Compatible with these devices	Sony Vaio SVS13A1A4E
Compatible with these devices	Sony Vaio SVS13A1X8RB
Compatible with these devices	Sony Vaio SVS13A2V9R
Compatible with these devices	Sony Vaio SVS13A3X
Compatible with these devices	Sony Vaio SVS15118EC
Compatible with these devices	Sony Vaio SVS1511L3ESPR

Name	Description
Compatible with these devices	Sony Vaio SVS1511W9E
Compatible with these devices	Sony Vaio SVS15128CCB
Compatible with these devices	Sony Vaio SVS1512X1R
Compatible with these devices	Sony Vaio SVS1513X9R
Protection against overheating	Yes
Compatible with these devices	Sony Vaio VPCSA25GHT
Compatible with these devices	Sony Vaio VPCSA2HGXB1
Compatible with these devices	Sony Vaio VPCSA38GGX
Compatible with these devices	Sony Vaio VPCSA3SGXX
Compatible with these devices	Sony Vaio VPCSA4GFX
Compatible with these devices	Sony Vaio VPCSB16FHW
Compatible with these devices	Sony Vaio VPCSB19GGB
Compatible with these devices	Sony Vaio VPCSB1V9RS
Compatible with these devices	Sony Vaio VPCSB26FA
Compatible with these devices	Sony Vaio VPCSB28GG
Compatible with these devices	Sony Vaio VPCSB2P9E
Compatible with these devices	Sony Vaio VPCSB35FH

Name	Description
Compatible with these devices	Sony Vaio VPCSB37GGS
Compatible with these devices	Sony Vaio VPCSB3M1RP
Compatible with these devices	Sony Vaio VPCSB47FJP
Compatible with these devices	Sony Vaio VPCSB4N9ES
Compatible with these devices	Sony Vaio VPCSD18
Compatible with these devices	Sony Vaio VPCSD48EC
Compatible with these devices	Sony Vaio VPCSE1AFX
Compatible with these devices	Sony Vaio VPCSE1X1RB
Compatible with these devices	Sony Vaio VPCSE2F1E
Compatible with these devices	Sony Vaio VPCSE2S2C3C
Compatible with these devices	Sony Vaio SVS13115GNB
Compatible with these devices	Sony Vaio SVS1311BFXW
Compatible with these devices	Sony Vaio SVS1311K
Compatible with these devices	Sony Vaio SVS1311S9E
Compatible with these devices	Sony Vaio SVS13125CGP
Compatible with these devices	Sony Vaio SVS13128C
Compatible with these devices	Sony Vaio SVS1312J3EW

Name	Description
Compatible with these devices	Sony Vaio SVS13133CV
Compatible with these devices	Sony Vaio SVS1313J1EW
Compatible with these devices	Sony Vaio SVS1313Z
Compatible with these devices	Sony Vaio SVS13A1S9ES
Compatible with these devices	Sony Vaio SVS13A1Z9R
Compatible with these devices	Sony Vaio SVS13A2Z9E
Compatible with these devices	Sony Vaio SVS15112
Compatible with these devices	Sony Vaio SVS1511AJ
Compatible with these devices	Sony Vaio SVS1511S2C
Compatible with these devices	Sony Vaio SVS15125
Compatible with these devices	Sony Vaio SVS1512D
Compatible with these devices	Sony Vaio SVS1513
Gamintojas	Greencell
Compatible with these devices	Sony Vaio VPCSA28GABI
Compatible with these devices	Sony Vaio VPCSA2Z9RT
Compatible with these devices	Sony Vaio VPCSA3CGX
Compatible with these devices	Sony Vaio VPCSA400C

Name	Description
Compatible with these devices	Sony Vaio VPCSB1
Compatible with these devices	Sony Vaio VPCSB18
Compatible with these devices	Sony Vaio VPCSB1AGX
Compatible with these devices	Sony Vaio VPCSB25FAB
Compatible with these devices	Sony Vaio VPCSB26FWB
Compatible with these devices	Sony Vaio VPCSB2AJ
Compatible with these devices	Sony Vaio VPCSB2Z9RB
Compatible with these devices	Sony Vaio VPCSB35FXL
Compatible with these devices	Sony Vaio VPCSB38GA
Compatible with these devices	Sony Vaio VPCSB3Q9ES
Compatible with these devices	Sony Vaio VPCSB4AJ
Compatible with these devices	Sony Vaio VPCSB4V9EB
Compatible with these devices	Sony Vaio VPCSD1S2C
Compatible with these devices	Sony Vaio VPCSE16
Compatible with these devices	Sony Vaio VPCSE1DGXB
Compatible with these devices	Sony Vaio VPCSE25FX
Compatible with these devices	Sony Vaio VPCSE2KGX

Name	Description
Compatible with these devices	Sony Vaio VPCSE2X9E
Compatible with these devices	Sony Vaio SVS13118
Compatible with these devices	Sony Vaio SVS1311E3R
Compatible with these devices	Sony Vaio SVS1311M9E
Compatible with these devices	Sony Vaio SVS13122CXP
Compatible with these devices	Sony Vaio SVS13126PG
Compatible with these devices	Sony Vaio SVS13129CJS
Compatible with these devices	Sony Vaio SVS1312P9E
Compatible with these devices	Sony Vaio SVS13137PG
Compatible with these devices	Sony Vaio SVS1313M1RW
Compatible with these devices	Sony Vaio SVS13A16
Compatible with these devices	Sony Vaio SVS13A1V8RB
Compatible with these devices	Sony Vaio SVS13A26PGB
Compatible with these devices	Sony Vaio SVS13A3C5E
Compatible with these devices	Sony Vaio SVS15115FXB
Compatible with these devices	Sony Vaio SVS1511F4R
Compatible with these devices	Sony Vaio SVS1511U9E

Name	Description
Compatible with these devices	Sony Vaio SVS15126
Compatible with these devices	Sony Vaio SVS1512U1R
Compatible with these devices	Sony Vaio SVS1513BGXB
Compatible with these devices	Sony Vaio SVS1513M1RB
Compatible with these devices	Sony Vaio VPCSA23
Compatible with these devices	Sony Vaio VPCSA2CFXSI
Compatible with these devices	Sony Vaio VPCSA35GX
Compatible with these devices	Sony Vaio VPCSA3M9EXI
Compatible with these devices	Sony Vaio VPCSA4A4E
Compatible with these devices	Sony Vaio VPCSB16FFB
Compatible with these devices	Sony Vaio VPCSB18GHB
Compatible with these devices	Sony Vaio VPCSB1H7E
Compatible with these devices	Sony Vaio VPCSB25FHP
Compatible with these devices	Sony Vaio VPCSB28
Compatible with these devices	Sony Vaio VPCSB2L1E
Compatible with these devices	Sony Vaio VPCSB33GXB
Compatible with these devices	Sony Vaio VPCSB36FN

Name	Description
Compatible with these devices	Sony Vaio VPCSB3AFX
Compatible with these devices	Sony Vaio VPCSB3X9E
Compatible with these devices	Sony Vaio VPCSB4M1R
Compatible with these devices	Sony Vaio VPCSB4Z9RB
Compatible with these devices	Sony Vaio VPCSD28EC
Compatible with these devices	Sony Vaio VPCSE17GA
Compatible with these devices	Sony Vaio VPCSE1S2C3C
Compatible with these devices	Sony Vaio VPCSE29FJB
Compatible with these devices	Sony Vaio VPCSE2N1E
Compatible with these devices	Sony Vaio SVS13112FXB
Compatible with these devices	Sony Vaio SVS13119
Compatible with these devices	Sony Vaio SVS1311G3E
Compatible with these devices	Sony Vaio SVS1311P9EB
Compatible with these devices	Sony Vaio SVS13123CWR
Compatible with these devices	Sony Vaio SVS13127PA
Compatible with these devices	Sony Vaio SVS1312E3RW
Compatible with these devices	Sony Vaio SVS1312S9R

Name	Description
Compatible with these devices	Sony Vaio SVS1313D
Compatible with these devices	Sony Vaio SVS1313R9EB
Compatible with these devices	Sony Vaio SVS13A1AJ
Compatible with these devices	Sony Vaio SVS13A1X9E
Compatible with these devices	Sony Vaio SVS13A2V9RS
Compatible with these devices	Sony Vaio SVS13A3X9E
Compatible with these devices	Sony Vaio SVS15118ECW
Compatible with these devices	Sony Vaio SVS1511L3S
Compatible with these devices	Sony Vaio SVS1511W9EB
Compatible with these devices	Sony Vaio SVS15128CCW
Compatible with these devices	Sony Vaio SVS1512X1RB
Compatible with these devices	Sony Vaio SVS1513X9RB
Number of cells	6
Compatible with these devices	Sony Vaio VPCSA25GX
Compatible with these devices	Sony Vaio VPCSA2S9R
Compatible with these devices	Sony Vaio VPCSA38GWX
Compatible with these devices	Sony Vaio VPCSA3T9E

Name	Description
Compatible with these devices	Sony Vaio VPCSA4HGX
Compatible with these devices	Sony Vaio VPCSB16FW
Compatible with these devices	Sony Vaio VPCSB19GW
Compatible with these devices	Sony Vaio VPCSB1X9E
Compatible with these devices	Sony Vaio VPCSB26FAS
Compatible with these devices	Sony Vaio VPCSB28GGB
Compatible with these devices	Sony Vaio VPCSB2P9EB
Compatible with these devices	Sony Vaio VPCSB35FHP
Compatible with these devices	Sony Vaio VPCSB37GH
Compatible with these devices	Sony Vaio VPCSB3M1RR
Compatible with these devices	Sony Vaio VPCSB47FJW
Compatible with these devices	Sony Vaio VPCSB4Q9E
Compatible with these devices	Sony Vaio VPCSD18EC
Compatible with these devices	Sony Vaio VPCSE
Compatible with these devices	Sony Vaio VPCSE1B9E
Compatible with these devices	Sony Vaio VPCSE1X9E
Compatible with these devices	Sony Vaio VPCSE2F1ES

Name	Description
Compatible with these devices	Sony Vaio VPCSE2S3C
Compatible with these devices	Sony Vaio SVS13116
Compatible with these devices	Sony Vaio SVS1311C
Compatible with these devices	Sony Vaio SVS1311K9E
Compatible with these devices	Sony Vaio SVS1311S9EB
Compatible with these devices	Sony Vaio SVS13125CH
Compatible with these devices	Sony Vaio SVS13128CC
Compatible with these devices	Sony Vaio SVS1312K
Compatible with these devices	Sony Vaio SVS13133CVB
Compatible with these devices	Sony Vaio SVS1313K
Compatible with these devices	Sony Vaio SVS1313ZDZB
Compatible with these devices	Sony Vaio SVS13A1S9S
Compatible with these devices	Sony Vaio SVS13A1Z9RB
Compatible with these devices	Sony Vaio SVS13A2Z9ES
Compatible with these devices	Sony Vaio SVS15112C5
Compatible with these devices	Sony Vaio SVS1511B
Compatible with these devices	Sony Vaio SVS1511S3C

Name	Description
Compatible with these devices	Sony Vaio SVS15125CH
Compatible with these devices	Sony Vaio SVS1512DCXB
Compatible with these devices	Sony Vaio SVS15136
COLOUR	
Compatible with these devices	Sony Vaio VPCSA28GAT
Compatible with these devices	Sony Vaio VPCSA3
Compatible with these devices	Sony Vaio VPCSA3CGXBI
Compatible with these devices	Sony Vaio VPCSA41FX
Compatible with these devices	Sony Vaio VPCSB11
Compatible with these devices	Sony Vaio VPCSB18FJ
Compatible with these devices	Sony Vaio VPCSB1AGXB
Compatible with these devices	Sony Vaio VPCSB25FAL
Compatible with these devices	Sony Vaio VPCSB27
Compatible with these devices	Sony Vaio VPCSB2B7E
Compatible with these devices	Sony Vaio VPCSB2ZDZ
Compatible with these devices	Sony Vaio VPCSB35FXP
Compatible with these devices	Sony Vaio VPCSB38GAB

Name	Description
Compatible with these devices	Sony Vaio VPCSB3Q9EW
Compatible with these devices	Sony Vaio VPCSB4C5E
Compatible with these devices	Sony Vaio VPCSB4V9R
Compatible with these devices	Sony Vaio VPCSD1S3C
Compatible with these devices	Sony Vaio VPCSE16FW
Compatible with these devices	Sony Vaio VPCSE1E1E
Compatible with these devices	Sony Vaio VPCSE25FXB
Compatible with these devices	Sony Vaio VPCSE2KGXB
Compatible with these devices	Sony Vaio VPCSE2X9EB
Compatible with these devices	Sony Vaio SVS13118EC
Compatible with these devices	Sony Vaio SVS1311E3RP
Compatible with these devices	Sony Vaio SVS1311M9ES
Compatible with these devices	Sony Vaio SVS13122CXR
Compatible with these devices	Sony Vaio SVS13126PGR
Compatible with these devices	Sony Vaio SVS1312A
Compatible with these devices	Sony Vaio SVS1312P9EB
Compatible with these devices	Sony Vaio SVS13137PGB

Name	Description
Compatible with these devices	Sony Vaio SVS1313M9E
Compatible with these devices	Sony Vaio SVS13A16GAB
Compatible with these devices	Sony Vaio SVS13A1V8RS
Compatible with these devices	Sony Vaio SVS13A29
Compatible with these devices	Sony Vaio SVS13A3M
Compatible with these devices	Sony Vaio SVS15116
Compatible with these devices	Sony Vaio SVS1511G
Compatible with these devices	Sony Vaio SVS1511U9ES
Compatible with these devices	Sony Vaio SVS15126PA
Compatible with these devices	Sony Vaio SVS1512U1RW
Compatible with these devices	Sony Vaio SVS1513C
Compatible with these devices	Sony Vaio SVS1513M1RW
Compatible with these devices	Sony Vaio VPCSA23GWBI
Compatible with these devices	Sony Vaio VPCSA2DGX
Compatible with these devices	Sony Vaio VPCSA36
Compatible with these devices	Sony Vaio VPCSA3N9E
Compatible with these devices	Sony Vaio VPCSA4AGX

Name	Description
Compatible with these devices	Sony Vaio VPCSB16FG
Compatible with these devices	Sony Vaio VPCSB18GW
Compatible with these devices	Sony Vaio VPCSB1Q1E
Compatible with these devices	Sony Vaio VPCSB25FHS
Compatible with these devices	Sony Vaio VPCSB28FJ
Compatible with these devices	Sony Vaio VPCSB2L1ES
Compatible with these devices	Sony Vaio VPCSB33GXL
Compatible with these devices	Sony Vaio VPCSB36FNB
Compatible with these devices	Sony Vaio VPCSB3AFXW
Compatible with these devices	Sony Vaio VPCSB3X9EB
Compatible with these devices	Sony Vaio VPCSB4M1RL
Compatible with these devices	Sony Vaio VPCSC1AFM
Compatible with these devices	Sony Vaio VPCSD28ECB
Compatible with these devices	Sony Vaio VPCSE17GAB
Compatible with these devices	Sony Vaio VPCSE1S3C
Compatible with these devices	Sony Vaio VPCSE2AGX
Compatible with these devices	Sony Vaio VPCSE2N1ES

Name	Description
Compatible with these devices	Sony Vaio SVS13112FXP
Compatible with these devices	Sony Vaio SVS131190X
Compatible with these devices	Sony Vaio SVS1311G3ES
Compatible with these devices	Sony Vaio SVS1311Q
Compatible with these devices	Sony Vaio SVS13125
Compatible with these devices	Sony Vaio SVS13127PAB
Compatible with these devices	Sony Vaio SVS1312G
Compatible with these devices	Sony Vaio SVS1312S9RB
Compatible with these devices	Sony Vaio SVS1313D4E
Compatible with these devices	Sony Vaio SVS1313S
Compatible with these devices	Sony Vaio SVS13A1C
Compatible with these devices	Sony Vaio SVS13A1X9ES
Compatible with these devices	Sony Vaio SVS13A2W
Compatible with these devices	Sony Vaio SVS13A3X9ES
Compatible with these devices	Sony Vaio SVS15118FXB
Compatible with these devices	Sony Vaio SVS1511M
Compatible with these devices	Sony Vaio SVS1511X



SMART ELECTRONICS
SALE / REPAIR

CONTACT US | +370 639 77277

QUICK PRODUCTS DELIVERY

1-2 w.d.

Name	Description
Compatible with these devices	Sony Vaio SVS15129
Compatible with these devices	Sony Vaio SVS1512X9E

UAB "REGO TECH"

Company code: 302449356
PVM code: LT100005005917
C/A: LT927300010118749098

WWW.MARSIETIS.LT

Email: info@marsietis.lt
Mobile: +370 (639) 77 277
Vilniaus st. 230 Siauliai, LT-76303, Lithuania