

**ACER 5.5x1.7 mm | 19V | 4.74A | 90W | automobilinis nešiojamo kompiuterio
kroviklis**

Generuota 2025-12-16



Pavadinimas	Aprašymas
Kištuko diametras	5.5x1.7 mm
Įtampa	19V
Galia	90W
Srovė	4.74A
Įvesties įtampa	12V DC
KODAS	(AUT-3)

Pavadinimas
Aprašymas
MODELIAI

ACER aspire 5820TG 5949 AcerNote 350 Series AcerNote 367 AcerNote 3680 AcerNote 370 AcerNote 370 Series AcerNote 380 AcerNote 382 AcerNote 850C AcerNote LifeNote 373 AcerNote Light 350 AcerNote Light 360 AcerNote Light 370 AcerNote Light 371 AcerNote Light 372 AcerNote Light 373 AcerNote Light 374 AcerNote Light 380 Series Alpha 550 Series Alpha 550LC Alpha 550LV Alpha 550XV Alpha 551 Alpha 551VX Aspire 1200 Series Aspire 1200X Aspire 1200XV Aspire 1202 Aspire 1202X Aspire 1203X Aspire 1203XC Aspire 1203XV Aspire 1300 Aspire 1350 Aspire 1410 Aspire 1410 Series Aspire 1420P Aspire 1430 Aspire 1450 Aspire 1551 Aspire 1640 Aspire 1640 Series Aspire 1640Z Aspire 1650 Series Aspire 1650Z Aspire 1680 Aspire 1680 Series Aspire 1690 Aspire 1690 Series Aspire 1690-II Aspire 1810T Aspire 1810TZ Aspire 1820PT Aspire 1825PTZ Aspire 1830T Aspire 2000 Aspire 2000 Series Aspire 2010 Aspire 2010 Series Aspire 2012WLCi Aspire 2020 Aspire 2020 Series Aspire 2420 Aspire 2920 Aspire 2930 Aspire 3000 Aspire 3000 Series Aspire 3010 Aspire 3010 Series Aspire 3020 Aspire 3020 Series Aspire 3030 Aspire 3030 Series Aspire 3040 Series Aspire 3050 Aspire 3050 Series Aspire 3100 Aspire 3100 Series Aspire 3200 Series Aspire 3410 Aspire 3500 Aspire 3500 Series Aspire 3510 Series Aspire 3600 Aspire 3610 Aspire 3610 Series Aspire 3620 Aspire 3620 Series Aspire 3628AWXCi Aspire 3630 Series Aspire 3640 Series Aspire 3650 Series Aspire 3660 Series Aspire 3670 Series Aspire 3680 Series Aspire 3690 Series Aspire 4220 Aspire 4220G Aspire 4230 Aspire 4232 Aspire 4251 Aspire 4310 Aspire 4315 Aspire 4320 Aspire 4320G Aspire 4330 Aspire 4520 Aspire 4520G Aspire 4530 Aspire 4553 Aspire 4710 Aspire 4710G Aspire 4710Z Aspire 4710ZG Aspire 4720 Aspire 4720G Aspire 4730Z Aspire 4730ZG Aspire 4741 Aspire 4741G Aspire 4745 Aspire 4920 Aspire 4920G Aspire 4930 Aspire 4930G Aspire 5000 Aspire 5000 Series Aspire 5010 Aspire 5020 Aspire 5020 Series Aspire 5030 Aspire 5030 Series Aspire 5040 series Aspire 5050 Aspire 5050 Series Aspire 5100 Aspire 5100 Series Aspire 5110 Series Aspire 5230 Aspire 5235 Aspire 5236 Aspire 5310 Aspire 5315 Aspire 5330 Aspire 5332 Aspire 5500 Aspire 5500 Series Aspire 5500Z Aspire 5510 Series Aspire 5515 Aspire 5520 Aspire 5520G Aspire 5530 Aspire 5530G Aspire 5536 Aspire 5536G Aspire 5540 Aspire 5550 Series Aspire 5560 Series Aspire 5570 Aspire 5570 Series Aspire 5570Z Aspire 5580 Aspire 5580 Series Aspire 5590 Series Aspire 5600 Series Aspire 5610 Aspire 5610 Series Aspire 5610Z Aspire 5620 Series Aspire 5630 Aspire 5630 Series Aspire 5650 Series Aspire 5670 Aspire 5670 Series Aspire 5672 Aspire 5680 Aspire 5680 Series Aspire 5690 Aspire 5710 Aspire 5710G Aspire 5710Z Aspire 5710ZG Aspire 5715Z Aspire 5720 Aspire 5730Z Aspire 5730ZG Aspire 5732Z Aspire 5735 Aspire 5735Z Aspire 5740 Aspire 5740G Aspire 5820T Aspire 5910G Aspire 5920 Aspire 5920G Aspire 5930 Aspire 5930G Aspire 5935 Aspire 5949 Aspire 6530 Aspire 6920 Aspire 6920G Aspire 6930G Aspire 7000 Series Aspire 7100 Aspire 7100 Series Aspire 7110 Series Aspire 7220 Aspire 7230 Aspire 7330 Aspire 7520 Aspire 7520G Aspire 7530 Aspire 7530G Aspire 7535 Aspire 7540G Aspire 7720 Aspire 7720G Aspire 7730G Aspire 7730Z Aspire 7730ZG Aspire 7736 Aspire 7740 Aspire 7740G Aspire 7741 Aspire 7741G Aspire 7741Z Aspire 7741ZG Aspire 7745 Aspire 7745G Aspire 7745Z Aspire 8540 Aspire 8540G Aspire 8735 Aspire 8735G Aspire 8735ZG Aspire 8920G Aspire 8920g-6A4G32Bn Aspire 9100 Aspire 9100 Series Aspire 9110 Series Aspire 9120 Series Aspire 9300 Aspire 9300 Series Aspire 9302 Aspire 9400 Aspire 9400 Series Aspire 9410 Series Aspire 9410Z Aspire 9412WSMi Aspire 9420 Series Aspire 9500 Aspire 9500 Series Aspire 9510 series Aspire 9520 Series Aspire One 521 Aspire One 531 Aspire One 532 Aspire One 532h-2Ds Aspire One 532h-W123 Aspire One 533 Aspire One 533- 23571 Aspire One 721 Aspire One 721-3574 Aspire One 753 Aspire One D1X0 Aspire One D260 Aspire One D2X0 Aspire One Pro531 Aspire Timeline 1810T Aspire TimelineX 4820TG Extensa 355 Extensa 360 Series Extensa 390 Series Extensa 391 Extensa 391C Extensa 391T Extensa 392 Extensa 392C Extensa 392T Extensa 393 Extensa 393C Extensa 393T Extensa 394 Extensa 394T Extensa 395 Extensa 395T Extensa 4120 Extensa

4220 Extensa 4620 Extensa 500 Extensa 501 Extensa 502 Extensa 503 Extensa 505 Extensa 512 Extensa 513 Extensa 514 Extensa 515 Extensa 516 Extensa 517 Extensa 5220 Extensa 550 Extensa 555 Extensa 560 Extensa 5620 Extensa 5630 Extensa 5630G Extensa 565 Extensa 570 Extensa 600 Series Extensa 610 Extensa 616 Extensa 620 Extensa 690 Extensa 700 Extensa 710 Extensa 711 Extensa 712 Extensa 7220 Extensa 7620 Extensa 7620G Extensa 7630G Extensa 900 Ferrari 1000 Ferrari 1000 Series Ferrari 1100 Ferrari 3000 Ferrari 3000 Series Ferrari 3200 Ferrari 3200 Series Ferrari 3400 Ferrari 3400 Series Ferrari 4000 Ferrari 5000 Ferrari 5000 Series Ferrari FR1000 Ferrari FR1100 Ferrari FR5000 Ferrari One 200 TravelMate 200 Series TravelMate 210 TravelMate 220 Series TravelMate 230 TravelMate 2300 TravelMate 2300 Series TravelMate 2301 TravelMate 2303 TravelMate 2310 TravelMate 2310 Series TravelMate 2350 TravelMate 2350 Series TravelMate 2352 TravelMate 2353 TravelMate 2400 Travelmate 2400 Series TravelMate 2410 TravelMate 2410 Series Travelmate 2420 TravelMate 2420 Series TravelMate 2430 Travelmate 2430 Series Travelmate 2440 TravelMate 2440 Series Travelmate 2450 Travelmate 2450 Series Travelmate 2460 Series Travelmate 2470 Series Travelmate 2480 TravelMate 2480 Series TravelMate 2490 Series TravelMate 260 Series TravelMate 270 Series TravelMate 280 Travelmate 290 TravelMate 290ATI TravelMate 290E TravelMate 292LMi TravelMate 3000 TravelMate 3000 Series Travelmate 3010 Travelmate 3010 Series Travelmate 3020 Series Travelmate 3030 Series Travelmate 3040 Series TravelMate 320 Series TravelMate 3200 Travelmate 3200 Series Travelmate 3210 Series TravelMate 3220 Travelmate 3220 Series Travelmate 3230 Series TravelMate 3240 Series TravelMate 3250 Series Travelmate 3260 TravelMate 3260 Series TravelMate 3270 TravelMate 3270 Series TravelMate 3273WXMi TravelMate 3280 Series Travelmate 3290 Series TravelMate 330 Series TravelMate 3300 Series TravelMate 340 Series TravelMate 340T TravelMate 341TV TravelMate 342T TravelMate 343TV TravelMate 350 Series TravelMate 3500 TravelMate 360 Series TravelMate 365 TravelMate 370 Series TravelMate 380 Series TravelMate 3900 Series TravelMate 4000 TravelMate 4000 Series TravelMate 4000M TravelMate 4001 TravelMate 4001LMi TravelMate 4002 TravelMate 4010 Series TravelMate 4020 Series TravelMate 4050 TravelMate 4050 Series TravelMate 4051 TravelMate 4052 TravelMate 4053 TravelMate 4060 TravelMate 4060 Series TravelMate 4070 Travelmate 4070 Series Travelmate 4080 Series TravelMate 4100 Series TravelMate 4100-II TravelMate 4150 Series TravelMate 420 Series Travelmate 4200 TravelMate 4200 Series TravelMate 4200WLMi TravelMate 4202 TravelMate 4202WLMi Travelmate 4210 Series Travelmate 4220 TravelMate 4220 Series Travelmate 4230 TravelMate 4230 Series TravelMate 4260 Series Travelmate 4270 Series TravelMate 4280 Series TravelMate 430 Series TravelMate 4310 TravelMate 4320 TravelMate 4400 Series TravelMate 4500 Series TravelMate 4500 Series TravelMate 4520 TravelMate 4600 Travelmate 4600 Series TravelMate 4600-II Travelmate 4650 TravelMate 4650 Series Travelmate 4670 TravelMate 4670 Series Travelmate 4720 TravelMate 4730G TravelMate 505 TravelMate 505 Series TravelMate 506 TravelMate 506 Series TravelMate 507 TravelMate 507 Series TravelMate 508 TravelMate 508 Series TravelMate 510 Series Travelmate 5100 TravelMate 5100 Series TravelMate 5110 Series TravelMate 514TVX TravelMate 520 TravelMate 520iT TravelMate 521 TravelMate 5210 TravelMate 521TE TravelMate 521TEV TravelMate 521TXV TravelMate 5220 TravelMate 5220G TravelMate 5230 TravelMate 524 TravelMate 524TE TravelMate 524TXV TravelMate 525 TravelMate 525TX TravelMate 525TXV TravelMate 527 TravelMate 527TXV TravelMate 529 TravelMate 529ATXV TravelMate 529TXV TravelMate 530 Series TravelMate 5310 TravelMate 5320 TravelMate 5340 TravelMate 5400M TravelMate 5440 TravelMate 550 Series TravelMate 5510 Travelmate 5520 TravelMate 5520G TravelMate 5530 TravelMate 5530G Travelmate 5600 TravelMate 5600 Series TravelMate 5610 Series TravelMate 5620 Series TravelMate 5672WLMi Travelmate 5710 TravelMate 5710G Travelmate 5720 TravelMate 5720G TravelMate 5730 TravelMate 5730G TravelMate 5740 TravelMate 600 Series TravelMate

6000 series TravelMate 610 Series TravelMate 620 Series TravelMate 6231 Travelmate 6291 Travelmate 6292 TravelMate 630 Series Travelmate 6410 TravelMate 6410 series Travelmate 6460 TravelMate 6460 series TravelMate 6492 TravelMate 650 series Travelmate 6500 Series TravelMate 6592 TravelMate 6592G TravelMate 660 series TravelMate 662LVi TravelMate 710 Series TravelMate 720 Series TravelMate 7220 TravelMate 7220G TravelMate 7230 TravelMate 730 Series TravelMate 7320 TravelMate 7340 TravelMate 740 Series TravelMate 7510 TravelMate 7520 TravelMate 7520G TravelMate 7530 TravelMate 7530G TravelMate 7720 TravelMate 7720G TravelMate 7730 TravelMate 7730G TravelMate 7740 TravelMate 800 series TravelMate 8000 Series Travelmate 8100 TravelMate 8100 Series TravelMate 8100A TravelMate 8132 TravelMate 8200 TravelMate 8200 Series TravelMate 8204 Travelmate 8210 TravelMate 8210 Series TravelMate 8372T TravelMate C100 TravelMate C100 Series TravelMate C110 TravelMate C110 Series TravelMate C200 TravelMate C200 Series TravelMate C204Tmi TravelMate C210 Series TravelMate C300 Series TravelMate C300Xci TravelMate C310 TravelMate C310 Series TravelMate K-550 Series Travelmate® Tablets C200 Travelmate® Tablets C300 Travelmate® Tablets C310 TravelMate2302 5750g 5949, AcerNote 350 Series, AcerNote 367, AcerNote 3680, AcerNote 370, AcerNote 370 Series, AcerNote 380, AcerNote 382, AcerNote 850C, AcerNote LifeNote 373, AcerNote Light 350, AcerNote Light 360, AcerNote Light 370, AcerNote Light 371, AcerNote Light 372, AcerNote Light 373, AcerNote Light 374, AcerNote Light 380 Series, Alpha 550 Series, Alpha 550LC, Alpha 550LV, Alpha 550XV, Alpha 551, Alpha 551VX, Aspire 1200 Series, Aspire 1200X, Aspire 1200XV, Aspire 1202, Aspire 1202X, Aspire 1203X, Aspire 1203XC, Aspire 1203XV, Aspire 1300, Aspire 1350, Aspire 1410, Aspire 1410 Series, Aspire 1420P, Aspire 1430, Aspire 1450, Aspire 1551, Aspire 1640, Aspire 1640 Series, Aspire 1640Z, Aspire 1650 Series, Aspire 1650Z, Aspire 1680, Aspire 1680 Series, Aspire 1690, Aspire 1690 Series, Aspire 1690-II, Aspire 1810T, Aspire 1810TZ, Aspire 1820PT, Aspire 1825PTZ, Aspire 1830T, Aspire 2000, Aspire 2000 Series, Aspire 2010, Aspire 2010 Series, Aspire 2012WLCi, Aspire 2020, Aspire 2020 Series, Aspire 2420, Aspire 2920, Aspire 2930, Aspire 3000, Aspire 3000 Series, Aspire 3010, Aspire 3010 Series, Aspire 3020, Aspire 3020 Series, Aspire 3030, Aspire 3030 Series, Aspire 3040 Series, Aspire 3050, Aspire 3050 Series, Aspire 3100, Aspire 3100 Series, Aspire 3200 Series, Aspire 3410, Aspire 3500, Aspire 3500 Series, Aspire 3510 Series, Aspire 3600, Aspire 3610, Aspire 3610 Series, Aspire 3620, Aspire 3620 Series, Aspire 3628AWXci, Aspire 3630 Series, Aspire 3640 Series, Aspire 3650 Series, Aspire 3660 Series, Aspire 3670 Series, Aspire 3680, Series, Aspire 3690 Series, Aspire 4220, Aspire 4220G, Aspire 4230, Aspire 4232, Aspire 4251, Aspire 4310, Aspire 4315, Aspire 4320, Aspire 4320G, Aspire 4330, Aspire 4520, Aspire 4520G, Aspire 4530, Aspire 4553, Aspire 4710, Aspire 4710G, Aspire 4710Z, Aspire 4710ZG, Aspire 4720, Aspire 4720G, Aspire 4730Z, Aspire 4730ZG, Aspire 4741, Aspire 4741G, Aspire 4745, Aspire 4920, Aspire 4920G, Aspire 4930, Aspire 4930G, Aspire 5000, Aspire 5000 Series, Aspire 5010, Aspire 5020, Aspire 5020 Series, Aspire 5030, Aspire 5030 Series, Aspire 5040 series, Aspire 5050, Aspire 5050 Series, Aspire 5100 Aspire 5100 Series, Aspire 5110 Series, Aspire 5230, Aspire 5235, Aspire 5236, Aspire 5310, Aspire 5315, Aspire 5330, Aspire 5332, Aspire 5500, Aspire 5500 , Series Aspire 5500Z, Aspire 5510 Series, Aspire 5515, Aspire 5520, Aspire 5520G, Aspire 5530, Aspire 5530G, Aspire 5536, Aspire 5536G, Aspire 5540, Aspire 5550, Series Aspire 5560 Series, Aspire 5570, Aspire 5570, Series Aspire 5570Z, Aspire 5580, Aspire 5580 Series, Aspire 5590 Series, Aspire 5600 Series, Aspire 5610, Aspire 5610 Series, Aspire 5610Z, Aspire 5620 Series, Aspire 5630, Aspire 5630 Series, Aspire 5650 Series, Aspire 5670, Aspire 5670 Series, Aspire 5672, Aspire 5680, Aspire 5680 Series, Aspire 5690, Aspire 5710, Aspire 5710G, Aspire 5710Z, Aspire 5710ZG, Aspire 5715Z, Aspire 5720, Aspire 5730Z, Aspire 5730ZG, Aspire 5732Z, Aspire 5735, Aspire 5735Z, Aspire 5740, Aspire 5740G, Aspire 5820T, Aspire 5910G, Aspire 5920, Aspire 5920G, Aspire 5930, Aspire 5930G, Aspire 5935, Aspire 5949, Aspire 6530, Aspire 6920, Aspire 6920G, Aspire 6930G, Aspire 7000 Series, Aspire 7100, Aspire 7100 Series, Aspire 7110

Series, Aspire 7220, Aspire 7230, Aspire 7330, Aspire 7520, Aspire 7520G, Aspire 7530, Aspire 7530G, Aspire 7535, Aspire 7540G, Aspire 7720, Aspire 7720G, Aspire 7730G, Aspire 7730Z, Aspire 7730ZG, Aspire 7736, Aspire 7740, Aspire 7740G, Aspire 7741, Aspire 7741G, Aspire 7741Z, Aspire 7741ZG, Aspire 7745, Aspire 7745G, Aspire 7745Z, Aspire 8540, Aspire 8540G, Aspire 8735, Aspire 8735G, Aspire 8735ZG, Aspire 8920G, Aspire 8920g-6A4G32Bn, Aspire 9100, Aspire 9100 Series, Aspire 9110 Series, Aspire 9120 Series, Aspire 9300, Aspire 9300 Series, Aspire 9302, Aspire 9400, Aspire 9400 Series, Aspire 9410 Series, Aspire 9410Z, Aspire 9412WSMi, Aspire 9420 Series, Aspire 9500, Aspire 9500 Series, Aspire 9510 series, Aspire 9520 Series, Aspire One 521, Aspire One 531, Aspire One 532, Aspire One 532h-2Ds, Aspire One 532h-W123, Aspire One 533, Aspire One 533- 23571, Aspire One 721, Aspire One 721-3574, Aspire One 753, Aspire One D1X0, Aspire One D260, Aspire One D2X0, Aspire One Pro531, Aspire Timeline 1810T, Aspire TimelineX 4820TG, Extensa 355, Extensa 360 Series, Extensa 390 Series, Extensa 391, Extensa 391C, Extensa 391T, Extensa 392, Extensa 392C, Extensa 392T, Extensa 393, Extensa 393C, Extensa 393T, Extensa 394, Extensa 394T, Extensa 395, Extensa 395T, Extensa 4120, Extensa 4220, Extensa 4620, Extensa 500, Extensa 501, Extensa 502, Extensa 503, Extensa 505, Extensa 512, Extensa 513, Extensa 514, Extensa 515, Extensa 516, Extensa 517, Extensa 5220, Extensa 550, Extensa 555, Extensa 560, Extensa 5620, Extensa 5630, Extensa 5630G, Extensa 565, Extensa 570, Extensa 600 Series, Extensa 610, Extensa 616, Extensa 620, Extensa 690, Extensa 700, Extensa 710, Extensa 711, Extensa 712, Extensa 7220, Extensa 7620, Extensa 7620G, Extensa 7630G, Extensa 900, Ferrari 1000, Ferrari 1000 Series, Ferrari 1100, Ferrari 3000, Ferrari 3000 Series, Ferrari 3200, Ferrari 3200 Series, Ferrari 3400, Ferrari 3400 Series, Ferrari 4000, Ferrari 5000, Ferrari 5000 Series, Ferrari FR1000, Ferrari FR1100, Ferrari FR5000, Ferrari One 200, TravelMate 200 Series, TravelMate 210, TravelMate 220 Series, TravelMate 230, TravelMate 2300, TravelMate 2300 Series, TravelMate 2301, TravelMate 2303, TravelMate 2310, TravelMate 2310 Series, TravelMate 2350, TravelMate 2350 Series, TravelMate 2352, TravelMate 2353, TravelMate 2400, Travelmate 2400 Series, TravelMate 2410, TravelMate 2410 Series, Travelmate 2420, TravelMate 2420 Series, TravelMate 2430, Travelmate 2430 Series, Travelmate 2440, TravelMate 2440 Series, Travelmate 2450, Travelmate 2450 Series, Travelmate 2460 Series, Travelmate 2470 Series, Travelmate 2480, TravelMate 2480 Series, TravelMate 2490 Series, TravelMate 260 Series, TravelMate 270 Series, TravelMate 280, Travelmate 290, TravelMate 290ATI, TravelMate 290E, TravelMate 292LMi, TravelMate 3000, TravelMate 3000 Series, Travelmate 3010, Travelmate 3010 Series, Travelmate 3020 Series, Travelmate 3030 Series, Travelmate 3040 Series, TravelMate 320 Series, TravelMate 3200, Travelmate 3200 Series, Travelmate 3210 Series, TravelMate 3220, Travelmate 3220 Series, Travelmate 3230 Series, TravelMate 3240 Series, TravelMate 3250 Series, Travelmate 3260, TravelMate 3260 Series, TravelMate 3270, TravelMate 3270 Series, TravelMate 3273WXM, TravelMate 3280 Series, Travelmate 3290 Series, TravelMate 330 Series, TravelMate 3300 Series, TravelMate 340 Series, TravelMate 340T, TravelMate 341TV, TravelMate 342T, TravelMate 343TV, TravelMate 350 Series, TravelMate 3500, TravelMate 360 Series, TravelMate 365, TravelMate 370 Series, TravelMate 380 Series, TravelMate 3900 Series, TravelMate 4000, TravelMate 4000 Series, TravelMate 4000M, TravelMate 4001, TravelMate 4001LMi, TravelMate 4002, TravelMate 4010 Series, TravelMate 4020 Series, TravelMate 4050, TravelMate 4050 Series, TravelMate 4051, TravelMate 4052, TravelMate 4053, TravelMate 4060, TravelMate 4060 Series, TravelMate 4070, Travelmate 4070 Series, Travelmate 4080 Series, TravelMate 4100 Series, TravelMate 4100-II, TravelMate 4150 Series, TravelMate 420 Series, Travelmate 4200, TravelMate 4200 Series, TravelMate 4200WLMi, TravelMate 4202, TravelMate 4202WLMi, Travelmate 4210 Series, Travelmate 4220, TravelMate 4220 Series, Travelmate 4230, TravelMate 4230 Series, TravelMate 4260 Series, Travelmate 4270 Series, TravelMate 4280 Series, TravelMate 430 Series TravelMate 4310, TravelMate 4320, TravelMate 4400 Series, TravelMate 4500, TravelMate 4500 Series, TravelMate 4520, TravelMate 4600, Travelmate

4600 Series, TravelMate 4600-II, Travelmate 4650, TravelMate 4650 Series, Travelmate 4670, TravelMate 4670 Series, Travelmate 4720, TravelMate 4730G, TravelMate 505, TravelMate 505 Series, TravelMate 506, TravelMate 506 Series, TravelMate 507, TravelMate 507 Series, TravelMate 508, TravelMate 508 Series, TravelMate 510 Series, Travelmate 5100, TravelMate 5100 Series, TravelMate 5110 Series, TravelMate 514TVX, TravelMate 520, TravelMate 520iT, TravelMate 521, TravelMate 5210, TravelMate 521TE, TravelMate 521TEV, TravelMate 521TXV, TravelMate 5220, TravelMate 5220G, TravelMate 5230, TravelMate 524, TravelMate 524TE, TravelMate 524TXV, TravelMate 525, TravelMate 525TX, TravelMate 525TXV, TravelMate 527, TravelMate 527TXV, TravelMate 529, TravelMate 529ATXV, TravelMate 529TXV, TravelMate 530 Series, TravelMate 5310, TravelMate 5320, TravelMate 5340, TravelMate 5400M, TravelMate 5440, TravelMate 550 Series, TravelMate 5510, Travelmate 5520, TravelMate 5520G, TravelMate 5530, TravelMate 5530G, TravelMate 5600, TravelMate 5600 Series, TravelMate 5610 Series, TravelMate 5620 Series, TravelMate 5672WLMi, Travelmate 5710, TravelMate 5710G, Travelmate 5720, TravelMate 5720G, TravelMate 5730, TravelMate 5730G, TravelMate 5740, TravelMate 600 Series, TravelMate 6000 series, TravelMate 610 Series, TravelMate 620 Series, TravelMate 6231, Travelmate 6291, Travelmate 6292, TravelMate 630 Series, Travelmate 6410, TravelMate 6410 series, Travelmate 6460, TravelMate 6460 series, TravelMate 6492, TravelMate 650 series, Travelmate 6500 Series, TravelMate 6592, TravelMate 6592G, TravelMate 660 series, TravelMate 662LVi, TravelMate 710 Series, TravelMate 720 Series, TravelMate 7220, TravelMate 7220G, TravelMate 7230, TravelMate 730 Series, TravelMate 7320, TravelMate 7340, TravelMate 740 Series, TravelMate 7510, TravelMate 7520, TravelMate 7520G, TravelMate 7530, TravelMate 7530G, TravelMate 7720, TravelMate 7720G, TravelMate 7730, TravelMate 7730G, TravelMate 7740, TravelMate 800 series, TravelMate 8000 Series, Travelmate 8100, TravelMate 8100 Series, TravelMate 8100A, TravelMate 8132, TravelMate 8200, TravelMate 8200 Series, TravelMate 8204, Travelmate 8210, TravelMate 8210 Series, TravelMate 8372T, TravelMate C100, TravelMate C110, TravelMate C110 Series, TravelMate C200, TravelMate C200 Series, TravelMate C204Tmi, TravelMate C210 Series, TravelMate C300 Series, TravelMate C300Xci, TravelMate C310, TravelMate C310 Series, TravelMate K-550 Series, Travelmate® Tablets C200, Travelmate® Tablets C300, Travelmate® Tablets C310, TravelMate2302, 5750g Acer Aspire One Packard Bell EasyNote Acer Aspire 1810T Acer Aspire 1810TZ eMachines EM250 Gateway LT10 Acer Aspire One 521-105DC Acer Aspire One 521-105DK Acer Aspire 1420P Acer Aspire 1425P Acer Aspire 1430 Acer Aspire 1430Z Acer Aspire 1551 Acer Aspire 1810 Acer Aspire 1820PT Acer Aspire 1820PTZ Acer Aspire 1825PT Acer Aspire 1825PTZ Gateway EC14 Gateway EC1400 Gateway EC14D Gateway EC14T Gateway EC18 Gateway EC1803h Gateway EC1803u Gateway EC1805u Gateway EC1814u Gateway EC1815u Gateway EC18D Gateway EC18T Gateway LT2304C Gateway LT2315U Gateway LT2316U Gateway LT2318U Gateway LT2319U Gateway LT2320U Gateway LT2321U Gateway LT2503U Gateway LT2514U Gateway LT2523U Gateway LT2525U Gateway LT2526U Gateway LT2122 Gateway LT2122U Gateway LT2123 Gateway LT2123U Packard Bell Dot Acer Aspire 1820 Acer Aspire 1820P Acer Aspire 1820TP Acer Aspire 1825 Acer Aspire 1825PZ Dell Inspiron 1010 Dell Inspiron 1011 Dell Inspiron 1012 Dell Inspiron 1018 Dell Inspiron 1090 Dell Inspiron 11z Dell Inspiron 1210 Dell Inspiron 1210n Dell Inspiron 910 Dell Inspiron Duo Dell Inspiron Mini Acer ADP Acer HP Acer PA-1300 LITEON PA-1300 Acer Aspire 1200 / 1650 / 2000 / 2010 / 2020/ 2420 / 2920 / 2930 / 3050 / 3100 / 3030 / 3620 / 3610 / 3650 / 3660 / 3670 / 3680 / 4220 / 4230 / 4310 / 4320 / 4330 / 4520 / 4530 / 4710 / 4710Z / 4720 / 4730Z / 4920 / 4930 / 5050 / 5100 / 5230 / 5235 / 5310 / 5315 / 5330 / 5520 / 5530 / 5535 / 5570 / 5570Z / 5580 / 5710 / 5710Z / 5715Z / 5720 / 5730Z / 5735 / 5735Z / 5920G / 5930 / 6530 / 6920 / 7100 / 7230 / 7330 / 7530 / 7530G / 7730 / 7730Z / 9100 / 9400 + Acer Aspire 1300 Series / Acer Aspire 1350 Series / Acer Aspire 1360 SeriesAspire 3000 (3002LCi, 3002WLCi, 3002WLMi, 3003WLCi, 3003WLCi)Aspire 1680 (1681LCi, 1681WLCi, 1681WLMi, 1683WLMi, 1684WLMi,

1685WLMi)Aspire 5000 (5002LMI, 5002WLMi, 5004WLMi) / Aspire 1410 (1414WLCi) / Aspire 1640 (1642WLMi)Aspire 1690 (AS1690LCi, AS1690WLCi, AS1690WLMi, AS1691WLCi, AS1691WLMi, AS1692WLMi, AS1694WLMi)Aspire 3600 (3603WXCi, 3603WXM, 3602NWXMi, 3603WXCi 3603WXM, 3603NWXMi 3603NWXMi, 3603XCi, 3608NWXCi, 3608WXCi 3608WXM) Acer TravelMate 2350 / 2400 / 2410 / 2450 / 2460 / 2470 / 2480 / 3230 / 3030 / 3040 / 3250 / 3260 / 3270 / 3300 / 4060 / 4150 / 4220 / 4310 / 4320 / 4330 / 4520 / 4720 / 4730 / 5100 / 5210 / 5220 / 5230 / 5310 / 5320 / 5510 / 5520 / 5530 / 5600 / 5710 / 5720 / 5730 / 6231 / 6291 / 6292 / 6492 / 6592 / 7230 / 7320 / 7530 / 7720 / 7730TravelMate 2310 (2312LCi) / TravelMate 3000 (3002WTCi) / TravelMate 3210 (3213WXCi, 3213WXM)TravelMate 2300 (2301LC, 2301LCi, 2301WLCi, 2301XC, 2303LC, 2303LCi, 2303WLCi, 2304LCi, 2304WLCi, ZL1)TravelMate 3220 (3220WXCi 3220WXM, 3222WXCi, 3222WXM)TravelMate 4000 (4000LCi, 4000WLCi, 4001LCi, 4001WLCi, 4001WLMi, 4002WLMi)TravelMate 4020, 4050 (4052LCi) / TravelMate 4500 (4501WLMi) / TravelMate 4100 (4100LCi, 4100LMI)TravelMate 6000 (6003LMI) / TravelMate 8000 (8002LCi, 8003LMI, 8006LMI) / TravelMate 8100 (8104WLMi, ZF1)TravelMate 2xx-Series: (200DX / 200T / 201 / 201T / 202 / 202T / 210 Series / 210 / 210T / 210TER / 210TXF / 211 / 211T / 212 / 212T / 212TE / 212TXV / 213 / 213T / 213TX / 213TXV / 220 / 222 / 223 / 225Series / 222X / 223X / 223XC / 223XV / 225X / 225XC / 225XV / 230 / 233 / 234 Series / 230XC / 230XV / 230XV-PRO / 233LC / 233X / 233XV / 233XVi / 234LCi / 260 / 261 Series / 261XC / 261XV Series / 260 / 261Series / 261X / 261XC / 261XV / 270 / 272 / 273 / 275 Series / 270XV / 272LC / 272X / 272XV / 272XVi / 273X / 273XV / 275LC / 280 / 281 / 283 Series / 281XC / 281XV / 283LC / 283LCi / 283XV / 283XVi / 290Series / 290LC / 290LCi / 290LMI / 290XCi / 290Xi / 290XMi / 290XVi / 291LCi / 291LCi-G / 291LMI / 291LMI-G / 291XCi / 291XCiH / 292LC / 292LCi / 292LM / 292LMI / 293LCi / 293LMI)TravelMate 3xx-Series: (310 / 311 / 312 / 313 / 314 Series / 310T / 311T / 312T / 313T / 314T / 320 Series / 330 / 332 / 333 Series / 330T / 332T / 333T / 340 / 341 / 342 / 343 Series / 340T / 341TV / 342T / 343TV / 345 / 347 Series / 345T / 347T Series / 350 / 351 / 352 / 353 / 354 Series / 350TE / 350TE-N / 351TE / 351TEV / 352TE / 353TE / 353TEV / 354TE / 354TEV / 360 / 361 / 364 Series / 361EVi / 364ECi Series / 365 Series / 370 Series / 371LCi / 371LMI / 371TCi / 371TCi XP / 371Ti / 371TMI / 370 Series / 371LCi / 371LMI / 371TCi / 371TCi XP / 371Ti / 371TMI)TravelMate 5xx-Series: (512DX / 512T / 512TE / 512T-64 / 513DX / 513T / 514T / 514TXV / 515TE / 516TE / 517TE TravelMate 53x-Series: 530LC / 530LCi / 530XC / 530XCi / 530XV / 530XVi / 531LC / 531LCi / 531XC / 531XCi / 531XV / 531XVi / 533LC / 533LCi / 533XC / 533XCi / 533XV / 533XVi / 534LC / 534LCi / 534TL / 534XC / 534XCi / 534XV / 535LC / 535LCi / 536LCi TravelMate 540 Series / 540LCi / 540LMI / 541LC / 541LCi / 541LCib / 541LMI / 541XCi / 541XV / 542LCi / 542LMI / 543LCi / 543LMI)TravelMate 6xx-Series: (600 / 602 / 603 / 604 Series / 610 / 611 / 612 / 613 / 614 Series / 610TXC / 610TXV / 610TXVi / 611TXC / 611TXCi / 611TXV / 612TXC / 612TXCi / 612TXV / 613TXC / 613TXV / 614TXV / 620 / 621 / 623 Series / 621LV / 621XC / 621XV / 623LC / 623LCi / 630 / 632 / 633 Series / 630XV / 630XCi / 632XCi / 633LCi Series / 650LC / 650XC / 650XCi / 653LC / 653LCi / 653XC / 653XCi / 653XV / 654LC / 654LCi / 654XC / 654XCi / 654XV / 655LCi / 660LCi / 660LMI / 661LC / 661LCi / 661LM / 661LMI / 661XC / 661XCi / 661XVi / 662LC / 662LCi / 662LM / 662LMI / 662XCi / 663LCi / 663LM / 663LMI)TravelMate 7xx-Series: (720 / 722 / 723 Series / 720TX / 720TXV / 721TX / 722iTX / 722iTXV / 722TX / 723TX / 723TXV / 730 / 732 / 734 / 735 Series / 730TX / 730TXV / 732TLV / 732TX / 732TXV / 734TL / 734TXV / 735TLV / 736 / 737 / 738 / 739 Series / 736TL / 736TLV / 737TLV / 738TLV / 739GTLV / 739TLV / 740 / 741 / 744 Series / 740LVF / 741LVF / 744LCF) TravelMate 80x-Series: 800LC / 800LCi / 800LCib / 800LMI / 800LMib / 800XC / 800XCi / 801LC / 801LCi / 801LCib / 801LMI / 801LMib / 801XC / 801XCi / 801XVi / 802LCi / 802LCib / 802LMI / 802LMib / 802XCi / 803LC / 803LCi / 803LCib / 803LM / 803LMI / 803LMib / 803XCi / 803XVi / 804LC / 804LCi / 804LCib / 804LM / 804LMI / 804LMib Acer Extensa 4120 / 4220 / 4620 / 5220 / 5620 / 5630 / 7220 / 7620 Acer Ferrari FR1000 / FR1100Acer Ferrari 3000 Series / Acer Ferrari 3200 Series / Acer Ferrari 4000 Series / Acer Ferrari 5000 Series

Compatible Part Numbers: LC.ADT01.006, ADP-65DB (REV.B), PA-1700-02, LC-T2801-006, LC.ADT01.001, AP.T3503.002, AP.06501.006 177626-001 222113-001 261867-001 91.48R28.003 adp65db ADP-65DB AP.06503.006 180676-001 25.10064.04 91.41Q28.002 91.42S28.002 5901720130754 AP.T2101.001 198713-001 25.10110.171 91.41Q28.003 25.10064.041 ADT-W61 AP.06503.003 AP.06501.005

1200, 1362, 1400, 1410, 1450, 1551, 1640, 1642WLMi, 1650, 1650Z, 1680 1681, 1682, 1683, 1690, 1691, 1692, 1693, 1694, 1690-D2, 1830TZ, 2000 2001, 2002, 2003, 2012, 2010, 2020 2023, 2025, 2026, 2420, 2440, 2920, 2920Z, 2921, 2930, 2930Z, 3000, 3020, 3030, 3040, 3050, 3100, 3103, 3103WLMi, 3103NWLMi, 3200, 3410, 3410G, 3412GX, 3500, 3502, 3510, 3600, 3603, 3608, 3630, 3640, 3650, 3660, 3680, 3683, 3684, 3690, 3693, 3750, 3750G, 3750Z, 3750ZG, 3810TG, 3810TZ, 3810TZG, 3820, 3820G, 3820T, 3820TG, 3820TZ, 3820TZG, 3820ZG, 3830, 3830G, 3830T, 3830TG, 3935, 4220, 4220G, 4230, 4235, 4240, 4250, 4251, 4252, 4253, 4253G, 4310, 4315, 4320, 4330, 4332, 4333, 4336, 4339, 4349, 4350, 4350G, 4352, 4352G, 4410, 4520, 4520G, 4530, 4535, 4535G, 4540, 4540G, 4551, 4551G, 4552, 4552G, 4553, 4553G, 4560, 4560G, 4625, 4625G, 4710, 4710G, 4710Z, 4710ZG, 4715Z, 4720, 4720G, 4720Z, 4720ZG, 4730ZG, 4732Z, 4733Z, 4736, 4736-2, 4736G, 4736G-2, 4736Z, 4736ZG, 4736ZG-2, 4738, 4738G, 4738Z, 4738ZG, 4739, 4739Z, 4740, 4740G, 4741, 4741G, 4741Z, 4741ZG, 4743, 4743G, 4743Z, 4743ZG, 4745, 4745G, 4749, 4749Z, 4750, 4750G, 4750Z, 4750ZG, 4752, 4752G, 4752Z, 4752ZG, 4755, 4755G, 4810T-O, 4810TG, 4810TG-O, 4810TZ, 4810TZ-O, 4810TZG, 4810TZG-O, 4820, 4820G, 4820T, 4820TG, 4820TZ, 4820TZG, 4820Z, 4830, 4830G, 4830T, 4830TG, 4830Z, 4920, 4920G, 4925G, 4930, 4930G, 4935, 4935G, 4937, 4937G, 5000, 5020, 5030, 5040, 5043, 5044, 5050, 5100, 5101, 5102, 5103, 5110, 5220, 5230, 5235, 5241, 5250, 5251, 5252, 5253, 5253G, 5310, 5315, 5320, 5330, 5332, 5333, 5334, 5335, 5335Z, 5336, 5338, 5342, 5349, 5410, 5500, 5500Z, 5510, 5515, 5516, 5517, 5520, 5520G, 5530, 5530G, 5532, 5534, 5535, 5536, 5536G, 5538, 5538G, 5540, 5541, 5541G, 5542, 5542G, 5550, 5551, 5551G, 5552, 5552G, 5553, 5553G, 5560, 5560_V3, 5560G, 5570, 5570Z, 5580, 5590, 5600, 5610, 5620, 5625, 5625G, 5630, 5650, 5670, 5672, 5680, 5710, 5710Z, 5710ZG, 5715Z, 5715ZG, 5720, 5720G, 5720Z, 5720ZG, 5730G, 5730Z, 5730ZG, 5732Z, 5732ZG, 5733, 5733Z, 5734Z, 5735, 5735Z, 5736, 5736Z, 5737Z, 5738, 5738-2, 5738DZG, 5738G, 5738G-2, 5738PG, 5738PZG, 5738Z, 5738Z-2, 5738ZG, 5738ZG-2, 5739, 5739G, 5740, 5740DG, 5740G, 5741, 5741G, 5741Z, 5741ZG, 5742, 5742G, 5742Z, 5742ZG, 5745, 5745G, 5745P, 5745PG, 5745Z, 5749, 5749Z, 5750, 5750Z, 5750ZG, 5755, 5755G, 5810TG, 5810TZ, 5810TZG, 5820G, 5820T, 5820TG, 5820TZ, 5820TZG, 5830G, 5830T, 5830TG, 5910G, 5920, 5930, 5930G, 5935, 5935G, 5940G, 5942G, 5943G, 5951G, 6530, 6530G, 6920, 6930, 6930G, 6930ZG, 6935, 6935G, 7000, 7100, 7103, 7104, 7110, 7111, 7121, 7130, 7110R, 7111R, 7121R, 7130R, 7100R, 7220, 7230, 7250, 7250G, 7251, 7315, 7339, 7520, 7520G, 7530, 7530G, 7535, 7535G, 7540, 7540G, 7551, 7551G, 7552G, 7560, 7560G, 7715Z, 7720, 7720G, 7720Z, 7720ZG, 7730, 7730G, 7730Z, 7730ZG, 7735, 7735G, 7735Z, 7735ZG, 7736, 7736G, 7736Z, 7736ZG, 7738, 7738G, 7739, 7739G, 7739Z, 7739ZG, 7740, 7740G, 7741, 7741G, 7741Z, 7741ZG, 7745, 7745G, 7745Z, 7750, 7750G, 7750Z, 7750ZG, 8000, 8100, 8530, 8530G, 8730, 8730G, 8730ZG, 8735, 8735G, 8735ZG, 8920, 8930, 8943G, 9100, 9110, 9120, 9302WSMi, 9304, 9305, 9400, 9410, 9410AWSMi, 9410Z, 9411, 9411AWSMi, 9412, 9412AWSMi, 9412WSMi, 9500, 9510, 9520, AXC-704, AZ3-105, AZ3-115, AZ3-605, AZ3-610, AZ3-613, AZ3-615, AZ3-710, AZC-605, AZC-700, E1-410, E1-410G, E1-421, E1-422, E1-422G, E1-430, E1-430G, E1-430P, E1-431, E1-431G, E1-432, E1-432G, E1-451G, E1-470, E1-470G, E1-470P, E1-470PG, E1-471, E1-471G, E1-472, E1-472G, E1-472P, E1-472PG, E1-521, E1-522, E1-530, E1-530G, E1-531, E1-531G, E1-532, E1-532G, E1-532P, E1-532PG, E1-570, E1-570G, E1-571, E1-572, E1-572G, E1-572P, E1-572PG, E1-731G, E1-732, E1-732G, E1-771, E1-771G, E1-772, E1-772G, E5-411, E5-471G, E5-472G, E5-521G, E5-531G, E5-551G, E5-571PG, E5-572G, E5-573, E5-575G, E5-721, E5-722G, E5-731, E5-731G, E5-771G, E5-772G, L100, M3-481, M3-481G, M3-580, M3-580G, M3-581G, M3-581PT, M3-581PTG, M3-581T, M3-581TG, M5-481, M5-481G, M5-481PT, M5-481PTG,

M5-481T, M5-481TG, M5-581G, M5-581T, M5-581TG, Nitro VN7-572G, R3600, R3610, R3700, R7-571, R7-571G, R7-572, R7-572G, S3-331, S3-371, S3-391, S3-951, S3-951 13,3", V3 15,6", V3-431, V3-471, V3-471G, V3-472PG, V3-531, V3-531G, V3-551, V3-551G, V3-571, V3-572G, V3-572PG, V3-731, V3-731G, V3-771, V3-771G, V3-772G, V5 15,6", V5-431, V5-431G, V5-431P, V5-431PG, V5-452G, V5-452PG, V5-471, V5-471G, V5-471P, V5-471PG, V5-472, V5-472G, V5-472P, V5-472PG, V5-473, V5-473G, V5-473P, V5-473PG, V5-531, V5-531G, V5-531P, V5-531PG, V5-551, V5-551G, V5-552, V5-552PG, V5-561G, V5-561PG, V5-571, V5-571G, V5-571P, V5-571PG, V5-572, V5-572G, V5-572P, V5-572PG, V5-573, V5-573G, V5-573P, V5-573PG, V7-481, V7-481G, V7-481P, V7-481PG, V7-482P, V7-482PG, V7-581, V7-581G, V7-581P, V7-581PG, V7-582P, V7-582PG, VN7-571, VN7-571G, VN7-591G, Z1220, Z1650, Z1650_WD, Z3-605, ZC-605, V3-571G, 9300, 5610Z, V5-552G, 3620/3623/3624, 5738DG, 5920G, E5-571G, 5820, E1-571G, 1640Z, 6920G, E1-731, V5-552P, E5-521, 1360, 3610/3613/3614, 9420, 5710G, 8920G, 4730Z, 8930G, E5-573G, VN7-791G 8935G, 1200X, 1200XV, 1202, 1202X, 1203X, 1203XC, 1203XV, 1300, 1350, 1420P, 1430, 1680, 1690-II, 1810T, 1810TZ, 1820PT, 1825PTZ, 1830T, 2000, 2012WLCi, 2020, 3010, 3610, 3620, 3628AWXCi, 3670, 4232, 4320G, 5010, 5236, 5690, 5750g, 5949, 7330, 8540, 8540G, 8920g-6A4G32Bn, 9302

Aspire One:

521, 531 532 532h-2Ds, 532h-W123, 533, 533- 23571, 721, 721-3574, 753, D1X0, D260, D2X0721, D250, D270, Pro531

Aspire Revo:

RL100, RL101, RL70, RL70_HE450

Aspire Timeline TimelineX:

1810T, 3810T, 4810T, 5810T, 5830T, 5830TG

eMachines:

D440, D442, D443, D520, D525, D528, D529, D620, D640, D640G, D642, D644, D644G, D720, D725, D728, D729, D729Z, D730, D730G, D730Z, D730ZG, D732, D732G, D732Z, D732ZG, E430, E440, E442, E443, E520, E525, E527, E528, E529, E620, E625, E627, E628, E630, E640, E640G, E642, E642G, E644, E644G, E720, E725, E727, E728, E729, E729Z, E730, E730G, E730Z, E730ZG, E732, E732G, E732Z, E732ZG, G420, G430, G443, G443G, G520, G525, G620, G625, G627, G630, G630G, G640, G640G, G720, G725, G729G, G729Z, G729ZG, G730, G730G, G730Z, G730ZG, R1401, R1402, Z1700, Z1711, E510

Extensa:

355, 360, 390, 391, 391C, 391T, 392, 392C, 392T, 393, 393C, 393T, 394, 394T, 395, 395T, 4120, 4220, 4620, 500, 501, 502, 503, 505, 512, 513, 514, 515, 516, 517, 5220, 550, 555, 560, 5620, 5630, 5630G, 565, 570, 600, 610, 616, 620, 690, 700, 710, 711, 712, 7220, 7620, 7620G, 7630G, 900, 2300, 2350, 2510G, 2600, 2900, 3000, 3001, 3100, 365, 366D, 367D, T, 368D, 390C, CX, 4100, 4100-D2, 4130, 4230, 4420, 4620Z, 4630, 4630G, 4630Z, 4630ZG, 500DX, 5010, 501DX, 501T, 502DX, 502T, 503T, 505DX, 5200, 5210, 5230, 5230E, 5235, 5410, 5420, 5420G, 5430, 550CD, CDT, 5510, 5510Z, 555CD, 560CD, 5610, 5610G, 5620G, 5620ZG, 5630EZ, 5630Z, 5630ZG, 5635, 5635-2, 5635G, 5635G-2, 5635Z, 5635ZG, 5635ZG-2, 565CD, 570CD, 5735G-2, 575CD, 620CD, 6600, 6700, 710DX, 710T, 710TE, 711TE, 712TE, 712TEV, 7230, 7230E, 7420, 7620Z, 7630, 7630EZ, 7630Z, 7630ZG, 550CDT, 555CDT, 560CDT, 565CDT, 570CDT, 575CDT, 5620Z

Acer Ferrari:

1000, 1100, 1200, 3000, 3200, 3400, 4000, 4005, 5000, FR1000, FR1100, FR5000, One 200

Gateway:

EC49C, ID56 M92, ID56 UMA, ID58 N10, ID58 UMA, LT32, N74G, N78G, NO20T, NO50T, NO50TG, NO51I, NO51IE, NO51IG, NS30I, NS40GTG, NS40T, NS40TG, NS41C, NS41I, NS50T, NS51C, NS51I, NS51IG, NV40, NV42, NV44, NV47H, NV48, NV50A, NV51, NV51B, NV51M, NV52, NV52L, NV53, NV53A, NV54, NV55C, NV55S, NV56, NV56R, NV57H, NV58, NV59, NV59C, NV73, NV74, NV75S, NV76R, NV77H, NV78, NV79, TC72C, TC73C, TC78C

Acer LCD monitoriai:

H274HT, HN274HBT, HN274HT, HR274HT, T232HLT, T272HLT

TravelMate:

200, 210, 220, 230, 2300, 2301, 2302, 2303, 2310, 2350, 2352, 2353, 2400, 2410, 2420, 2430, 2440, 2450, 2460, 2470, 2480, 2490, 260, 270, 280, 290, 290ATi, 290E, 292Lmi, 3000, 3010, 3020, 3030, 3040, 320, 3200, 3210, 3220, 3230, 3240, 3250, 3260, 3270, 3273WXM, 3280, 3290, 330, 3300, 340, 340T, 341TV, 342T, 343TV, 350, 3500, 360, 365, 370, 380, 3900, 4000, 4000M, 4001, 4001Lmi, 4002, 4010, 4020, 4050, 4051, 4052, 4053, 4060, 4070, 4080, 4100, 4100-II, 4150, 420, 4200, 4200WLMi, 4202, 4202WLMi, 4210, 4220, 4230, 4260, 4270, 4280, 430, 4310, 4320, 4400, 4500, 4520, 4600, 4600-II, 4650, 4670, 4720, 4730G, 505, 506, 507, 508, 510, 5100, 5110, 514TVX, 520, 520iT, 521, 5210, 521TE, 521TEV, 521TVX, 5220, 5220G, 5230, 524, 524TE, 524TVX, 525, 525TX, 525TVX, 527, 527TVX, 529, 529ATXV, 529TVX, 530, 5310, 5320, 5340, 5400M, 5440, 550, 5510, 5520, 5520G, 5530, 5530G, 5600, 5610, 5620, 5672WLMi, 5710, 5710G, 5720, 5720G, 5730, 5730G, 5740, 600, 6000, 610, 620, 6231, 6291, 6292, 630, 6410, 6460, 6492, 650, 6500, 6592, 6592G, 660, 662Lvi, 710, 720, 7220, 7220G, 7230, 730, 7320, 7340, 740, 7510, 7520, 7520G, 7530, 7530G, 7720, 7720G, 7730, 7730G, 7740, 800, 8000, 8100, 8100A, 8132, 8200, 8204, 8210, 8372T, C100, C110, C200, C204Tmi, C210, C300, C300Xci, C310, K-550, Tablets C200, Tablets C300, Tablets C310, 200DX/T, 201DX/T/TVX, 202T/TE/TEV, 203TX, 210 210,212,213, 222, 223, 225, 222X, 223X, 223XC, 223XV, 225X, 225XC, 225XV, 230 230, 233, 2300 2301, 2310 2312, 2313, 2319, 2350 2353, 2354, 2355, 2410 2413, 2419, 2492 WLMi, 261, 261X, 261XC, 261XV, 272, 273, 275, 270XV, 272LC, 272X, 272XV, 272Xvi, 273X, 273XV, 275LC, 292LCi, 3200 3201, 3202, 3203, 3204, 3210Z, 332, 333, 330T, 331T, 332T, 333T, 341, 342, 343, 345, 345T, 347, 347T, 351, 352, 353, 354, 350TE/TE-N, 351TEV/TEV-D/TEV-N, 352TE, 353TE, 353TEV, 354TE, 354TEV, 361, 364, 361Evi, 364ECi, 370 370, 371, 372, 374, 4000 4001, 420 420/422/426/427, 430 432, 433, 435, 4330, 4335, 4530, 4600-D2, 4730, 4740, 4740G, 4740Z, 4750G, 505DX/T, 506DX/T, 507DX/T, 508DX/T, 512, 513, 514, 515, 516, 517, 510DX, 510T, 511TE, 512DX, 512T, 512TE, 513T, 514T, 514TE, 514TVX, 515T, 515TE, 516TE, 517TE, 518TX, 520 CELERON, 520 Pentium III 521,522,524,525,529, 521TE/TEV/TVX, 522TX/TVX, 525TX/TVX, 530 533, 535, 5330, 5335, 5344, 5360, 5513ZWLMi, 5542, 5542G, 5730-3G, 5735, 5735Z, 5735ZG, 5740G, 5740Z, 5740ZG, 5742, 5742G, 5742Z, 5742ZG, 5744, 5744Z, 5760, 5760G, 5760Z, 5760ZG, 602, 603, 604, 6000 6001, 6002, 6003, 6004, 600TER, 602TER, 603TER, 604TER, 611, 612, 613, 614, 610TXC, 610TVX, 610TVXi, 611TXC, 611TXci, 611TVX, 612TXC, 612TXci, 612TVX, 613TXC, 613TVX, 614TVXci, 621, 623, 621LV, 621XC, 621XV, 623LC, 623LCi, 6252, 6290, 6293-G, 630 630,632,633,634,636,637, 630XV, 630Xci, 632Xci, 633LCi, 6400, 6452, 6493, 6493-G, 6495T, 6495TG, 650 654, 653, 6552, 6593, 6593-G, 6594, 6594G, 6595G, 6595T, 6595TG, 660 661, 662, 663, 722, 723, 720TX, 721TX, 722TX/ITX, 722TXNT, 722TVX/ITXV, 723TX, 723TVX, 732, 734, 735, 730TE/TX/TVX, 732TLV/TVX, 7330, 734TL/TVX, 735TLV, 736, 737, 738, 739, 736TL/TLV, 737TLV, 738TLV, 739TLV/GTLV, 741, 744, 740LVF, 741LVF, 744LCF, 7514, 7740G, 7750, 7750G, 7750Z, 7750ZG, 800 800, 801, 803, 804, 8000 8002, 8003, 8004, 8005, 8006, 8003LMI, 8004LMI, 8100 8101, 8103, 8104, 8106, 8100 8102 WL CI , 8104LMI / WLMi, 8100S, 8215, 8371G, 8372, 8372G, 8372T HF, 8372TG HF, 8372TZ, 8372Z, 8372ZG, 8431, 8471G, 8472 HF, 8472G HF, 8472T HF, 8472TG HF, 8473, 8473G, 8473T, 8473TG, 8481, 8481G, 8481T, 8481TG, 8531, 8571G, 8572 HF, 8572G HF, 8572T HF, 8572TG HF, 8573, 8573G, 8573T, 8573TG, C100 Tablet 102, 104, C110 Tablet C110, C111, C200 Tablet 202, 204, C300 Tablet 300, 301, 302, 303, C300Xci-G, C301Xci, C301Xci-G, C302MXi, C302XMi, C302XMi-G, C310 Tablet 311, 312, 313, 314, P253, P453, P633, P653, TM C200, TM C210, TM C310, TM2490, TM3030, TM3040, TM3210Z, TM4060, TM4270, TM4280, TM4310, TM4335, TM4350, TM4730, TM4730G, TM4740, TM4740G, TM4740Z, TM4740ZG, TM4750, TM4750G, TM4750Z, TM4750ZG, TM5210, TM5230, TM5310, TM5330, TM5335, TM5344, TM5360, TM5360G, TM5510, TM5530, TM5530G, TM5542, TM5542G, TM5710, TM5710G, TM5730, TM5730_3G, TM5730G, TM5735, TM5735Z, TM5735ZG, TM5740, TM5740G, TM5740Z,

TM5740ZG, TM5742, TM5742G, TM5742Z, TM5742ZG, TM5744, TM5744Z, TM5760, TM5760G, TM5760Z, TM5760ZG, TM6410, TM6460, TM6493, TM6495, TM6495G, TM6495T, TM6495TG, TM6592, TM6593, TM6593G, TM6594, TM6594e, TM6594eG, TM6594G, TM6595, TM6595G, TM6595T, TM6595TG, TM7330, TM7530, TM7530G, TM7730, TM7730G, TM7740, TM7740G, TM7750, TM7750G, TM7750Z, TM7750ZG, TM8210, TM8331, TM8372, TM8372 HF, TM8372G, TM8372G HF, TM8372T, TM8372T HF, TM8372TG, TM8372TG HF, TM8372TZ, TM8372Z, TM8372Z HF, TM8372ZG, TM8372ZG HF, TM8431, TM8471, TM8471G, TM8472, TM8472 HF, TM8472G, TM8472G HF, TM8472T, TM8472T HF, TM8472TG, TM8472TG HF, TM8472Z, TM8472ZG, TM8473, TM8473G, TM8473T, TM8473TG, TM8473Z, TM8481, TM8481G, TM8481T, TM8481TG, TM8531, TM8571, TM8571G, TM8572, TM8572 HF, TM8572G, TM8572G HF, TM8572T, TM8572T HF, TM8572TG, TM8572TG HF, TM8572Z, TM8573, TM8573G, TM8573T, TM8573TG, 6293 P238-M-3273 P243-M, P243-MG, P245-M, P245-MG, P245-MP, P245-MPG, P246-MG, P253-E, P253-M, P253-MG, P255-M, P255-MG, P255-MPG, P256-MG, P273-M, P273-MG, P276-MG, P277-MG, P453-M, P453-MG, P455-M, P455-MG, P633-M, P633-V, P643-M, P643-MG, P643-V, P645-M, P645-MG, P645-V, P645-VG, P653-M, P653-MG, P653-V

TravelMate Timeline:

8371, 8372, 8471, 8571

TravelMate X:

TMX483, TMX483G

Veriton:

N2120G, N260G, N270G, N280G, N281G, N282G, N4620GE, N4630GW, Z2640GW, Z2660GW, Z290G, Z291G, Z292G, Z4810G

Advent:

8315, HEL81, IFL90, IFL91, IFT00

Packard Bell:

Butterfly, M, M-FM-440NC, DOT A, EASY, ONE (NO DURON), ONE (WITH DURON), ONE 3120, ONE DC, ONE DC 1700DVD, ONE DC 1701, ONE SILVER, ONE SILVER 3101, EasyNote, BFM, BFS2, BU45, LE11BZ, LE69KB, LJ61, LJ65, LJ67, LJ71, LJ71, LJ73, LJ73, LJ75, LJ75, LJ77, LK11BZ, LK13BZ, LM81, LM81, LM82, LM82, LM83, LM83, LM85, LM85, LM86, LM86, LM87, LM87, LM88, LM89, LM94, LM94, LM98, LM98, LS11, LS11HR, LS11SB, LS13HR, LS13SB, LS44HR, LS44SB, LV11HC, LV44HC, LX86, MH35, MX36, MX52, NE11HC, NJ31, NJ32, NJ65, NJ66, NM85, NM86, NM87, NM98, NS11HR, NS44HR, NS45HR, NX69HR, NX82, NX86, SC 3700, SC 3750, SC J2i, SILVER, T5, TE11BZ, TE11BZ, TE11HC, TE11HC, TE69CX, TE69CXP, TE69HW, TE69KB, TH36, TJ61, TJ62-RB-240NC, TJ64, TJ65, TJ65-CU860NC, TJ66, TJ68, TJ71, TJ72, TJ73, TJ74, TJ75, TJ76, TJ78, TK11, TK11BZ, TK13, TK13BZ, TK36, TK37, TK81, TK83, TK85, TK87, TM01, TM05, TM80, TM81, TM82, TM83, TM85, TM86, TM87, TM89, TM93, TM94, TM97, TM98, TM99, TN65, TR81, TR83, TS11, TS11HR, TS11SB, TS13HR, TS13SB, TS44HR, TS44SB, TS45HR, TS45SB, TSX62HR, TSX66HR, TV11CM, TV11HC, TV43CM, TV43CM, TV43HC, TV44CM, TV44CM, TV44HC, TX62HR, TX69HR, TX86, VX, DT85, TJ67

Alpha:

550, 550LC, 550LV, 550XV, 551, 551VX

AcerNote:

350 367 3680 370 380 382 850C LifeNote 373 Light 350 Light 360 Light 370 Light 371 Light 372 Light 373 Light 374 Light 380
177626-001222113-001261867-00191.48R28.003adp65dbADP-65DBAP.06503.006180676-0012
5.10064.0491.41Q28.00291.42S28.0025901720130754AP.T2101.001198713-00125.10110.17191.4
1Q28.00325.10064.041ADT-W61AP.06503.003AP.06501.005