

**LENOVO 10.5x4.0mm USB | 20V | 4.74A | 90W | automobilinis nešiojamo kompiuterio kroviklis**

Generuota 2026-06-04



Pavadinimas	Aprašymas
Įvesties įtampa	12V DC
Kištuko diametras	10.5x4.0 mm (USB)
Įtampa	20V
Galia	90W
Srovė	4.74A
KODAS	(AUT-5)

**Pavadinimas**

**Aprašymas**

**MODELIAI**

OA36258, OA36259, OA36260, OA36261, OA36262, OA36263, OA36264, OA36265, OA36266, OA36267, OA36268, OA36269, OA36270, OA36271, OA36272, OA36273, OB46994, OB47008, 112012-11, 36200235, 36200236, 36200237, 36200252, 36200254, 36200298, 45N0235, 45N0236, 45N0237, 45N0238, 45N0239, 45N0240, 45N0245, 45N0246, 45N0249, 45N0250, 45N0253, 45N0254, 45N0256, 45N0258, 45N0260, 45N0262, 45N0264, 45N0305, 45N0306, 45N0309, 45N0310, 45N0326, 45N0328, 59340248, ADLX65NCC3A, ADLX65NDC3A, ADLX65NLC3A, ADLX90NCC3A, ADLX90NCT3A, ADLX90NDC3A, ADLX90NLC3A, ADLX90NLT3, ADLX90NLT3A, PA-1900-72, IdeaPad, Yoga 11, 11S, 13, ThinkPad E531 Edge, E431, S3, S5, T431s, X1, Carbon, X230s, Lenovo, OB46995, OB46996, OB46997, OB46998, OB46999, OB47000, OB47001, OB47002, OB47003, OB47004, OB47005, OB47006, OB47007, OB47009, 23535UF, 3443, Series 3443-CTO, 3443CTO, 3444, 3444-25U, 3444-28U, 3444-2DU, 3444-2GU, 3444-2HU, 3444-2KU, 3444-4ZU, 3444-52U, 3444-53U, 3444-54U, 3444-55U, 3444-56U, 3444-59U, 3444-5AU, 3444-AWU, 3444-AZU, 3444-B7U, 3444-B8U, 3444-B9U, 3444-BBU, 3444-BCU, 3444-BDU, 3444-BEU, 3444-BFU, 3444-F7U, 3444-F8U, 3444-F9U, 3444-FAU, 3444-FBU, 3444-FCU, 3444-FDU, 3444-FEU, 3444-FFU, 3444-FGU, 344425U, 344428U, 34442DU, 34442GU, 34442HF, 34442HU, 344456U, 3444AZF, 3444AZU, 3444B7U, 3444B8U, 3444BAU, 3444BDU, 3444CUF, 3444CUU, 3444CWU, 3444F9U, 3444FEU, 3446, 3448, 3448-22U, 3448-23U, 3448-24U, 3448-25U, 3448-2MU, 3448-34U, 3448-35U, 3448-39U, 3448-3AU, 3448-58U, 3448-59U, 3448-5AU, 3448-5BU, 3448-5CU, 3448-5DU, 3448-94U, 3448-95U, 3448-AVU, 3448-AWU, 3448-AXU, 3448-AYU, 3460, 3460-22U, 3460-23U, 3460-24U, 3460-25U, 3460-34U, 3460-35U, 3460-36U, 3460-37U, 3460-58U, 3460-59U, 3460-5AU, 3460-5BU, 3460-5CU, 3460-5DU, 3460-AVU, 3460-AWU, 3460-AXU, 3460-AYU, 3460-AZU, 3460-B2U, 3460/i5/i7, 34607ZG, 3462, 3463, N3N25UK, N3N2SGE, N3N2SUK, N3N4LGE, N3N4MGE, N3N72GE, N3N72UK, N3N7YMD, N3N7ZGE, N3N7ZUK, N3N82GE, N3N82UK, N3NANGE, Touch 3444CYU, Win 8 i5-3317U, i5-3427U, i7-3667U, i7-3667UM, win Thinkpad Square, interfaces with pin Fit Models: (3444), (3460), 3460-23U3460-22U PA-1900-72IF, 45N0242, 45N0248, 45N0252, 36200252 45M0246, 62775AU/i5-3230M IdeaPad B490; IdeaPad B490s; IdeaPad Flex14; IdeaPad Flex15; IdeaPad G400; IdeaPad G405; IdeaPad G405s; IdeaPad G500; IdeaPad G500s; IdeaPad G505; IdeaPad G505s; IdeaPad G510; IdeaPad G700; IdeaPad S210 Touch; IdeaPad S510p; IdeaPad U330 Touch; IdeaPad U330p; IdeaPad U430p; IdeaPad U530; IdeaPad Yoga 11; IdeaPad Yoga 11S; IdeaPad Yoga 13; IdeaPad Z510; IdeaPad Z710; ThinkPad E531; ThinkPad Edge E431; ThinkPad S3; ThinkPad S5; ThinkPad T431s; ThinkPad T440; Thinkpad T440p; Thinkpad T440S; ThinkPad T540P; ThinkPad X1 Carbon; ThinkPad X230s; U430. 36200235; 36200236; 36200237; 36200252; 36200254; 36200298; 45N0235; 45N0236; 45N0237; 45N0238; 45N0239; 45N0240; 45N0245; 45N0246; 45N0249; 45N0250; 45N0305; 45N0306; 45N0309; 45N0310; ADLX90NCC3A; ADLX90NDC3A; ADLX90NLC3A; PA-1900-72; OB46994; OB46995; OB46996; OB46997; OB46998; OB46999; OB47000; OB47001; OB47002; OB47003; OB47004; OB47005; OB47006; OB47007; OB47008; OB47009. OA36258; OA36259; OA36260; OA36261; OA36262; OA36263; OA36264; OA36265; OA36266; OA36267; OA36268; OA36269; OA36270; OA36271; OA36272; OA36273; OB46994; OB46995; OB46996; OB46997; OB46998; OB46999; OB47000; OB47001; OB47002; OB47003; OB47004; OB47005; OB47006; OB47007; OB47008; OB47009; 112012-11; 36200235; 36200236; 36200237; 36200252; 36200254; 36200298; 36200604; 36200608; 36200612; 45M0246; 45N0235; 45N0236; 45N0237; 45N0238; 45N0239; 45N0240; 45N0242; 45N0245; 45N0246; 45N0248; 45N0249; 45N0250; 45N0252; 45N0253; 45N0254; 45N0256; 45N0258; 45N0260; 45N0262; 45N0264; 45N0305; 45N0306; 45N0309; 45N0310; 45N0326; 45N0328; 59340248; ADLX65NCC3A; ADLX65NDC3A; ADLX65NLC3A; ADLX90NCC3A; ADLX90NCT3A; ADLX90NDC3A; ADLX90NLC3A; ADLX90NLT3; ADLX90NLT3A; FRU45N0238; FRU45N0244; FRU45N0250; FRU45N0498; FRU45N0499;

FRU45N0500; PA-1900-72; PA-1900-72IF. 330-14ARR Lenovo; Yoga 730-151KB ideapad; Yoga 730-151WL Lenovo; V130-141KB V130-151KB V330-141SK Lenovo; V330-151SK Flex 3 -1435 V110-15AST G40-70 G500 B51-80 U330p Yoga 500-151SK ideapad; B71-80; Z50-75; B40-30 Touch All-in-One; B70-80; Flex 15D; Yoga 500-14ACL ideapad; G700 B50-30 Touch All-in-One; B40-30; G400; B50-35 All-in-One; S41-70; U31-70; Z40-70; G50-45; V510-151KB; E40-70; 305-141BD; S41-75; Flex 2-14; G40-45; V310-141SK; B50-30; 300-151SK; Yoga 500-141SK; Flex 3-1480; S410p Touch; 500-15ACZ; G50-80; Yoga 2 Pro; Z470; B50-70; Z41-70; Z500 Touch; B51-35; Flex 15; Z370; M5400; Z70-80; U430p; G510; 300-141SK; Z380; G70-35; Yoga 500-141HW; 300-171SK; B41-80; E51-80; 310S-14AST; V310-151KB; Yoga 500-141BD; G51-35; G505; Yoga 500-151BD; G410; Z40-75; U41-70; V310-141KB; G50-70 300-151BR; G41-35; B40-45; 305-15ABM; K4450; E41-80; S41-35; U430 Touch; 300S-141SK; E50-80; U330; Yoga 2 13; Z480; B5400; Z510; Z710; 500-14ACZ; G710; Flex 2 Pro-15; Flex 14D; G500s; S500 Touch; B41-35; Z585; V510-141KB; G70-80; Z50-70; V110-151AP; 500-141SK; V110-151KB; V110-14AST; V110-141AP; Z400; E40-80; 305-151BD; E40-30; E4430; Flex 14; Yoga 500-151HW; V310-151SK; Z400 Touch; 500S-141SK; 500-151SK; S510p Touch; 305-151HW; Z500 ideapad; G40-30; E50-70; 300-141BR; G50-30; M41-80; B40-70; 500S-131SK; S510p; Z580; V110-151SK; Z410; G70-70; B4400; Flex 3-1580; Flex 2-15; V720-14; V330-151KB; 330-151KB 81FE; B40-30 80F1; B40-70 80F3; B40-80 80F6, 80L; B50-30 80E; G Serie G50-80; G Serie G505; G Serie G510; G Serie G700; G Serie G710; G500; G505S; S210; S215; U330; U330P 80B0; U430; U430P; U530; Yoga 13; Z410; Z500; Z510; M5400 80B5; M93p SFF 10A3, 10A9, 10A2, 10A8; 11e 20E8, 20G9, 20GB, 20HT, 20HV; 11e Chromebook 20GD, 20GF, 20J0; 13 20GJ, 20GK, 20J1, 20J2; A275 20KC, 20KD; A475 20KL, 20KM; E450 20DD; E460 20ET, 20EU; E465 20E; E470 20H1, 20H2; E475 20H4; E560 20EV, 20EW; E565 20EY; E570 20H5, 20H6; E575 20H8; Edge E431 Non-Touch (6277); Edge E431 Touch (6886); Edge E440 (20C5); Edge E531 (6885); Edge E540; Edge E540 (20C6); Edge E550; L440 (20AS, 20AT); L460 (20FU, 20FV); L460 20FU, 20FV; L470 20J4, 20J5, 20JU, 20JV; L540; L540 (20AU, 20AV); L560 (20F1, 20F2); L560 20F1, 20F2; L570 20J8, 20J9, 20JR; P40 Yoga 20GQ, 20GR; P5020FK, 20F; P5120HB, 20HC, 20JY, 20KO; S431 (20AX); S440 (20AY, 20BB); S531 (20BO, 6887); S540 (20B3); T25 20K7; T431s; T440; T440 (20B6, 20B7); T440 20B7; T440(20AQ, 20AR); T44020AQ, 20AR; T440p (20AN, 20AW); T440s; T450 (20BU, 20BV); T450(20BW, 20BX); T45020BW; T450s; T460 (20FM, 20FN); T460 20FM, 20FN; T460(20F9, 20FA); T46020F9, 20FA; T460p (20FW, 20FX); T460p 20FW, 20F; T470 20JM, 20JN; T47020HF, 20HG, 20JS, 20J; T470p 20J6, 20J7; T540p; T540p (20BE, 20BF); T540p 20BE; T550 (20CK, 20CJ); T560 (20FH, 20FJ); T560 20FH, 20FJ; T570 20H9, 20HA, 20JW, 20J; Tablet 11e (1sgen, 20D9, 20DA); Tablet 11e (1sgen, 20DB, 20DU) Chromebook; Tablet 11e (2nd gen, 20E6, 20E8) Intel; Tablet 11e (2nd gen, 20ED, 20EE) AMD; Tablet 11e (3rd gen, 20GB, 20G9) Clamshell; Tablet 11e (3rd gen, 20GD, 20GF) Clamshell Chromebook; Tablet Helix; W55020E1; X1; X1 (1286); X1 (1291); X1 (1293); X1 (1294); X1 Carbon; X1 Carbon (34xx); X1 Carbon (3rd gen., 20BS, 20BT); X1 Carbon (4th gen., 20FB, 20FC); X1 Carbon 20BT, 20FB, 20FC; X1 Hybrid (1286); X1 Hybrid (1291); X1 Hybrid (1294); X1 Yoga 20FQ, 20FR; X240; X240(20AJ, 20AK); X250 20CL, 20CM; X260 (20F5, 20F6); X260 20F5, 20F6; X270 20HM, 20HN, 20K5, 20K6; Yoga 11e (1sgen, 20D9, 20DA); Yoga 11e (1sgen, 20DB, 20DU) Chromebook; Yoga 11e (2nd gen, 20E5, 20E7); Yoga 11e (3rd gen, 20GA, 20G8); Yoga 11e (3rd gen, 20GC, 20GE) Chromebook; Yoga 11e 20E5, 20E7, 20GA, 20HS, 20HU; Yoga 11e Chromebook 20GC, 20GE; Yoga 14 20FY; Yoga 260 20FD, 20FE, 20GS, 20G; Yoga 370 20JH, 20JJ; Yoga 460 20EL, 20EM; V330-141KB 81B0; V330-151KB 81A; V330-151SK 81AW; V720 80Y1.

OA36258  
OA36259  
OA36260  
OA36261  
OA36262

0A36263  
0A36264  
0A36265  
0A36266  
0A36267  
0A36268  
0A36269  
0A36270  
0A36271  
0A36272  
0A36273  
0B46994  
0B46995  
0B46996  
0B46997  
0B46998  
0B46999  
0B47000  
0B47001  
0B47002  
0B47003  
0B47004  
0B47005  
0B47006  
0B47007  
0B47008  
0B47009  
112012-11  
36200235  
36200236  
36200237  
36200252  
36200254  
36200298  
36200604  
36200608  
36200612  
45M0246  
45N0235  
45N0236  
45N0237  
45N0238  
45N0239  
45N0240  
45N0242  
45N0245  
45N0246  
45N0248  
45N0249  
45N0250  
45N0252

45N0253  
45N0254  
45N0256  
45N0258  
45N0260  
45N0262  
45N0264  
45N0305  
45N0306  
45N0309  
45N0310  
45N0326  
45N0328  
59340248  
ADLX65NCC3A  
ADLX65NDC3A  
ADLX65NLC3A  
ADLX90NCC3A  
ADLX90NCT3A  
ADLX90NDC3A  
ADLX90NLC3A  
ADLX90NLT3  
ADLX90NLT3A  
FRU45N0238  
FRU45N0244  
FRU45N0250  
FRU45N0498  
FRU45N0499  
FRU45N0500  
PA-1900-72  
PA-1900-72IF  
ADLX65NCC3A

Tinkami Lenovo kompiuteriai: (informacija gali būti nepilna)

330-14ARR Lenovo  
Yoga 730-15IKB ideapad  
Yoga 730-15IWL Lenovo  
V130-14IKB Lenovo  
V130-15IKB Lenovo  
V330-14ISK Lenovo  
V330-15ISK Lenovo  
Flex 3 -1435 Lenovo  
V110-15AST Lenovo  
G40-70 Lenovo  
G500 Lenovo  
B51-80 Lenovo  
U330p ideapad  
Yoga 500-15ISK ideapad  
B71-80 Lenovo

Z50-75 Lenovo  
B40-30 Touch All-in-One Lenovo  
B70-80 Lenovo  
Flex 15D ideapad  
Yoga 500-14ACL ideapad  
G700 Lenovo  
B50-30 Touch All-in-One Lenovo  
B40-30 Lenovo  
G400 Lenovo  
B50-35 All-in-One Lenovo  
S41-70 Lenovo  
U31-70 Lenovo  
Z40-70 Lenovo  
G50-45 Lenovo  
V510-15IKB Lenovo  
E40-70 Lenovo  
305-14IBD ideapad  
S41-75 Lenovo  
Flex 2-14 Lenovo  
G40-45 Lenovo  
V310-14ISK Lenovo  
B50-30 Lenovo  
300-15ISK ideapad  
Yoga 500-14ISK ideapad  
Flex 3-1480 Lenovo  
S410p Touch ideapad  
500-15ACZ ideapad  
G50-80 Lenovo  
Yoga 2 Pro Lenovo  
Z470 ideapad  
B50-70 Lenovo  
Z41-70 Lenovo  
Z500 Touch ideapad  
B51-35 Lenovo  
Flex 15 ideapad  
Z370 ideapad  
M5400 Lenovo  
Z70-80 Lenovo  
U430p ideapad  
G510 Lenovo  
300-14ISK ideapad  
Z380 ideapad  
G70-35 Lenovo  
Yoga 500-14IHW ideapad  
300-17ISK ideapad  
B41-80 Lenovo  
E51-80 Lenovo  
310S-14AST ideapad  
V310-15IKB Lenovo  
Yoga 500-14IBD ideapad  
G51-35 Lenovo

G505 Lenovo  
Yoga 500-15IBD ideapad  
G410 Lenovo  
Z40-75 Lenovo  
U41-70 Lenovo  
V310-14IKB Lenovo  
G50-70 Lenovo  
Z51-70 Lenovo  
300-15IBR ideapad  
G41-35 Lenovo  
B40-45 Lenovo  
305-15ABM ideapad  
K4450 Lenovo  
E41-80 Lenovo  
S41-35 Lenovo  
U430 Touch ideapad  
300S-14ISK ideapad  
E50-80 Lenovo  
U330 Touch ideapad  
Yoga 2 13 Lenovo  
Z480 ideapad  
B5400 Lenovo  
Z510 ideapad  
Z710 ideapad  
500-14ACZ ideapad  
G710 Lenovo  
Flex 2 Pro-15 Lenovo  
Flex 14D ideapad  
G500s Lenovo  
S500 Touch ideapad  
B41-35 Lenovo  
Z585 ideapad  
V510-14IKB Lenovo  
G70-80 Lenovo  
Z50-70 Lenovo  
V110-15IAP Lenovo  
500-14ISK ideapad  
V110-15IKB Lenovo  
V110-14AST Lenovo  
V110-14IAP Lenovo  
Z400 ideapad  
E40-80 Lenovo  
305-15IBD ideapad  
E40-30 Lenovo  
E4430 Lenovo  
Flex 14 ideapad  
Yoga 500-15IHW ideapad  
V310-15ISK Lenovo  
Z400 Touch ideapad  
500S-14ISK ideapad  
500-15ISK ideapad

S510p Touch ideapad  
305-15IHW ideapad  
Z500 ideapad  
G40-30 Lenovo  
E50-70 Lenovo  
300-14IBR ideapad  
G50-30 Lenovo  
M41-80 Lenovo  
B40-70 Lenovo  
500S-13ISK ideapad  
S510p ideapad  
Z580 ideapad  
V110-15ISK Lenovo  
Z410 ideapad  
G70-70 Lenovo  
B4400 Lenovo  
Flex 3-1580 Lenovo  
Flex 2-15 Lenovo  
V720-14 Lenovo  
V330-15IKB Lenovo  
330-15IKB 81FE  
B40-30 80F1  
B40-70 80F3  
B40-80 80F6, 80L  
B50-30 80E  
G Serie G50-80  
G Serie G505  
G Serie G510  
G Serie G700  
G Serie G710  
IdeaPad G500  
IdeaPad G505S  
IdeaPad S210  
IdeaPad S215  
IdeaPad U330  
IdeaPad U330P 80B0  
IdeaPad U430  
IdeaPad U430P  
IdeaPad U530  
IdeaPad Yoga 13  
IdeaPad Z410  
IdeaPad Z500  
IdeaPad Z510  
M5400 80B5  
ThinkCentre M93p SFF 10A3, 10A9, 10A2, 10A8  
ThinkPad 11e 20E8, 20G9, 20GB, 20HT, 20HV  
ThinkPad 11e Chromebook 20GD, 20GF, 20J0  
Thinkpad 13 20GJ, 20GK, 20J1, 20J2  
ThinkPad A275 20KC, 20KD  
ThinkPad A475 20KL, 20KM  
ThinkPad E450 20DD

ThinkPad E460 20ET, 20EU  
ThinkPad E465 20E  
ThinkPad E470 20H1, 20H2  
ThinkPad E475 20H4  
ThinkPad E560 20EV, 20EW  
ThinkPad E565 20EY  
ThinkPad E570 20H5, 20H6  
ThinkPad E575 20H8  
ThinkPad Edge E431 Non-Touch (6277)  
ThinkPad Edge E431 Touch (6886)  
ThinkPad Edge E440 (20C5)  
ThinkPad Edge E531 (6885)  
ThinkPad Edge E540  
ThinkPad Edge E540 (20C6)  
ThinkPad Edge E550  
ThinkPad L440 (20AS, 20AT)  
ThinkPad L460 (20FU, 20FV)  
ThinkPad L460 20FU, 20FV  
ThinkPad L470 20J4, 20J5, 20JU, 20JV  
ThinkPad L540  
ThinkPad L540 (20AU, 20AV)  
ThinkPad L560 (20F1, 20F2)  
ThinkPad L560 20F1, 20F2  
ThinkPad L570 20J8, 20J9, 20JR  
ThinkPad P40 Yoga 20GQ, 20GR  
ThinkPad P5020FK, 20F  
ThinkPad P5120HB, 20HC, 20JY, 20KO  
ThinkPad S431 (20AX)  
ThinkPad S440 (20AY, 20BB)  
ThinkPad S531 (20B0, 6887)  
ThinkPad S540 (20B3)  
ThinkPad T25 20K7  
ThinkPad T431s  
ThinkPad T440  
ThinkPad T440 (20B6, 20B7)  
ThinkPad T440 20B7  
ThinkPad T440(20AQ, 20AR)  
ThinkPad T44020AQ, 20AR  
ThinkPad T440p (20AN, 20AW)  
ThinkPad T440s  
ThinkPad T450 (20BU, 20BV)  
ThinkPad T450(20BW, 20BX)  
ThinkPad T45020BW  
ThinkPad T450s  
ThinkPad T460 (20FM, 20FN)  
ThinkPad T460 20FM, 20FN  
ThinkPad T460(20F9, 20FA)  
ThinkPad T46020F9, 20FA  
ThinkPad T460p (20FW, 20FX)  
ThinkPad T460p 20FW, 20F  
ThinkPad T470 20JM, 20JN

ThinkPad T47020HF, 20HG, 20JS, 20J  
ThinkPad T470p 20J6, 20J7  
ThinkPad T540p  
ThinkPad T540p (20BE, 20BF)  
ThinkPad T540p 20BE  
ThinkPad T550 (20CK, 20CJ)  
ThinkPad T560 (20FH, 20FJ)  
ThinkPad T560 20FH, 20FJ  
ThinkPad T570 20H9, 20HA, 20JW, 20J  
ThinkPad Tablet 11e (1sgen, 20D9, 20DA)  
ThinkPad Tablet 11e (1sgen, 20DB, 20DU) Chromebook  
ThinkPad Tablet 11e (2nd gen, 20E6, 20E8) Intel  
ThinkPad Tablet 11e (2nd gen, 20ED, 20EE) AMD  
ThinkPad Tablet 11e (3rd gen, 20GB, 20G9) Clamshell  
ThinkPad Tablet 11e (3rd gen, 20GD, 20GF) ClamshellChromebook  
ThinkPad Tablet Helix  
ThinkPad W55020E1  
ThinkPad X1  
ThinkPad X1 (1286)  
ThinkPad X1 (1291)  
ThinkPad X1 (1293)  
ThinkPad X1 (1294)  
ThinkPad X1 Carbon  
ThinkPad X1 Carbon (34xx)  
ThinkPad X1 Carbon (3rd gen., 20BS, 20BT)  
ThinkPad X1 Carbon (4th gen., 20FB, 20FC)  
ThinkPad X1 Carbon 20BT, 20FB, 20FC  
ThinkPad X1 Hybrid (1286)  
ThinkPad X1 Hybrid (1291)  
ThinkPad X1 Hybrid (1294)  
ThinkPad X1 Yoga 20FQ, 20FR  
ThinkPad X240  
ThinkPad X240(20AJ, 20AK)  
ThinkPad X250 20CL, 20CM  
ThinkPad X260 (20F5, 20F6)  
ThinkPad X260 20F5, 20F6  
ThinkPad X270 20HM, 20HN, 20K5, 20K6  
Thinkpad Yoga 11e (1sgen, 20D9, 20DA)  
Thinkpad Yoga 11e (1sgen, 20DB, 20DU) Chromebook  
Thinkpad Yoga 11e (2nd gen, 20E5, 20E7)  
Thinkpad Yoga 11e (3rd gen, 20GA, 20G8)  
Thinkpad Yoga 11e (3rd gen, 20GC, 20GE) Chromebook  
ThinkPad Yoga 11e 20E5, 20E7, 20GA, 20HS, 20HU  
ThinkPad Yoga 11e Chromebook 20GC, 20GE  
ThinkPad Yoga 14 20FY  
ThinkPad Yoga 260 20FD, 20FE, 20GS, 20G  
ThinkPad Yoga 370 20JH, 20JJ  
ThinkPad Yoga 460 20EL, 20EM  
V330-14IKB 81BO  
V330-15IKB 81A  
V330-15ISK 81AW



ĮVAIRIOS ELEKTRONIKOS  
PREKYBA / REMONTAS

SUSISIEKITE | +370 639 77277

GREITAS PREKIŲ PRISTATYMAS

1-2 d.d.

V720 80Y1

**UAB "REGO TECH"**

Įm.kodas: 302449356

PVM kodas: LT100005005917

A/S: LT927300010118749098

**WWW.MARSIIETIS.LT**

El.paštas: info@marsietis.lt

Kontaktinis tel.: +370 (639) 77 277

Vilniaus g. 230 Šiauliai, LT-76303, Lietuva