

LENOVO 10.5x4.0mm USB | 20V | 4.74A | 90W | automobilinis nešiojamo kompiuterio kroviklis

Generuota 2026-04-12



Pavadinimas	Aprašymas
Įtampa	20V
Galia	90W
Srovė	4.74A
Įvesties įtampa	12V DC
Kištuko diametras	10.5x4.0 mm (USB)
KODAS	(AUT-5)

Pavadinimas

Aprašymas

MODELIAI

OA36258, OA36259, OA36260, OA36261, OA36262, OA36263, OA36264, OA36265, OA36266, OA36267, OA36268, OA36269, OA36270, OA36271, OA36272, OA36273, OB46994, OB47008, 112012-11, 36200235, 36200236, 36200237, 36200252, 36200254, 36200298, 45N0235, 45N0236, 45N0237, 45N0238, 45N0239, 45N0240, 45N0245, 45N0246, 45N0249, 45N0250, 45N0253, 45N0254, 45N0256, 45N0258, 45N0260, 45N0262, 45N0264, 45N0305, 45N0306, 45N0309, 45N0310, 45N0326, 45N0328, 59340248, ADLX65NCC3A, ADLX65NDC3A, ADLX65NLC3A, ADLX90NCC3A, ADLX90NCT3A, ADLX90NDC3A, ADLX90NLC3A, ADLX90NLT3, ADLX90NLT3A, PA-1900-72, IdeaPad, Yoga 11, 11S, 13, ThinkPad E531 Edge, E431, S3, S5, T431s, X1, Carbon, X230s, Lenovo, OB46995, OB46996, OB46997, OB46998, OB46999, OB47000, OB47001, OB47002, OB47003, OB47004, OB47005, OB47006, OB47007, OB47009, 23535UF, 3443, Series 3443-CTO, 3443CTO, 3444, 3444-25U, 3444-28U, 3444-2DU, 3444-2GU, 3444-2HU, 3444-2KU, 3444-4ZU, 3444-52U, 3444-53U, 3444-54U, 3444-55U, 3444-56U, 3444-59U, 3444-5AU, 3444-AWU, 3444-AZU, 3444-B7U, 3444-B8U, 3444-B9U, 3444-BBU, 3444-BCU, 3444-BDU, 3444-BEU, 3444-BFU, 3444-F7U, 3444-F8U, 3444-F9U, 3444-FAU, 3444-FBU, 3444-FCU, 3444-FDU, 3444-FEU, 3444-FFU, 3444-FGU, 344425U, 344428U, 34442DU, 34442GU, 34442HF, 34442HU, 344456U, 3444AZF, 3444AZU, 3444B7U, 3444B8U, 3444BAU, 3444BDU, 3444CUF, 3444CUU, 3444CWU, 3444F9U, 3444FEU, 3446, 3448, 3448-22U, 3448-23U, 3448-24U, 3448-25U, 3448-2MU, 3448-34U, 3448-35U, 3448-39U, 3448-3AU, 3448-58U, 3448-59U, 3448-5AU, 3448-5BU, 3448-5CU, 3448-5DU, 3448-94U, 3448-95U, 3448-AVU, 3448-AWU, 3448-AXU, 3448-AYU, 3460, 3460-22U, 3460-23U, 3460-24U, 3460-25U, 3460-34U, 3460-35U, 3460-36U, 3460-37U, 3460-58U, 3460-59U, 3460-5AU, 3460-5BU, 3460-5CU, 3460-5DU, 3460-AVU, 3460-AWU, 3460-AXU, 3460-AYU, 3460-AZU, 3460-B2U, 3460/i5/i7, 34607ZG, 3462, 3463, N3N25UK, N3N2SGE, N3N2SUK, N3N4LGE, N3N4MGE, N3N72GE, N3N72UK, N3N7YMD, N3N7ZGE, N3N7ZUK, N3N82GE, N3N82UK, N3NANGE, Touch 3444CYU, Win 8 i5-3317U, i5-3427U, i7-3667U, i7-3667UM, win Thinkpad Square, interfaces with pin Fit Models: (3444), (3460), 3460-23U3460-22U PA-1900-72IF, 45N0242, 45N0248, 45N0252, 36200252 45M0246, 62775AU/i5-3230M IdeaPad B490; IdeaPad B490s; IdeaPad Flex14; IdeaPad Flex15; IdeaPad G400; IdeaPad G405; IdeaPad G405s; IdeaPad G500; IdeaPad G500s; IdeaPad G505; IdeaPad G505s; IdeaPad G510; IdeaPad G700; IdeaPad S210 Touch; IdeaPad S510p; IdeaPad U330 Touch; IdeaPad U330p; IdeaPad U430p; IdeaPad U530; IdeaPad Yoga 11; IdeaPad Yoga 11S; IdeaPad Yoga 13; IdeaPad Z510; IdeaPad Z710; ThinkPad E531; ThinkPad Edge E431; ThinkPad S3; ThinkPad S5; ThinkPad T431s; ThinkPad T440; Thinkpad T440p; Thinkpad T440S; ThinkPad T540P; ThinkPad X1 Carbon; ThinkPad X230s; U430. 36200235; 36200236; 36200237; 36200252; 36200254; 36200298; 45N0235; 45N0236; 45N0237; 45N0238; 45N0239; 45N0240; 45N0245; 45N0246; 45N0249; 45N0250; 45N0305; 45N0306; 45N0309; 45N0310; ADLX90NCC3A; ADLX90NDC3A; ADLX90NLC3A; PA-1900-72; OB46994; OB46995; OB46996; OB46997; OB46998; OB46999; OB47000; OB47001; OB47002; OB47003; OB47004; OB47005; OB47006; OB47007; OB47008; OB47009. OA36258; OA36259; OA36260; OA36261; OA36262; OA36263; OA36264; OA36265; OA36266; OA36267; OA36268; OA36269; OA36270; OA36271; OA36272; OA36273; OB46994; OB46995; OB46996; OB46997; OB46998; OB46999; OB47000; OB47001; OB47002; OB47003; OB47004; OB47005; OB47006; OB47007; OB47008; OB47009; 112012-11; 36200235; 36200236; 36200237; 36200252; 36200254; 36200298; 36200604; 36200608; 36200612; 45M0246; 45N0235; 45N0236; 45N0237; 45N0238; 45N0239; 45N0240; 45N0242; 45N0245; 45N0246; 45N0248; 45N0249; 45N0250; 45N0252; 45N0253; 45N0254; 45N0256; 45N0258; 45N0260; 45N0262; 45N0264; 45N0305; 45N0306; 45N0309; 45N0310; 45N0326; 45N0328; 59340248; ADLX65NCC3A; ADLX65NDC3A; ADLX65NLC3A; ADLX90NCC3A; ADLX90NCT3A; ADLX90NDC3A; ADLX90NLC3A; ADLX90NLT3; ADLX90NLT3A; FRU45N0238; FRU45N0244; FRU45N0250; FRU45N0498; FRU45N0499;

FRU45N0500; PA-1900-72; PA-1900-72IF. 330-14ARR Lenovo; Yoga 730-151KB ideapad; Yoga 730-151WL Lenovo; V130-141KB V130-151KB V330-141SK Lenovo; V330-151SK Flex 3 -1435 V110-15AST G40-70 G500 B51-80 U330p Yoga 500-151SK ideapad; B71-80; Z50-75; B40-30 Touch All-in-One; B70-80; Flex 15D; Yoga 500-14ACL ideapad; G700 B50-30 Touch All-in-One; B40-30; G400; B50-35 All-in-One; S41-70; U31-70; Z40-70; G50-45; V510-151KB; E40-70; 305-141BD; S41-75; Flex 2-14; G40-45; V310-141SK; B50-30; 300-151SK; Yoga 500-141SK; Flex 3-1480; S410p Touch; 500-15ACZ; G50-80; Yoga 2 Pro; Z470; B50-70; Z41-70; Z500 Touch; B51-35; Flex 15; Z370; M5400; Z70-80; U430p; G510; 300-141SK; Z380; G70-35; Yoga 500-141HW; 300-171SK; B41-80; E51-80; 310S-14AST; V310-151KB; Yoga 500-141BD; G51-35; G505; Yoga 500-151BD; G410; Z40-75; U41-70; V310-141KB; G50-70 300-151BR; G41-35; B40-45; 305-15ABM; K4450; E41-80; S41-35; U430 Touch; 300S-141SK; E50-80; U330; Yoga 2 13; Z480; B5400; Z510; Z710; 500-14ACZ; G710; Flex 2 Pro-15; Flex 14D; G500s; S500 Touch; B41-35; Z585; V510-141KB; G70-80; Z50-70; V110-151AP; 500-141SK; V110-151KB; V110-14AST; V110-141AP; Z400; E40-80; 305-151BD; E40-30; E4430; Flex 14; Yoga 500-151HW; V310-151SK; Z400 Touch; 500S-141SK; 500-151SK; S510p Touch; 305-151HW; Z500 ideapad; G40-30; E50-70; 300-141BR; G50-30; M41-80; B40-70; 500S-131SK; S510p; Z580; V110-151SK; Z410; G70-70; B4400; Flex 3-1580; Flex 2-15; V720-14; V330-151KB; 330-151KB 81FE; B40-30 80F1; B40-70 80F3; B40-80 80F6, 80L; B50-30 80E; G Serie G50-80; G Serie G505; G Serie G510; G Serie G700; G Serie G710; G500; G505S; S210; S215; U330; U330P 80B0; U430; U430P; U530; Yoga 13; Z410; Z500; Z510; M5400 80B5; M93p SFF 10A3, 10A9, 10A2, 10A8; 11e 20E8, 20G9, 20GB, 20HT, 20HV; 11e Chromebook 20GD, 20GF, 20J0; 13 20GJ, 20GK, 20J1, 20J2; A275 20KC, 20KD; A475 20KL, 20KM; E450 20DD; E460 20ET, 20EU; E465 20E; E470 20H1, 20H2; E475 20H4; E560 20EV, 20EW; E565 20EY; E570 20H5, 20H6; E575 20H8; Edge E431 Non-Touch (6277); Edge E431 Touch (6886); Edge E440 (20C5); Edge E531 (6885); Edge E540; Edge E540 (20C6); Edge E550; L440 (20AS, 20AT); L460 (20FU, 20FV); L460 20FU, 20FV; L470 20J4, 20J5, 20JU, 20JV; L540; L540 (20AU, 20AV); L560 (20F1, 20F2); L560 20F1, 20F2; L570 20J8, 20J9, 20JR; P40 Yoga 20GQ, 20GR; P5020FK, 20F; P5120HB, 20HC, 20JY, 20KO; S431 (20AX); S440 (20AY, 20BB); S531 (20B0, 6887); S540 (20B3); T25 20K7; T431s; T440; T440 (20B6, 20B7); T440 20B7; T440(20AQ, 20AR); T44020AQ, 20AR; T440p (20AN, 20AW); T440s; T450 (20BU, 20BV); T450(20BW, 20BX); T45020BW; T450s; T460 (20FM, 20FN); T460 20FM, 20FN; T460(20F9, 20FA); T46020F9, 20FA; T460p (20FW, 20FX); T460p 20FW, 20F; T470 20JM, 20JN; T47020HF, 20HG, 20JS, 20J; T470p 20J6, 20J7; T540p; T540p (20BE, 20BF); T540p 20BE; T550 (20CK, 20CJ); T560 (20FH, 20FJ); T560 20FH, 20FJ; T570 20H9, 20HA, 20JW, 20J; Tablet 11e (1sgen, 20D9, 20DA); Tablet 11e (1sgen, 20DB, 20DU) Chromebook; Tablet 11e (2nd gen, 20E6, 20E8) Intel; Tablet 11e (2nd gen, 20ED, 20EE) AMD; Tablet 11e (3rd gen, 20GB, 20G9) Clamshell; Tablet 11e (3rd gen, 20GD, 20GF) Clamshell Chromebook; Tablet Helix; W55020E1; X1; X1 (1286); X1 (1291); X1 (1293); X1 (1294); X1 Carbon; X1 Carbon (34xx); X1 Carbon (3rd gen., 20BS, 20BT); X1 Carbon (4th gen., 20FB, 20FC); X1 Carbon 20BT, 20FB, 20FC; X1 Hybrid (1286); X1 Hybrid (1291); X1 Hybrid (1294); X1 Yoga 20FQ, 20FR; X240; X240(20AJ, 20AK); X250 20CL, 20CM; X260 (20F5, 20F6); X260 20F5, 20F6; X270 20HM, 20HN, 20K5, 20K6; Yoga 11e (1sgen, 20D9, 20DA); Yoga 11e (1sgen, 20DB, 20DU) Chromebook; Yoga 11e (2nd gen, 20E5, 20E7); Yoga 11e (3rd gen, 20GA, 20G8); Yoga 11e (3rd gen, 20GC, 20GE) Chromebook; Yoga 11e 20E5, 20E7, 20GA, 20HS, 20HU; Yoga 11e Chromebook 20GC, 20GE; Yoga 14 20FY; Yoga 260 20FD, 20FE, 20GS, 20G; Yoga 370 20JH, 20JJ; Yoga 460 20EL, 20EM; V330-141KB 81B0; V330-151KB 81A; V330-151SK 81AW; V720 80Y1.

OA36258
OA36259
OA36260
OA36261
OA36262

0A36263
0A36264
0A36265
0A36266
0A36267
0A36268
0A36269
0A36270
0A36271
0A36272
0A36273
0B46994
0B46995
0B46996
0B46997
0B46998
0B46999
0B47000
0B47001
0B47002
0B47003
0B47004
0B47005
0B47006
0B47007
0B47008
0B47009
112012-11
36200235
36200236
36200237
36200252
36200254
36200298
36200604
36200608
36200612
45M0246
45N0235
45N0236
45N0237
45N0238
45N0239
45N0240
45N0242
45N0245
45N0246
45N0248
45N0249
45N0250
45N0252

45N0253
45N0254
45N0256
45N0258
45N0260
45N0262
45N0264
45N0305
45N0306
45N0309
45N0310
45N0326
45N0328
59340248
ADLX65NCC3A
ADLX65NDC3A
ADLX65NLC3A
ADLX90NCC3A
ADLX90NCT3A
ADLX90NDC3A
ADLX90NLC3A
ADLX90NLT3
ADLX90NLT3A
FRU45N0238
FRU45N0244
FRU45N0250
FRU45N0498
FRU45N0499
FRU45N0500
PA-1900-72
PA-1900-72IF
ADLX65NCC3A

Tinkami Lenovo kompiuteriai: (informacija gali būti nepilna)

330-14ARR Lenovo
Yoga 730-15IKB ideapad
Yoga 730-15IWL Lenovo
V130-14IKB Lenovo
V130-15IKB Lenovo
V330-14ISK Lenovo
V330-15ISK Lenovo
Flex 3 -1435 Lenovo
V110-15AST Lenovo
G40-70 Lenovo
G500 Lenovo
B51-80 Lenovo
U330p ideapad
Yoga 500-15ISK ideapad
B71-80 Lenovo

Z50-75 Lenovo
B40-30 Touch All-in-One Lenovo
B70-80 Lenovo
Flex 15D ideapad
Yoga 500-14ACL ideapad
G700 Lenovo
B50-30 Touch All-in-One Lenovo
B40-30 Lenovo
G400 Lenovo
B50-35 All-in-One Lenovo
S41-70 Lenovo
U31-70 Lenovo
Z40-70 Lenovo
G50-45 Lenovo
V510-15IKB Lenovo
E40-70 Lenovo
305-14IBD ideapad
S41-75 Lenovo
Flex 2-14 Lenovo
G40-45 Lenovo
V310-14ISK Lenovo
B50-30 Lenovo
300-15ISK ideapad
Yoga 500-14ISK ideapad
Flex 3-1480 Lenovo
S410p Touch ideapad
500-15ACZ ideapad
G50-80 Lenovo
Yoga 2 Pro Lenovo
Z470 ideapad
B50-70 Lenovo
Z41-70 Lenovo
Z500 Touch ideapad
B51-35 Lenovo
Flex 15 ideapad
Z370 ideapad
M5400 Lenovo
Z70-80 Lenovo
U430p ideapad
G510 Lenovo
300-14ISK ideapad
Z380 ideapad
G70-35 Lenovo
Yoga 500-14IHW ideapad
300-17ISK ideapad
B41-80 Lenovo
E51-80 Lenovo
310S-14AST ideapad
V310-15IKB Lenovo
Yoga 500-14IBD ideapad
G51-35 Lenovo

G505 Lenovo
Yoga 500-15IBD ideapad
G410 Lenovo
Z40-75 Lenovo
U41-70 Lenovo
V310-14IKB Lenovo
G50-70 Lenovo
Z51-70 Lenovo
300-15IBR ideapad
G41-35 Lenovo
B40-45 Lenovo
305-15ABM ideapad
K4450 Lenovo
E41-80 Lenovo
S41-35 Lenovo
U430 Touch ideapad
300S-14ISK ideapad
E50-80 Lenovo
U330 Touch ideapad
Yoga 2 13 Lenovo
Z480 ideapad
B5400 Lenovo
Z510 ideapad
Z710 ideapad
500-14ACZ ideapad
G710 Lenovo
Flex 2 Pro-15 Lenovo
Flex 14D ideapad
G500s Lenovo
S500 Touch ideapad
B41-35 Lenovo
Z585 ideapad
V510-14IKB Lenovo
G70-80 Lenovo
Z50-70 Lenovo
V110-15IAP Lenovo
500-14ISK ideapad
V110-15IKB Lenovo
V110-14AST Lenovo
V110-14IAP Lenovo
Z400 ideapad
E40-80 Lenovo
305-15IBD ideapad
E40-30 Lenovo
E4430 Lenovo
Flex 14 ideapad
Yoga 500-15IHW ideapad
V310-15ISK Lenovo
Z400 Touch ideapad
500S-14ISK ideapad
500-15ISK ideapad

S510p Touch ideapad
305-15IHW ideapad
Z500 ideapad
G40-30 Lenovo
E50-70 Lenovo
300-14IBR ideapad
G50-30 Lenovo
M41-80 Lenovo
B40-70 Lenovo
500S-13ISK ideapad
S510p ideapad
Z580 ideapad
V110-15ISK Lenovo
Z410 ideapad
G70-70 Lenovo
B4400 Lenovo
Flex 3-1580 Lenovo
Flex 2-15 Lenovo
V720-14 Lenovo
V330-15IKB Lenovo
330-15IKB 81FE
B40-30 80F1
B40-70 80F3
B40-80 80F6, 80L
B50-30 80E
G Serie G50-80
G Serie G505
G Serie G510
G Serie G700
G Serie G710
IdeaPad G500
IdeaPad G505S
IdeaPad S210
IdeaPad S215
IdeaPad U330
IdeaPad U330P 80B0
IdeaPad U430
IdeaPad U430P
IdeaPad U530
IdeaPad Yoga 13
IdeaPad Z410
IdeaPad Z500
IdeaPad Z510
M5400 80B5
ThinkCentre M93p SFF 10A3, 10A9, 10A2, 10A8
ThinkPad 11e 20E8, 20G9, 20GB, 20HT, 20HV
ThinkPad 11e Chromebook 20GD, 20GF, 20J0
Thinkpad 13 20GJ, 20GK, 20J1, 20J2
ThinkPad A275 20KC, 20KD
ThinkPad A475 20KL, 20KM
ThinkPad E450 20DD

ThinkPad E460 20ET, 20EU
ThinkPad E465 20E
ThinkPad E470 20H1, 20H2
ThinkPad E475 20H4
ThinkPad E560 20EV, 20EW
ThinkPad E565 20EY
ThinkPad E570 20H5, 20H6
ThinkPad E575 20H8
ThinkPad Edge E431 Non-Touch (6277)
ThinkPad Edge E431 Touch (6886)
ThinkPad Edge E440 (20C5)
ThinkPad Edge E531 (6885)
ThinkPad Edge E540
ThinkPad Edge E540 (20C6)
ThinkPad Edge E550
ThinkPad L440 (20AS, 20AT)
ThinkPad L460 (20FU, 20FV)
ThinkPad L460 20FU, 20FV
ThinkPad L470 20J4, 20J5, 20JU, 20JV
ThinkPad L540
ThinkPad L540 (20AU, 20AV)
ThinkPad L560 (20F1, 20F2)
ThinkPad L560 20F1, 20F2
ThinkPad L570 20J8, 20J9, 20JR
ThinkPad P40 Yoga 20GQ, 20GR
ThinkPad P5020FK, 20F
ThinkPad P5120HB, 20HC, 20JY, 20KO
ThinkPad S431 (20AX)
ThinkPad S440 (20AY, 20BB)
ThinkPad S531 (20B0, 6887)
ThinkPad S540 (20B3)
ThinkPad T25 20K7
ThinkPad T431s
ThinkPad T440
ThinkPad T440 (20B6, 20B7)
ThinkPad T440 20B7
ThinkPad T440(20AQ, 20AR)
ThinkPad T44020AQ, 20AR
ThinkPad T440p (20AN, 20AW)
ThinkPad T440s
ThinkPad T450 (20BU, 20BV)
ThinkPad T450(20BW, 20BX)
ThinkPad T45020BW
ThinkPad T450s
ThinkPad T460 (20FM, 20FN)
ThinkPad T460 20FM, 20FN
ThinkPad T460(20F9, 20FA)
ThinkPad T46020F9, 20FA
ThinkPad T460p (20FW, 20FX)
ThinkPad T460p 20FW, 20F
ThinkPad T470 20JM, 20JN

ThinkPad T47020HF, 20HG, 20JS, 20J
ThinkPad T470p 20J6, 20J7
ThinkPad T540p
ThinkPad T540p (20BE, 20BF)
ThinkPad T540p 20BE
ThinkPad T550 (20CK, 20CJ)
ThinkPad T560 (20FH, 20FJ)
ThinkPad T560 20FH, 20FJ
ThinkPad T570 20H9, 20HA, 20JW, 20J
ThinkPad Tablet 11e (1sgen, 20D9, 20DA)
ThinkPad Tablet 11e (1sgen, 20DB, 20DU) Chromebook
ThinkPad Tablet 11e (2nd gen, 20E6, 20E8) Intel
ThinkPad Tablet 11e (2nd gen, 20ED, 20EE) AMD
ThinkPad Tablet 11e (3rd gen, 20GB, 20G9) Clamshell
ThinkPad Tablet 11e (3rd gen, 20GD, 20GF) ClamshelChromebook
ThinkPad Tablet Helix
ThinkPad W55020E1
ThinkPad X1
ThinkPad X1 (1286)
ThinkPad X1 (1291)
ThinkPad X1 (1293)
ThinkPad X1 (1294)
ThinkPad X1 Carbon
ThinkPad X1 Carbon (34xx)
ThinkPad X1 Carbon (3rd gen., 20BS, 20BT)
ThinkPad X1 Carbon (4th gen., 20FB, 20FC)
ThinkPad X1 Carbon 20BT, 20FB, 20FC
ThinkPad X1 Hybrid (1286)
ThinkPad X1 Hybrid (1291)
ThinkPad X1 Hybrid (1294)
ThinkPad X1 Yoga 20FQ, 20FR
ThinkPad X240
ThinkPad X240(20AJ, 20AK)
ThinkPad X250 20CL, 20CM
ThinkPad X260 (20F5, 20F6)
ThinkPad X260 20F5, 20F6
ThinkPad X270 20HM, 20HN, 20K5, 20K6
Thinkpad Yoga 11e (1sgen, 20D9, 20DA)
Thinkpad Yoga 11e (1sgen, 20DB, 20DU) Chromebook
Thinkpad Yoga 11e (2nd gen, 20E5, 20E7)
Thinkpad Yoga 11e (3rd gen, 20GA, 20G8)
Thinkpad Yoga 11e (3rd gen, 20GC, 20GE) Chromebook
ThinkPad Yoga 11e 20E5, 20E7, 20GA, 20HS, 20HU
ThinkPad Yoga 11e Chromebook 20GC, 20GE
ThinkPad Yoga 14 20FY
ThinkPad Yoga 260 20FD, 20FE, 20GS, 20G
ThinkPad Yoga 370 20JH, 20JJ
ThinkPad Yoga 460 20EL, 20EM
V330-14IKB 81BO
V330-15IKB 81A
V330-15ISK 81AW



ĮVAIRIOS ELEKTRONIKOS
PREKYBA / REMONTAS

SUSISIEKITE | +370 639 77277

GREITAS PREKIŲ PRISTATYMAS

1-2 d.d.

V720 80Y1

UAB "REGO TECH"

Įm.kodas: 302449356

PVM kodas: LT100005005917

A/S: LT927300010118749098

WWW.MARSIIETIS.LT

El.paštas: info@marsietis.lt

Kontaktinis tel.: +370 (639) 77 277

Vilniaus g. 230 Šiauliai, LT-76303, Lietuva