

Lenovo Original.



LENOVO 90W / 20V / 4.5A / Square tip with pin Original Nešiojamo kompiuterio įkroviklis

Generuota 2025-07-19

Pavadinimas

MODELIS

Aprašymas

OB46994 ,OB46995 ,OB46996 ,OB46997 ,OB46998 ,OB46999 ,OB47000 ,OB47001 ,OB47002 ,OB47003 ,OB47004 ,OB47005 ,OB47006 ,OB47007 ,OB47008 ,OB47009 ,36200235 ,36200236 ,36200237 ,36200250 ,36200252 ,36200254 ,36200298 ,45N0235 ,45N0236 ,45N0237 ,45N0238 ,45N0239 ,45N0240 ,45N0242 ,45N0244 ,45N0245 ,45N0246 ,45N0249 ,45N0250 ,45N0305 ,45N0306 ,45N0309 ,45N0310 ,ADLX90NCC3A ,ADLX90NDC2A ,ADLX90NDC3A ,ADLX90NLC2A ,ADLX90NLC3A
Lenovo300-22ISU , 510-22ISH , C20 , C20-30 , C40 , C40-05 , C40-30 , C50 , C50-30 , F0BX , F0CB , G400 , G410 , G500 , G500H , G500S , G510 , G510 4056 , G510 4059 , G510 59-406675 , G510 59-441358 , G510 80A8 , G510S , G700 , G710 , Z51 , Z51-70 , Z51-70 80K6 ,
IdeaCentre series520-22AST , 520-22ICB , 520-22IKL , 520-22IKU , 520-24ARR , 520-24AST ,
IdeaPad series700-15ISK , 720S , 720S-15IKB , G500 , G500S TOUCH , G510 , Y40 , Y40-70 , Y40-80 , Y50 , Y50 TOUCH , Y50-80 , Y50-80 TOUCH , Z510 , Z510 59400193 , Z510 59400198 , Z510 TOUCH , Z710 ,
Thinkpad seriesE470 , E560P , E570 , HELIX , L440 , L440 20AS , L540 , S440 , S5 , S531 , S540 , T440 , T440P , T440S , T440S 20AR , T450P , T450S , T540P , X1 CARBON , X240 , X240 TOUCH , YOGA ,
ThinkPad Edge seriesE431 , E440 , E531 , E540