

**ASUS Original.**



**ASUS 65W / 19V / 3.42A / 5.5x2.5mm Original Nešiojamo kompiuterio įkroviklis**

Generuota 2026-05-23

Pavadinimas

Aprašymas

**MODELIAI**

adp-65hb bb  
a12-065n2a  
adp-65wh ab  
1903420D  
04G2660  
EXA1208EH  
04G266003164  
04G2660031N0  
0A001-00042800  
04G2660031N1  
04G2660031T0  
04G2660031T2  
04G2660047D0  
04G2660047L2  
04G266010700  
0A001-00041500  
0A001-00043600  
180676-001  
25.L180G.001  
54Y8848  
603284-001  
700393-001  
722970-001  
90-XB03NOPW00050Y  
ADP-60DB  
BOXNUC7I3BNK  
EXA0703YH  
EXA1203YH  
F1781A  
FRU54Y8848  
FSP065-10AABA  
FSP065-REB  
FUJ:CP500585-XX  
NUC

**Pavadinimas**

**Aprašymas**

**KODAS**

**Acer serija Aspire**

04G2660047D0,0712A1965,3123-K911,36001678,57Y6400,6708BA0012B,6709BZ9010A,90-XB  
OMNOPW00030T,A5B00075639795,ADP-65DB,ADP-65DW C,ADP-65GD  
B,ADP-65GDB,ADP-65JH AB,ADP-65JH BB,ADP-65JHAB,ADP-65JHBB,ADP-65YB,Asus ADP-65DW  
B,Asus ADP-65GD B,AsusADP-65DWB,AsusADP-65GDB,C39280-Z4-C571,EXA1208EH,PA-1600-0  
1,PA-1650-02,PA-1650-22,pa-1650-48,PA-1650-52LC,PA-1650-66,PA-1650-78,PA-1750-78,PA339  
6U-1ACA,PA3714E-1AC3,pa3714u-1aca,PA5178U-1ACA,S26391-F321-L100,SADP-65KB,  
1200,1300,1410,1450,1640,1650,1680,1690,2000,2010,2020,2930,3000,3030,3500,3610,3620,  
3630,3640,3650,3660,3670,3935,4220,4410,4520,4530,4535,4540,4715,4720,4730,4735,481  
0,4930,4935,5000,5030,5050,5100,5110,5320,5330,5500,5515,5530,5532,5535,5550,  
seria Extensa  
2350,4010,4130,4220,4230,4420,4430,4620,4630,5010,5120,5210,5230,5235,5420,5610,5620  
,5635,6600,7230,serija Ferrari  
1000,1100,1200,serija TravelMate  
660,720,7230,730,7320,7330,740,7520,800,8000,8100,8331,8371,8431,8471,8531,8571,Advent  
1515 NORDIC,2008,3086 NORDIC,4470,5365,5372,5470,5471,5480,5490,5493,6000,6410,6412  
,6413,6413A,6414,6414B,6415,6416,6417,6418,6419,6421,6422,6520,6521,6522,6551,6552,6553,  
6555,6651,7002,7006,7007,7008,7009,7011,7012,7013,7014,7015,7016,7017,7018,7019,7026,7  
027,7035,7038,7040,7041,7045,7048,7049,7053,7056,7060,7061M,7068,7070,7072,7073,70  
78,7079,7080,7081,7086,7087,7088,7089,7090,7094,7095,7096,7100,7105,7111,7200,7201,72  
04,7206,7211,7250,7255,7300,7340,7360,7365,8001,8109,8115,8117,8212,8275,8315,8480,9912,  
MILANO ELITE,QC430,QRC430,Aristo serija Slim  
200,330,serija Smart  
300S,340,350,420,440,Asus  
32V,A2L,A3AC,A3E,A3F,A3FC,A3FP,A3G,A3H,A3HF,A3N/L,A3V,A3VC,A3VP,A4000D,A4000G,A4  
000K,A411D,A411E,A411N,A4700D,A4700K,A52D,A52F,A52F-EX1240U,A52JB,A52JK,A52JT,A52N,  
A53E,A53SC,A53SD,A53SJ,A53SK,A53SM,A53SV,A53TA,A53TK,A53U,A53Z,A550,A5E,A5EB,A5E  
C,A6000,A6000G,A6000K,A6000NE,A6000U,A600KM,A6700G,A6700NE,A6F,A6G,A6JC,A6J  
M,A6K,A6KT,A6L,A6M,A6NE,A6R,A6RP,A6T,A6TC,A6U,A6VC,A84BR,A84SD,A84SJ,A84SM,A8E,A  
8F,A8FM,A8H,A8HE,A8JA,A8JC,A8JE,A8JM,A8JN,A8JR,A8JV,A8LE,A8M,A9RP,A9T,B1,B1000,B1400  
A,B1500,B1500A,B43E,B43F,B43S,B53E,B53F,B53J,B53S,B80A,F2F,F2HF,F2J,F2JA,F302LJ,F302LJ-  
R4051H,F302LJ-R4052H,F3F,F3H,F3JC,F3JE,F3L,F3Q,F450JF,F450L,F450LA,F450LB,F50GX,F50Q  
,F50Z,F550,F550C,F550CA,F550L,F555,F555L,F555LB,F555LB-X0144T,F555LB-X0236T,F555LJ,  
F555LJ-X0943T,F555LJ-X0945T,F555LJ-X0947T,F555LJ-X0948T,F555LJ-X0949T,F555LJ-X1265T,  
F555Q,F555QA,F555QA-DM343T,F555UJ-X0044T,F5G,F5L,F5M,F5N,F5R,F5RI,F6A,F6E,F80CR,F  
80L,F80Q,F83T,F83VD,F9F,F9J,G1,K40C,K40IJ,K40IL,K40IN,K50C,K52F,K52N,K550CA,K550CC,K  
550DP,K550L,K555,K555L,K555LD,K55A,K55DR,K55N,K55V,K55VD,K55VM,K56,K56C,K56CA,K  
56CB,K56CM,K611C,K61L,K61LC,K62F,K70IJ,K72F,K72JR,K84C,K84H,K84HR,K84HY,K84L,K84LY,L1  
,L1A,L1B,L2,L2B,L2D,L2E,L31,L32,L3200,L34,L3400,L35,L3500,L3500D,L3500T,L3800,L3800C,L3  
C,L3CE,L3D,L3H,L3S,L3TP,L4,L4E,L4H,L4L,L4R,L84,L84B,L84C,L84CE,L84F,L84K,L84L,LAMBORG  
HINI VX1,M1A,M2,M2A,M2C,M2E,M2N,M2NE,M3AE,M3N,M3NP,M5,M5000N,M51A,M51E,M52V,  
M5A,M5AE,M5N,M5NP,M6,M6000N,M6000R,M6700NA,M6700NE,M6800NE,M6A,M6C,M6C  
E,M6FM,M6N,M6NA,M6NE,M6R,M6RF,M6V,M6VA,M7A,M7V,M9A,M9F,M9J,M9V,N10E,N10J,N1  
OJC,N10JG,N10JH,N20A,N20H,N51A,N51TE,P24E,P30A,P31F,P31JG,P31SD,P31SG,P41JF,P41SV,P50  
IJ,P52F,P81IJ,PL30JT,PL80JT,PL80VT,Q301LA,Q301LP,R1E,R1F,R300,R510,R510C,R510CA,R510CC,

Pavadinimas

Aprašymas

**GAMINTOJO KODAS**

MSI

A6200,CR400,CR41,CR410,CR42 2M,CR420,CR420MX,CR460,CR500,CR600,CR61,CR610,CR620,CR630,CR640,CR70,CR700,CR720,CX410,CX413,CX420,CX420MX,CX480 (BATERIA 6 OGNIWOWA),CX500,CX500DX,CX600,CX605,CX61,CX620,CX623,CX650,CX70,CX700,CX705,CX705MX,CX720,EX460,EX465,EX465MX,FR600,FR600 3D,FR720,FX400,FX420 (BATERIA 6 OGNIWOWA),FX600MX,FX610MX,FX720,GP60,P600,PR300,S6000,U250,X350,X360,X370,X400,X420,X430,X460,X600,X600 PRO,X620,Packard Bell serija EasyNote F,LJ 65,LJ61,LJ63,LJ67,LJ71,LJ73,LJ75,LJ77,LK11BZ,LK13BZ,LM81,LM82,LM83,LM85,LM86,LM87,LM