

ASUS Original.



ASUS 45W / 19V / 2.37A / 4.0x1.35mm Original Nešiojamo kompiuterio įkroviklis

Generuota 2025-11-23

Pavadinimas

MODELIAI

Aprašymas

0A001-00233800
0A001-00235000
0A001-00235800
0A001-00236400
0A001-00237800
0A001-00237800
0A001-00238700
0A001-00693600
0A001-00695500
0A001-01101200
AD210802000
AD883020010H-1LF
AD883020010H-3LF
AD883020010HLF 4PHI
ADP-45BW CE
ADP-45BW Z2B A03
W15-045N2B CL:X
W16-045N3B
AD2066020010LF
ADP-45BW Z2B
W16-045N3B CL:A
w19-045n3b
w19 045n3b
0A001-00697800
adp-458w
010h-3lf
0A001-01100700
ADP-45ZE B
type 010lf

Pavadinimas
Aprašymas
KODAS

OA001-00043100,OA001-00044600,OA001-00045900,OA001-00049200,OA001-00049700,
 OA001-00230000,OA001-00230300,OA001-00230800,OA001-00233800,OA001-00234800,
 OA001-00235000,OA001-00235800,OA001-00236300,OA001-00236400,OA001-00237800,O
 A001-00237900,OA001-00441200,OA001-00441700,OA001-00442900,OA001-01100400,OA
 200-00021000,OA200-00021900,90-XB34NOPW00000Y,90-XB34NOPW00010Y,90-XB3JOOP
 W00080,90-XB3NNOPW00010Y,ad2066020,ADP-40TH,ADP-40TH
 A,ADP-40THA,ADP-45AW,ADP-45AW AA,ADP-45AWAA,ADP-45BW,adp-45bw
 c,adp-45bwc,ADP-65AW
 A,ADP-65AWA,DA001-01100400,N45W-01,OA001-01100400,W16-045N3B,W16-045N3B
 CL,W16-045N3BCL,w19-045n3b
 AsusA512DA, D553M, F201E, F509F, F509FA, F509FA-EJ207T, F540S, F543U, F543UA, F543UA-
 DM1876T, F543UA-DM1882T, F553M, M409BA, M409DA, M409DJ, M409DL, M509DA, R540,
 R540S, R541UJ-DM448, S532F, S532FAC, S532FAC-BN094T, X200, X200CA, X200M, X201,
 X201E, X302LJ, X302UA, X302UJ, X302UV, X407MA, X407UA, X407UB, X407UF, X409FA,
 X409UA, X441BA, X441MB, X441SC, X441UA, X441UB, X441UV, X456UA, X507LA, X507UA,
 X509FA, X540BA, X540LA, X540LJ, X540MB, X540NV, X540SA, X540SC, X540UB, X540YA,
 X541SC, X541UA, X543B, X543BA, X543BP, X543MB, X543U, X543UA, X543UB, X545FA, X553M,
 X556UA,
 serija TaiChi21, 31,
 serija Vivobook15 F510U, 15 F512UA, 15 F512UA-EJ233T, 15 F512UA-EJ268T, 15 X542UA, A541U,
 F200, F200CA, F201E, K401L, K401LB, Q200, Q200E, Q301, Q301L, Q301LA, R542U, S13, S13
 S330UA, S13 S330UA-EY27T, S14 S410UA, S200, S200E, X201, X201E, X202, X202E, X302LA,
 X405, X405U, X405UA, X540YA,
 serija VivoBook 14X411QA, X412FA, X412UA,
 serija VivoBook 15X505ZA, X509UA, X510UA, X512FA, X512UA, X542UA,
 serija VivoBook 17X712FA,
 serija VivoBook FlipTP301UA, TP501U, TP501UA,
 seria VivoBook Flip 14TP412UA,
 serija VivoBook MaxX441NC, X441UV, X541UA,
 serija VivoBook S13S330FA-EY024T, S330UA,
 seria VivoBook S14S406UA, S410UA, S430F, S430FA, S430FA-EB047T, S430FN, S430UA,
 S430UN, S432FA, X420UA,
 serija VivoBook S15S510UA, S532FA,
 serija ZenbookBX21, BX21A, BX31A, BX32, BX32A, U38DT, U38N, UK31K, UX21, UX21A, UX301,
 UX301LA, UX302L, UX302LA, UX302LG, UX302LG-C4019H, UX302LG-C4019P, UX303LA,
 UX303LB, UX303LN, UX303U, UX303UA, UX303UB, UX305, UX305C, UX305CA, UX305F,
 UX305FA, UX305L, UX305LA, UX305U, UX305UA, UX305UB, UX306, UX306U, UX306UA,
 UX306UA-VB72, UX31, UX310UA, UX310UQ, UX31A, UX31A-1AR4, UX31A-1AR5, UX31A-1AR7,
 UX31A-2D, UX31A-AB71, UX31A-AB72, UX31A-BHI5T11, UX31A-DB51, UX31A-DB52, UX31E, UX31K,
 UX31L, UX31LA, UX32A, UX32L, UX32LA, UX32LN, UX32V, UX32VD, UX330CA, UX330UA,
 UX331FN, UX360, UX360C, UX360CA, UX360UA, UX360UAK, UX410UA, UX42A, UX42V,
 UX42VS, UX430U, UX430UA, UX430UQ, UX50, UX510UW, UX510UX, UX52VS, UX560UA,
 X331UA, X331UN,
 serija ZenBook 13UX331UA, UX331UAL,
 serija Zenbook PrimeUX32V, UX32VD, UX42V, UX42VS, UX52VS
 Asus ZenBook UX31LAAsus K401JAsus X451Asus X451CAAsus X451CAAsus X451MAAsus
 X451MAAsus X451MA-DB01Asus X451MAVAsus Taichi 21Asus R540Asus F201Asus F201EAsus
 VivoBook Q200Asus VivoBook Q200EAsus VivoBook S200Asus VivoBook S200EAsus
 VivoBook X202Asus VivoBook X202EAsus X201Asus X201EAsus ZenBook UX31AAsus ZenBook

UX31A-DH71Asus VivoBook F200Asus VivoBook F200CAAsus X200Asus X200CAAsus
X200CAAsus X200LAsus X200LAAsus X200MAAsus X200MAAsus Zenbook UX32AAsus
Zenbook UX32VDAAsus ZenBook UX21AAsus Vivobook F201EAsus X102BAAsus ZenBook
UX302LGAAsus VivoBook Q301Asus VivoBook Q301LAsus VivoBook Q301LAAsus VivoBook
Q301LPAAsus ZenBook BX31AAsus ZenBook BX32Asus Zenbook BX32AAsus Zenbook
UX21AAsus ZenBook UX31LAsus ZenBook UX32VAsus ZenBook UX32VDAAsus ZenBook
UX42AAsus ADPAsus Q304Asus Q304UAsus Q304UAAsus Q302Asus Q302LAsus
Q302LAAsus Q302UAsus Q302UAAsus K401Asus K401LAsus K401LBAAsus K401UAsus
K401UBAAsus K401UQAsus A441Asus A441SAAsus A441SAAsus A441SCAsus A441UAsus
A441UAAAsus A441UVAAsus F102BAAsus F202Asus F441Asus F441SAAsus F441SAAsus
F441UAsus F441UAAAsus F441UVAAsus K441Asus K441UAsus K441UAAAsus K441UVAAsus
K541Asus Q303Asus Q303UAsus Q303UAAsus TaiChi 31Asus Vivobook X201Asus Vivobook
X201EAsus X441Asus X441SAAsus X441SAAsus X441SCAsus X441UAsus X441UAAAsus ZenBook
BX21Asus Zenbook BX21AAsus ZenBook BX31
UX42VSUX50UX301UX32VUX32VDUX52VSTransformers BookTP300LTP300LA