

**ASUS Original.**



**ASUS 45W / 19V / 2.37A / 3.0x1.1mm Original Nešiojamo kompiuterio įkroviklis**

Generuota 2026-04-18

**Pavadinimas**

**MODELIS**

**Aprašymas**

delta electronics  
ADP-45FE F  
AD-4019A  
BA44-00279A  
BA44-00278A  
BA44-00272A  
BA44-00295A  
BA44-00262A  
BA44-00278A  
BA44-00279A  
AD-4019P  
AD-4019SL  
AD-4019W  
AA-PA2N40L  
AA-PA2N40S  
AA-PA2N40W  
AA-PA3NS40  
AAPA3NS40  
PA-1400-24  
ON2811  
ON2811-C  
W15-045N4B  
KP.04501.004  
KP.04503.001  
KP.0450H.003  
KP04501004  
KP04503001  
KP0450H003  
KP.04501.012  
KP04501012  
pa-1450-26  
adp-45he

Pavadinimas

Aprašymas

**MODELIAI**

Acer

OA001-00230000,OA200-00021000,90-XB34N0PW00000Y,A045R021L,ADP-45AW,ADP-45A W A,ADP-45AWA,n17h2,N45W-01,PA-1450-26,W15-045N4B,XB02OAPW00100Q

ASPIRE SWITCH 12,  
serija Aspire

A315-22,A514-52,R5-471T,R5-571T,R7-371T,R7-371T-55DJ,R7-371T-57SN,R7-371T-583M,R7-371T-58XM, R7-371T-59L6,R7-371T-701C,R7-371T-729P,R7-371T-72TC,R7-371T-7474,R7-372T,S5-371T, S5-371T-537V,S5-371T-57WW,S5-371T-58CC,S5-371T-76CY,V13,V3-371-57W1,V3-372T-58TH,V3-372T-72L6,V3-372T-75U6,V3-372T-75VV,  
serija Aspire 3

A315,A315-22,A315-23-R98U,A315-34,A315-54K-3889,  
serija Aspire 5

A514-52,A514-52-306T,A514-52-54SK,A515-54,A515-54G-51JE,  
serija Aspire One Cloudbook 11 14

AO1-131,AO1-131M,AO1-132,AO1-431,AO1-431M,  
serija Chromebook

11 C730,11 CB3-131-C3SZ,13 C810,C730-C10K,C730-C24Y,C730-C4U4,C730-C4V9, C730-C7PV,CB 3-131-COUG,CB3-131-C1CA,CB3-131-C2E2,CB3-131-C2EW,CB3-131-C2SS,CB3-131-C2V4,CB3-131-C3K D,CB3-131-C3SZ,CB3-131-C5RA,CB5-311,  
serija Chromebook 11

C730E-C07S,CB3-111,CB3-111-C670,CB3-111-C8UB,CB3-131,CB3-131-C3KD, CB3-131-C3SZ,CB3-132,C