

HP BULLET 4.8X1.7MM

HP 4.8x1.7mm Bullet maitinimo laidas su kištuku

Generuota 2024-05-14



Pavadinimas

Aprašymas

KODAS

(DC-18L)

Kištuko diametras

4.8x1.7 mm

Pavadinimas
Aprašymas
MODELIAI

Krovikliams 18.5v 4.9a lub 19v 4.74a (modeliai: PA-1900-05C1, PPP012L, 374474-001, 374791-001, 393954-001, 394224-001, PA-1900-08, PA-1900-08R1, PA-1900-18H1, PPP012L-S, PPP014L-S). Compaq serija Armada
100S,110,110S,E300,E500,E500S,E700,M300,M500,M700,V300, serija Evo
N1000,N1000C,N1000V,N1005V,N1010V,N1015V,
N1020V,N1025V,N110,N150,N200,N400,N400C,N410C,
N600,N600C,N610C,N610V,N620C,N800,N8000,N800C,N800V, serija Presario
1500,1500AP,1500AU,1500SC,1500US,1501,1501AP,
1502,1502SC,1503,1505AP,1505US,1506,1506TC, 1507,1507TC,1508,1508TC,1509,1510,1510AP,
1510AU,1510US,1511,1512,1512AP,1513AP, 1514AP,1515AP,1516,1516EA,1520,1520AP,1520CA,
1520U,1520US,1522,1522E,1523E,1525,1525E,1525U,
1525US,1530S,1531,1531A,1535,1535A,1536A,1538,
1538A,1540A,1545A,1550,1550A,1555,1555A,1565A,
1568,1568A,1570,1572,1575A,1580,1580A,2200,2201AP,
2201US,2800,2800CA,2800US,2801CL,2805US,300,620,
800,900,900US,905,905US,910,910US,912,912RSH,918,
918RSH,920,920US,B3800,C500,F500,M2000,V2000,
V2010,V2030,V2100,V2300,V2400,V2500,V2600,V4000,
V5000,V6000,V6100,V6200,V6300,V6500,X1000, X1015,X1030,X1040,X1200,X1300, serija
Prosignia 160,165,170,190,800, HP serija Business Notebook
530,550,6720,6720S,6720T,6820S,G5000,G6000,
NC4000,NC4010,NC4200,NC6000,NC6100,NC6105,
NC6110,NC6115,NC6120,NC6220,NC6230,NC7200,
NC8000,NC8230,NW8000,NW8240,NX4800,NX5000,
NX5100,NX6100,NX6105,NX6110,NX6115,NX6120,
NX6125,NX6130,NX7000,NX7010,NX7040,NX7100,
NX7200,NX8000,NX8220,NX8420,NX9020,NX9030,NX9040,NX9050, serija Notebook PC
2000-101XX,2000-104CA,2000-120CA,2000-129CA,
2000-130CA,2000-140CA,2000-150CA,2000-151CA,
2000-208CA,2000-210US,2000-211HE,2000-216NR,
2000-217NR,2000-219DX,2000-224CA,2000-227CL,
2000-228CA,2000-239DX,2000-239WM,2000-240CA,
2000-250CA,2000-299WM,2000-300CA,2000-320CA,
2000-329WM,2000-340CA,2000-350US,2000-351NR,
2000-352NR,2000-353NR,2000-354NR,2000-355DX,
2000-356US,2000-358NR,2000-361NR,2000-363NR,
2000-365DX,2000-369NR,2000-369WM,2000-370CA,
2000-373CA,2000-379WM,2000-410US,2000-412NR,
2000-420CA,2000-427CL,2000-450CA,2000T-300, 2000Z-100,2000Z-300,2000Z-400,2133,
serija Pavilion DV1000,DV1000-DZ677AV,DV1000-DZ678AV,
DV1000-DZ731AV,DV1000T,DV1001AP-PK809AS, DV1001XX-PK807AS,DV1002AP-PF352PA,
DV1002XX-PK808AS,DV1003AP-PF353PA, DV1004AP-PF354PA,DV1005AP-PF355PA,
DV1006AP-PF356PA,DV1007AP,DV1007AP-PF367PA, DV1008AP,DV1008AP-
PF368PA,DV1009AP-PH468PA, DV1009XX-PR284AS,DV1010,DV1010AP-PH476PA,
DV1010CA,DV1010CA-PM056UA,DV1010CA-PM056UAR, DV1010US-
PM053UAR,DV1011AP,DV1012AP-PD111PA, DV1012LA-PQ641LA,DV1013AP-PD110PA, DV1013AP-
PD112PA,DV1014AP-PD113PA, DV1014LA-PP888LA,DV1015AP-PD114PA, DV1015LA-
PN713LA,DV1016AP-PD117PA, DV1017AP-PD118PA,DV1018AP-PD119PA, DV1019AP-
PD120PA,DV1010US-PM053UA, DV1020AP-PH482PA,DV1021AP-PH483PA, DV1022AP-

Laido ilgis, m

PASLAUGA

PN562PA,DV1023AP-PN563PA, DV1024AP-PN575PA,DV1024LA-PP889LA,DV1025AP-PN576PA,
DV1025LA-PN712LA,DV1026AP-PN907PA, DV1027AP-PN578PA,DV1029AP-PN888PA,
DV1029AP-PN908PA,DV1030,DV1030AP-PN910PA, DV1031AP-PP963PA,DV1032AP-PP971PA,
DV1033AP-PP981PA,DV1034AP-P982PA, DV1035AP-PP989PA,DV1036AP-PS939PA, DV1037AP-
PS940PA,DV1040CA,DV1040CA-PM057UA, DV1040CA-PM057UAR,DV1040US-PM054UA,
DV1040US-PM054UAR,DV1042QV-PM055UA, DV1044LA-PP890LA,DV1049CL-PM058UA,
DV1049CL-PM058UAR,DV1060US-PM059UA, V1060US-PM059UAR,DV1065US-PM061UA,
DV1065US-PM061UAR,DV1067EA-PQ563EA, DV1068EA-PQ564EA,DV1071EA-PQ562EA,DV1100,
DV1101AP-PS925PA,DV1102AP-PS926PA, DV1122AP-PV253PA,DV1128AP-
PV295PA,DV1134AP,DV1135AP,DV1200,
DV1240CA,DV1300,DV1300-DT111AV,DV1301AP,DV1302AP,DV1303AP,DV1309AP,
DV1315CL,DV1317AP,DV1327AP,DV1330CA,DV1331SE,
DV1400,DV1500,DV1600,DV2000,DV2000T,DV2000Z,
DV2001TU,DV2001TX,DV2001XX,DV2002TU,DV2002TX,
DV2002XX,DV2003EA,DV2003TU,DV2003TX,DV2004EA,
DV2004TU,DV2004TX,DV2004XX,DV2005EA,DV2005TU,
DV2005TX,DV2005XX,DV2006EA,DV2006TU, DV2006TX,DV2006XX,DV2007EA,DV2007TU,
DV2007TX,DV2008EA,DV2008TU,DV2008TX, DV2009EA,DV2009TU,DV2009TX,DV2009XX,
DV2010EA,DV2010TU,DV2010TX,DV2011EA,DV2011TU,
DV2011TX,DV2011XX,DV2012EA,DV2012TU,DV2012TX,
DV2013EA,DV2013TU,DV2013TX,DV2014EA,DV2014TU,
DV2014TX,DV2015EA,DV2015NR,DV2015TU,DV2015TX,
DV2016EA,DV2016TU,DV2016TX,DV2017EA,DV2017TU,
DV2017TX,DV2018EA,DV2018TU,DV2018TX,DV2019EA,
DV2019TU,DV2019TX,DV2020CA,DV2020EA,DV2020TU,
DV2020TX,DV2020US,DV2021TU,DV2021TX,DV2022TU,
DV2022US,DV2023TU,DV2024TU,DV2024TX,DV2025LA,
DV2025NR,DV2025TU,DV2025TX,DV2026TU,DV2026TX,
DV2027TU,DV2027TX,DV2028EA,DV2028TU,DV2028TX,
DV2029EA,DV2029TU,DV2029TX,DV2030EA,DV2030TU,
DV2030TX,DV2031EA,DV2031TU,DV2031TX,DV2032EA,
DV2032TU,DV2032TX,DV2033EA,DV2033TU,DV2033TX,
DV2034EA,DV2034TU,DV2034TX,DV2035EA,DV2035LA,
DV2035TU,DV2035TX,DV2035US,DV2036EA,DV2036TU,
DV2036TX,DV2037TU,DV2037TX,DV2037US,DV2038TU,
DV2038TX,DV2039TU,DV2039TX,DV2040CA,DV2040TU,
DV2040TX,DV2040US,DV2041TU,DV2041TX,DV2042TU,
DV2042TX,DV2043TU,DV2043TX,DV2044TU,DV2044TX,
DV2045EA,DV2045TU,DV2046TU,DV2046TX,DV2047CL,
DV2047TU,DV2047TX,DV2048TX,DV2049TX,DV2050TU,
DV2050TX,DV2050US,DV2053EA,DV2054EA,DV2055EA,
DV2056EA,DV2057EA,DV2058EA,DV2064EA,DV2065EA,
DV2080EA,DV2081EA,DV2082EA,DV2083EA,DV2084EA,
DV2085EA,DV2088XX,DV2095EA,DV2097EA,DV2098EA,
DV2099EA,DV2100,DV2101EU,DV2101XX,DV2102XX,
DV2103EA,DV2103TU,DV2103XX,DV2104EA,DV2104EU,
DV2104NR,DV2104TU,DV2104XX,DV2105EA,DV2105XX,
DV2106EA,DV2106EU,DV2108EA,DV2109NR,DV2110EU,
DV2110RS,DV2111RS,DV2112RS,DV2115EA,DV2115WM,
DV2116,DV2116EA,DV2116TX,DV2116WM,DV2119XX,
DV2120,DV2120CA,DV2120LA,DV2120TU,DV2120US,

DV2123EU,DV2123TU,DV2125,DV2125EA,DV2125LA,
DV2125NR,DV2126EA,DV2129EA,DV2129TX,DV2129US,
DV2130,DV2130EA,DV2130TX,DV2130US,DV2131EA,
DV2133EA,DV2134EA,DV2134US,DV2135BR,DV2135LA,
DV2138XX,DV2140BR,DV2140EU,DV2140TX,DV2141EU,
DV2142TX,DV2143TX,DV2145BR,DV2147EA,DV2149EA,
DV2150EA,DV2150TX,DV2151TX,DV2152EA,DV2152TX,
DV2164EU,DV2166EU,DV2171,DV2171CA,DV2171CL,
DV2171EA,DV2172EA,DV2173EA,DV2174,DV2174CL,
DV2174EA,DV2175EA,DV2184EA,DV2185EA,DV2190EA,
DV2195EU,DV2196EA,DV2197EA,DV2200,DV2200EA,
DV2201CA,DV2201XX,DV2202CA,DV2202XX,DV2205EA,
DV2207EA,DV2208EA,DV2209EA,DV2209TU,DV2210TU,
DV2210US,DV2213CA,DV2213CL,DV2214US,DV2215EA,
DV2215TU,DV2216EA,DV2217EA,DV2220US,DV2221US,
DV2222EA,DV2222LA,DV2224EA,DV2225NR,DV2227EA,
DV2240BR,DV2244EA,DV2245BR,DV2245EA,DV2246EA,
DV2247BR,DV2250BR,DV2255BR,DV2260BR,DV2265EA,
DV2267EA,DV2268EA,DV2275EA,DV2276EA,DV2278EA,
DV2281EA,DV2282EA,DV2297EA,DV2298EA,DV2300,
DV2301AU,DV2302AU,DV2303AU,DV2304AU,DV2305AU,
DV2306AU,DV2308TU,DV2310CA,DV2310US,DV2312US,
DV2313CA,DV2313CL,DV2315NR,DV2315US,DV2317CA,
DV2317US,DV2320LA,DV2320US,DV2322LA,DV2325LA,
DV2400,DV2401XX,DV2402CA,DV2402TX,DV2402XX,
DV2404CA,DV2406TX,DV2407TX,DV2408CA,DV2409TX,
DV2410CA,DV2410TX,DV2410US,DV2411TX,DV2412CA,
DV2413CA,DV2413CL,DV2414TX,DV2415NR,DV2415TX,
DV2415US,DV2416US,DV2418CA,DV2418NR,DV2419US,
DV2420LA,DV2420US,DV2422CA,DV2422LA,DV2423LA,
DV2425LA,DV2432CA,DV2432NR,DV2500,DV2500T,
DV2500TV,DV2500TW,DV2500TX,DV2501XX,DV2502XX,
DV2503XX,DV2504XX,DV2505XX,DV2506XX,DV2515TX,
DV2525TX,DV2526TX,DV2527TX,DV2528TX,DV2535LA,
DV2535TX,DV2539TX,DV2550SE,DV2600,DV2601XX,
DV2602CA,DV2602TU,DV2602TX,DV2602XX,DV2604TX,
DV2605TX,DV2606TU,DV2606TX,DV2607TU,DV2608CA,
DV2608TU,DV2609TU,DV2610CA,DV2610TU,DV2610US,
DV2611TU,DV2612CA,DV2612TU,DV2613CL,DV2613TU,
DV2613TX,DV2615NR,DV2615US,DV2617US,DV2618CA,
DV2619NR,DV2620CA,DV2620US,DV2621LA,DV2622CA,
DV2622LA,DV2624LA,DV2625LA,DV2626LA,DV2628TX,
DV2629TX,DV2630TX,DV2631TX,DV2633TX,DV2634TX,
DV2635LA,DV2635TX,DV2636TX,DV2638TX,DV2639TX,
DV2640TX,DV2641TX,DV2642TX,DV2643TX,DV2644TX,
DV2660SE,DV2700,DV2700TV,DV2700TW,DV2701XX,
DV2702TU,DV2702TX,DV2702XX,DV2703TX,DV2703XX,
DV2704TX,DV2704XX,DV2705TU,DV2705TX,DV2706TU,
DV2706TX,DV2707TU,DV2707TX,DV2708CA,DV2708TU,
DV2708TX,DV2709TU,DV2709TX,DV2710CA,DV2710TU,
DV2710TX,DV2712TU,DV2712TX,DV2713CA,DV2713TX,

DV2714CA,DV2714TU,DV2714TX,DV2715CA,DV2715NR,
DV2715TX,DV2716CA,DV2716TX,DV2717TX,DV2718CA,
DV2718TX,DV2718US,DV2719NR,DV2719TX,DV2720TX,
DV2721TX,DV2722TX,DV2724CA,DV2725LA,DV2726CA,
DV2726LA,DV2727CA,DV2728CA,DV2730TX,DV2734TX,
DV2735TX,DV2736TX,DV2736US,DV2737TX,DV2738TX,
DV2739TX,DV2740SE,DV2740TX,DV2741TX,DV2742SE,
DV2745SE,DV2746TX,DV2747TX,DV2748TX,DV2749TX,
DV2750TX,DV2751TX,DV2751XX,DV2752TX,DV2752XX,
DV2755TX,DV2757TX,DV2759TX,DV2763TX,DV2765TX,
DV2766TX,DV2768TX,DV2769TX,DV2770TX,DV2771TX,
DV2774TX,DV2779TX,DV2781TX,DV2800T,DV2800TY,
DV2801AU,DV2801TU,DV2801TX,DV2801XX,DV2802AU,
DV2802TU,DV2802TX,DV2803TU,DV2804CA,DV2804TU,
DV2805,DV2805TU,DV2806TU,DV2807NR,DV2807TU,
DV2808CA,DV2808TU,DV2809TU,DV2809TX,DV2810CA,
DV2810TU,DV2810TX,DV2811TX,DV2812TX,DV2813TX,
DV2814CA,DV2814TX,DV2815NR,DV2816TX,DV2817CA,
DV2818CA,DV2818TX,DV2819NR,DV2820TX,DV2821TX,
DV2823CA,DV2823TX,DV2824TX,DV2825TX,DV2826TX,
DV2828CA,DV2829TX,DV2830TX,DV2831TX,DV2832TX,
DV2833TX,DV2834CA,DV2834TX,DV2835TX,DV2836TX,
DV2837TX,DV2838TX,DV2839TX,DV2840SE,DV2840TX,
DV2841TX,DV2842SE,DV2842TX,DV2845SE,DV2846TX,
DV2847TX,DV2848TX,DV2849TX,DV2850TX,DV2851XX,
DV2854CA,DV2872LA,DV2890CA,DV2890NR,DV2894CA,
DV2901TU,DV2901TX,DV2902TU,DV2902TX,DV2903TU,
DV2904TU,DV2904TX,DV2905TU,DV2906TU,DV2907TU,
DV2909TX,DV2910CA,DV2911TX,DV2911US,DV2914CA,
DV2915CA,DV2915NR,DV2915TX,DV2917CA,DV2917CL,
DV2917TX,DV2919TX,DV2920TX,DV2921TX,DV2925LA, DV2928CA,DV2928SE,DV2940SE,DV294
1SE,DV2945SE,DV2946NR,DV2949SE,DV2988NR, DV2988SE,DV2990NR,DV2998NR,DV2999NR,
DV4-2173NR,DV4000,DV4000-PC253AV,DV4000-PC268AV,
DV4000-PC269AV,DV4000-PH856AV,DV4000-PH857AV,
DV4000-PR496AV,DV4000LA,DV4000XX,DV4000XX-PX249AS, DV4001AP-
PV281PA,DV4001EA-EB916EA,DV4001XX, DV4001XX-PX248AS,DV4002AP-
PV282PA,DV4003AP-PV294PA, DV4004AP-PV298PA,DV4004XX,DV4004XX-PX251AS,DV4005
AP-PV302PA,DV4005US,DV4005US-EA410UA,DV4005XX,DV4006AP-PV303PA,DV4006XX,DV
4006XX-PX250AS,DV4007AP,DV4007AP-PV304PA,DV4007XX,DV4007XX-
PX259AS,DV4008AP-PV316PA, DV4009AP-PV317PA,DV4010AP-PV318PA,DV4011AP-PV319PA,
DV4012AP-PV320PA,DV4013AP-PV321PA,DV4014AP, DV4014AP-PV332PA,DV4014EA-
EA037EA,DV4015AP-PV333PA, DV4015CL,DV4015CL-PX306UA,DV4015EA-
EA034EA,DV4016AP-PY843PA, DV4016EA-EB907EA,DV4017AP,DV4017AP-PY853PA,
DV4017EA-EA032EA,DV4018AP,DV4018AP-PY854PA, DV4018CL,DV4018EA-
EB915EA,DV4019AP-PY881PA, DV4019EA-EA033EA,DV4020AP-PY882PA, DV4020EA-
EA022EA,DV4020US-PX304UA, DV4021AP-PY883PA,DV4021EA,DV4021EA-
EB923EA,DV4022AP, DV4022AP-ED099PA,DV4022EA-EB926EA, DV4023AP-
ED100PA,DV4023EA-EB917EA, DV4024AP,DV4024AP-ED102PA,DV4024EA-EB924EA,
DV4025AP-EE547PA,DV4025EA-EA036EA, DV4026AP-EE548PA,DV4027EA-EA038EA,
DV4030CA,DV4030CA-PX311UA,DV4030EA, DV4030EA-EA021EA,DV4030EA-EB914EA,
DV4030US,DV4030US-PX302UA,DV4031EA-EB910EA, DV4040CA,DV4040CA-

PX308UA,DV4040EA-EB920EA, DV4040US,DV4040US-PX303UA,DV4043EA-EA030EA,,
DV4046EA-EA028EA,DV4049EA-EB921EA, DV4050EA-EA025EA,DV4051EA-EB918EA,
DV4052EA-EB911EA,DV4054EA-EB913EA, DV4056EA-EA039EA,DV4057EA-EA029EA,
DV4060EA-EA023EA,DV4070EA,DV4070EA-EB925EA, DV4073EA-EB908EA,DV4075EA-
EA024EA, DV4078EA-EA026EA,DV4080EA-EB922EA, DV4085EA-EA031EA,DV4086EA-
EA035EA, DV4100,DV4100-EA292AV,DV4100-EA294AV, DV4101AP,DV4101AP-
PY885PA,DV4102AP, DV4102AP-PY896PA,DV4102EA-EH187EA, DV4103AP-
PY905PA,DV4103EA-EF177EA, DV4104AP-PY906PA,DV4105AP-PY907PA, DV4106AP-
ED098PA,DV4107AP-ED144PA, DV4108AP-ED145PA,DV4108EA-EF175EA, DV4109AP-
ED146PA,DV4109EA-EH197EA, DV4110AP,DV4110AP-ED142PA,DV4110EA-EH725EA,
DV4111AP,DV4111AP-ED143PA, DV4112AP-ED147PA,DV4113AP-ED148PA, DV4113EA-
EH726EA,DV4114AP,DV4114AP-ED149PA, DV4115AP,DV4115AP-ED150PA,DV4115EA-EF190EA,
DV4116AP-ED171PA,DV4117AP,DV4117AP-ED172PA, DV4118AP-ED174PA,DV4119AP-EE452PA,
DV4120AP-EE483PA,DV4121AP,DV4121AP-EE501PA, DV4122AP-EE500PA,DV4122EA-EF186EA,
DV4123AP-EE517PA,DV4124AP-EE518PA, DV4125AP,DV4125AP-EE524PA,DV4125EA-EH185EA,
DV4125US,DV4125US-EC325UA,DV4126AP-EE528PA, DV4126EA-EH183EA,DV4127AP-
EE529PA,DV4128AP, DV4128AP-EE553PA,DV4128EA-EH191EA,DV4129AP, DV4129AP-
EH019PA,DV4129EA-EH730EA,DV4129US, DV4130AP,DV4130AP-EH020PA,DV4130EA,
DV4130EA-EF171EA,DV4130US,DV4130US-EC317UA, DV4131EA-EF182EA,DV4134EA-EH180EA,
DV4135EA-EH724EA,DV4136EA-EF183EA,DV4137EA-EH192EA, DV4138EA-EF188EA, DV4139EA-
EK552EA,DV4140EA-EF178EA, DV4141EA-EH731EA,DV4142EA-EH188EA, DV4143EA-
EF179EA,DV4144EA-EK553EA,DV4145EA-EF176EA, DV4146EA-EH182EA,DV4146EA-EH727EA
DV4148EA-EK551EA,DV4149EA-EH181EA, DV4150CA-EC322UA,DV4150EA-EF172EA,
DV4150US,DV4150US-EC316UA,DV4151EA-EF185EA, DV4152EA-EF173EA,DV4152EA-
EH196EA,DV4153EA-EH178EA, DV4154EA-EH179EA,DV4155CL,DV4155CL-EC321UA, DV4155EA-
EH186EA,DV4155US,DV4155US-EC324UA, DV4156EA-EH194EA,DV4157EA-EH732EA,DV4158EA-
EF184EA, DV4159EA-EH729EA,DV4160EA-EH728EA, DV4161EA-EF180EA,DV4162EA-EH189EA,
DV4163EA-EF174EA,DV4164EA-EH184EA,DV4165CL, DV4165CL-EC318UA,DV4165EA-
EF187EA,DV4170CA-EC320UA, DV4170US,DV4170US-EC315UA,DV4174EA-EH733EA, DV4176EA-
EH190EA,DV4178EA-EF189EA, DV4180US-EC327UA,DV4182EA-EH195EA, DV4199EA-
EF181EA,DV4200,DV4201TU,DV4201TX,DV4201XX, DV4202TU,DV4202XX,DV4203EA-
EK915EA,DV4203TX, DV4203XX,DV4205TX,DV4206TX,
DV4207TU,DV4207TX,DV4208TX,DV4209TX,DV4210TX,
DV4211TX,DV4212TX,DV4213TX,DV4214TX,DV4215TX,
DV4217CL,DV4218TX,DV4220TX,DV4221TX,DV4222TX,
DV4223CL,DV4223TX,DV4224EA,DV4225NR,DV4226TX, DV4230US,DV4230US-
EC329UA,DV4231EA,DV4250US,DV4253US,DV4257US,
DV4268EA,DV4269US,DV4270US,DV4272US,DV4275NR,
DV4302EA,DV4304EA,DV4305EA,DV4305US,DV4306EA,
DV4307CA,DV4307CL,DV4308WM,DV4309EA,DV4310US,
DV4312EA,DV4315EA,DV4318EA,DV4320US,DV4321EA,
DV4322EA,DV4324EA,DV4325EA,DV4326EA,DV4327EA,
DV4330CA,DV4330US,DV4334EA,DV4335EA,DV4335NR,
DV4336EA,DV4337EA,DV4339EA,DV4340US,DV4342EA,
DV4344EA,DV4346EA,DV4348EA,DV4350EA,DV4351EA,
DV4353EA,DV4354EA,DV4356EA,DV4357EA,DV4358EA,
DV4360EA,DV4363EA,DV4364EA,DV4365EA,DV4367EA,
DV4368EA,DV4376EA,DV4378EA,DV4379EA,DV4381EA,
DV4383EA,DV4384EA,DV4385EA,DV4386EA,DV4388EA,
DV4391EA,DV4392EA,DV4394EA,DV4395EA,DV4396EA,
DV4398EA,DV4400,DV4401RS,DV4401XX,DV4402TU,

DV4405NR,DV4410US,DV4419US,DV4420CA,DV4420US,
DV4435EA,DV4440EA,DV4445EA,DV4450EA,DV5000,
DV5000EA,DV5000T,DV5000Z,DV5001XX,DV5002EA,
DV5003CL,DV5003EA,DV5005EA,DV5006EA,DV5007EA,
DV5008EA,DV5009EA,DV5010EA,DV5011EA,DV5012EA,
DV5016EA,DV5017CL,DV5017EA,DV5018EA,DV5020CA,
DV5020US,DV5021EA,DV5022EA,DV5023EA,DV5024EA,
DV5026EA,DV5027EA,DV5029US,DV5030US,DV5031EA,
DV5033EA,DV5034EA,DV5035EA,DV5035NR,DV5036EA,
DV5037EA,DV5040US,DV5041EA,DV5046EA,DV5047EA,
DV5050EA,DV5051EA,DV5052EA,DV5053EA,DV5054EA,
DV5055EA,DV5056EA,DV5057EA,DV5058EA,DV5059EA,
DV5061EA,DV5062EA,DV5063EA,DV5074EA,DV5075EA,
DV5077EA,DV5078EA,DV5084EA,DV5088XX,DV5091EA,
DV5092EA,DV5093EA,DV5094EA,DV5095EA,DV5096EA,
DV5097EA,DV5098EA,DV5099EA,DV5099XX,DV5100,
DV5102EU,DV5104EU,DV5106EU,DV5107TX,DV5109TX,
DV5110CA,DV5110TX,DV5110US,DV5111TU,DV5111TX,
DV5113EU,DV5113TX,DV5114EU,DV5115EU,DV5115NR,
DV5116EU,DV5116NR,DV5117CA,DV5117CL,DV5119EU,
DV5119TX,DV5120EA,DV5120EU,DV5120LA,DV5120US,
DV5121EA,DV5121EU,DV5122EA,DV5122TX,DV5123EA,
DV5123TX,DV5124EU,DV5124TX,DV5125EU,DV5125TX,
DV5127EU,DV5127TX,DV5128EU,DV5128TX,DV5129EU,
DV5129US,DV5130CA,DV5130EU,DV5130TX,DV5130US,
DV5131EU,DV5131TX,DV5132EU,DV5132TX,DV5134EA,
DV5134EU,DV5135EU,DV5135NR,DV5136EU,DV5137EA,
DV5139US,DV5140CA,DV5140EA,DV5140EU,DV5140US,
DV5142EA,DV5143EA,DV5144EA,DV5145EA,DV5147EA,
DV5148EA,DV5149EA,DV5149EU,DV5150EA,DV5150US,
DV5155EU,DV5156EU,DV5157EA,DV5157EU,DV5158EU,
DV5159EU,DV5161EU,DV5163CL,DV5164EA,DV5165EA,
DV5166EA,DV5167CL,DV5170US,DV5173EA,DV5173EU,
DV5174EU,DV5176EA,DV5176EU,DV5177EA,DV5178EA,
DV5178US,DV5179EA,DV5186EU,DV5189EU,DV5189XX,
DV5190EA,DV5190US,DV5191EA,DV5192EA,DV5193EA,
DV5194EA,DV5196EA,DV5196XX,DV5197EA,DV5198EA,
DV5198XX,DV5199XX,DV5200,DV5200TU,DV5201TX,
DV5202TX,DV5203TX,DV5204TX,DV5205EA,DV5205TU,
DV5205TX,DV5206TX,DV5207TX,DV5208TX,DV5209TX,
DV6211EA,DV6212EA,DV6213CL,DV6213EA, DV6214EA,DV6215CA,DV6215EA,DV6215TX,
DV6215US,DV6216EA,DV6216TX,DV6217EA, DV6218EA,DV6218TX,DV6219EA,DV6220BR,
DV6220EU,DV6221TX,DV6223EU,DV6225EU, DV6225US,DV6226US,DV6227CL,DV6230BR,
DV6230EA,DV6231EA,DV6231EU,DV6233EA, DV6233SE,DV6235CA,DV6235EU,DV6235NR,
DV6235US,DV6236EA,DV6236US,DV6237EA, DV6238EA,DV6239EA,DV6239EU,DV6240EU,
DV6241EA,DV6241EU,DV6242EA,DV6242EU, DV6243CL,DV6243EA,DV6243EU,DV6244EA,
DV6244EU,DV6244US,DV6245CA,DV6245EA, DV6245EU,DV6245US,DV6247CA,DV6247CL,
DV6247EA,DV6248EU,DV6249EU,DV6250EU, DV6251EU,DV6252EU,DV6253CL,DV6253EU,
DV6254EA,DV6254EU,DV6255CA,DV6255EU, DV6255US,DV6256EU,DV6256US,DV6258SE,
DV6259EU,DV6260EU,DV6262EU,DV6263CL, DV6263EU,DV6265CA,DV6265EA,
DV6265EU,DV6265US,DV6266EU,DV6267CL, DV6267EU,DV6269EU,DV6274EA,DV6275EA,

DV6275US,DV6276EA,DV6276EU,DV6277EA, DV6278EU,DV6280EA,DV6281EA,DV6283EU,
DV6284EU,DV6285EU,DV6286EA,DV6286EU, DV6287EU,DV6288EA,DV6290EA,DV6291EA,
DV6295EU,DV6297EA,DV6298EA,DV6299EA,
DV6299XX,DV6300,DV6303TU,DV6305CA,DV6305US,
DV6306RS,DV6307CA,DV6308CA,DV6308NR,DV6315CA,
DV6324US,DV6325CA,DV6325US,DV6326US,DV6335CA,
DV6335US,DV6337CL,DV6337US,DV6338SE,DV6340EU,
DV6345US,DV6353CA,DV6353CL,DV6353US,DV6355CA,
DV6355US,DV6357EU,DV6358SE,DV6363CA,DV6365US,
DV6375US,DV6399XX,DV6400,DV6400A,DV6401CA,
DV6401TU,DV6401TX,DV6401XX,DV6402CA,DV6402TU,
DV6402XX,DV6403CL,DV6404CA,DV6404TX,DV6405CA,
DV6405US,DV6406CA,DV6406NR,DV6407NR,DV6408CA,
DV6408NR,DV6409CA,DV6409US,DV6409WM,DV6410CA,
DV6415CA,DV6415US,DV6416CA,DV6418CA,DV6420LA, DV6422LA
N,DV6423OM,DV6424CA,DV6425CA,DV6425US,DV6426CA,
DV6426US,DV6427CL,DV6428CA,DV6433CL,DV6435CA,
DV6436NR,DV6439NR,DV6445US,DV6446US,DV6447OM,
DV6448SE,DV6449US,DV6450US,DV6451US,DV6452SE,
DV6458SE,DV6470US,DV6499XX,DV6500,DV6500T,
DV6500Z,DV6501AU,DV6501XX,DV6502XX,DV6503AU,
DV6503TU,DV6504AU,DV6505AU,DV6505TU,DV6513TX,
DV6514TX,DV6518TX,DV6520TX,DV6521TX,DV6523TX,
DV6524TX,DV6531TX,DV6540TX,DV6541TX,DV6542TX,
DV6545TX,DV6547EA,DV6550TX,DV6560US,DV6563CL,
DV6565CA,DV6565US,DV6567CL,DV6568SE,DV6570US,
DV6573CL,DV6575CA,DV6575US,DV6585CA,DV6589US,
DV6597XX,DV6598XX,DV6599XX,DV6600,DV6601AU,
DV6601TU,DV6601TX,DV6602AX,DV6603AX,DV6603CA,
DV6604AU,DV6604CL,DV6604NR,DV6604TU,DV6604TX,
DV6605CA,DV6605US,DV6607CL,DV6607NR,DV6607RS,
DV6608CA,DV6609WM,DV6610TX,DV6611CA,DV6611TX,
DV6612CA,DV6613TX,DV6615TX,DV6616TX,DV6618CA,
DV6618TX,DV6619TX,DV6620LA,DV6620TX,DV6621TX,
DV6622CA,DV6622TX,DV6623CL,DV6623TX,DV6624CA,
DV6624TX,DV6625CA,DV6625TX,DV6625US,DV6626CA,
DV6626TX,DV6626US,DV6627CA,DV6627NR,DV6627OM,
DV6628TX,DV6628US,DV6629CA,DV6629TX,DV6629US,
DV6629WM,DV6631CA,DV6633US,DV6634NR,DV6636NR,
DV6640BR,DV6640US,DV6642CA,DV6643CL,DV6645CA,
DV6645US,DV6646US,DV6647CL,DV6647NR,DV6648SE,
DV6651XX,DV6652XX,DV6653CL,DV6654US,DV6660SE,
DV6661SE,DV6662SE,DV6663CA,DV6663CL,DV6663US,
DV6670CA,DV6672US,DV6675US,DV6693US,DV6696NR,
DV6699XX,DV6700,DV6700T,DV6700Z,DV6701AX,
DV6701CA,DV6701TU,DV6701TX,DV6701US,DV6701VX,
DV6701XX,DV6702AU,DV6702AX,DV6702TU,DV6702TX,
DV6702VX,DV6703AU,DV6703AX,DV6703TU,DV6703VX,
DV6704AU,DV6704AX,DV6704CA,DV6704NR,DV6704TX,
DV6704VX,DV6705AX,DV6705CA,DV6705TU,DV6705TX,
DV6705VX,DV6706AU,DV6706AX,DV6707AX,DV6707TX,

DV6707US,DV6708AX,DV6708TX,DV6709TX,DV6710AX,
DV6710TX,DV6711AX,DV6713CA,DV6714CA,DV6714TX,
DV6715TX,DV6716CA,DV6716TX,DV6717TX,DV6718CA,
DV6718TX,DV6719TX,DV6720LA,DV6720TX,DV6721LA,
DV6721TX,DV6722LA,DV6722TX,DV6724CA,DV6725CA,
DV6725TX,DV6725US,DV6726TX,DV6727CA,DV6727TX,
DV6728CA,DV6728TX,DV6729CA,DV6729TX,DV6729US,
DV6730TX,DV6731TX,DV6732TX,DV6734TX,DV6735TX,
DV6736NR,DV6736TX,DV6737TX,DV6739TX,DV6740TX,
DV6742TX,DV6743TX,DV6744CA,DV6744TX,DV6745TX,
DV6745US,DV6746CA,DV6747CL,DV6747NR,DV6748CA,
DV6748US,DV6749TX,DV6750TX,DV6751TX,DV6751US,
DV6751XX,DV6753CA,DV6753CL,DV6753TX,DV6754TX,
DV6755CA,DV6755US,DV6756US,DV6757CA,DV6758US,
DV6759TX,DV6762TX,DV6763TX,DV6764TX,DV6765TX,
DV6766TX,DV6768TX,DV6769TX,DV6770SE,DV6770TX,
DV6771TX,DV6772NR,DV6772TX,DV6775TX,DV6775US,
DV6776TX,DV6777TX,DV6778TX,DV6779TX,DV6780CA,
DV6780SE,DV6780TX,DV6781TX,DV6782TX,DV6783TX,
90TX,DV6791TX,DV6792TX,DV6793TX,DV6794TX,DV6795TX,
DV6796TX,DV6798TX,DV6800,DV6801AX,DV6801CA,DV6801TU,
DV6801TX,DV6802AX,DV6802TU,DV6802TX,DV6803AX,DV6803TU,
DV6803TX,DV6804AX,DV6804TU,DV6804TX,DV6805CA,DV6805TU,
DV6805TX,DV6806TX,DV6807TX,DV6807US,DV6808TX,DV6809US,
DV6809WM,DV6810TX,DV6810US,DV6811TX,DV6812NR,
DV6814CA,DV6815NR,DV6815TX,DV6816TX,DV6817TX,
DV6818CA,DV6818TX,DV6819TX,DV6820TX,DV6821TX,
DV6822TX,DV6823TX,DV6823US,DV6824CA,DV6824TX,
DV6825CA,DV6825TX,DV6827CA,DV6827TX,DV6828TX,
DV6829TX,DV6830TX,DV6830US,DV6831TX,DV6832TX,
DV6833TX,DV6833US,DV6834CA,DV6834TX,DV6835CA,
DV6835NR,DV6835TX,DV6836TX,DV6837CL,DV6837TX,
DV6838CA,DV6838NR,DV6838TX,DV6839CL,DV6839TX,
DV6840TX,DV6841TX,DV6847TX,DV6848TX,DV6851XX,
DV6853CA,DV6853CL,DV6854CA,DV6858CA,DV6864CA,
DV6870US,DV6871US,DV6872LA,DV6874CA,DV6875CA,
DV6875SE,DV6880SE,DV6883CL,DV6884CA,DV6885CA,
DV6885SE,DV6898CA,DV6899XX,DV6900,DV6901TU,
DV6901TX,DV6902TU,DV6902TX,DV6903TU,DV6903TX,
DV6904CA,DV6907CA,DV6907TX,DV6908TX,DV6909TX,
DV6910CA,DV6911OM,DV6911US,DV6912TX,DV6913CA,
DV6913RS,DV6915CA,DV6915NR,DV6916TX,DV6917CL,
DV6917NR,DV6917TX,DV6918SE,DV6918TX,DV6919CA,
DV6919TX,DV6920TX,DV6921TX,DV6923TX,DV6926NR,
DV6928US,DV6929NR,DV6929WM,DV6930US,DV6933CL,
DV6934CA,DV6935CA,DV6936US,DV6937CL,DV6938SE,
DV6939CA,DV6940SE,DV6948CA,DV6958SE,DV6968CA,
DV6974CA,DV6976CA,DV6985SE,DV6988CA,DV6995LA,
DV6998CA,DV8000,DV8000T,DV8000Z,DV8002EA,DV8005EA,
DV8010EA,DV8013CL,DV8013XX,DV8027EA,DV8028EA,
DV8029EA,DV8035EA,DV8040US,DV8040XX,DV8045EA

DV8051EA,DV8075EA,DV8088US,DV8099XX,DV80XXUS,
DV8100,DV8102EA,DV8110US,DV8113CL,DV8113EA,
DV8114EA,DV8116EA,DV8117EA,DV8120CA,DV8125NR,
DV8130US,DV8135EA,DV8135NR,DV8140US,DV8155EA,
DV8173EA,DV8175EA,DV8176EA,DV8177EA,DV8178EA,
DV8179EA,DV8195EA,DV8197EA,DV8199EA,DV81XXUS,
DV8200,DV8201TX,DV8202TX,DV8203TX,DV8204TX,
DV8205TX,DV8206TX,DV8207TX,DV8208TX,DV8209TX
DV8210CA,DV8210EA,DV8210US,DV8211EA,DV8211EU,
DV8212EA,DV8213CL,DV8213EA,DV8214EA,DV8214TX,
DV8215EA,DV8215TX,DV8219EA,DV8220CA,DV8220EA,
DV8220US,DV8221EA,DV8222EA,DV8223EA,DV8225CA,
DV8225EA,DV8225NR,DV8226EA,DV8227EA,DV8228EA,
DV8229EA,DV8230CA,DV8230EA,DV8230US,DV8231EA,
DV8233CL,DV8233EA,DV8235EA,DV8235NR,DV8240US
,DV8251EA,DV8252EU,DV8253EA,DV8254EA,DV8260EA,
DV8275EA,DV8275LA,DV8279EA,DV8280EA,DV8280US,
DV8286EA,DV8287EA,DV8289EA,DV8289XX,DV8290EA,
DV8291EA,DV8292EA,DV8293EA,DV8294EA,DV8295EA,
DV8298EA,DV8298XX,DV8299XX,DV8300,DV8300TX,DV8301NR,
DV8301TX,DV8302TX,DV8304TX,DV8305CA,DV8305TX,
DV8305US,DV8306EA,DV8306TX,DV8307EA,DV8307TX,
DV8309US,DV8310US,DV8312TX,DV8314TX,DV8315NR,
DV8315TX,DV8318TX,DV8320EA,DV8320US,DV8321TX,
DV8322EA,DV8323EA,DV8325EA,DV8327CA,DV8327CL,
DV8327US,DV8328CA,DV8333CL,DV8339US,DV8375LA,
DV8379EA,DV8380US,DV8382EA,DV8389EA,DV8390EA,
DV8391EA,DV8393EA,DV8395EA,DV8398EA,DV8399XX,
DV8400,DV8408US,DV9000,DV9000EA,DV9000T,DV9000Z,
DV9001EA,DV9001XX,DV9002EA,DV9002NR,DV9002XX,
DV9003EA,DV9003TX,DV9003XX,DV9004EU,DV9004TX,
DV9004XX,DV9005CA,DV9005EA,DV9005TX,DV9005US,
DV9005XX,DV9006EA,DV9006OM,DV9006TX,DV9008EA,
DV9008NR,DV9009CA,DV9009CL,DV9009NR,DV9009TX,
DV9009US,DV9010CA,DV9010TX,DV9010US,DV9011TX,
DV9012TX,DV9013CA,DV9013CL,DV9013TX,DV9014EA,
DV9014TX,DV9015EA,DV9015TX,DV9016EA,DV9016TX,
DV9017EA,DV9017TX,DV9018EA,DV9019EA,DV9019TX,
DV9020TX,DV9021TX,DV9022EA,DV9022TX,DV9023US,
DV9024EA,DV9030EA,DV9030US,DV9035EA,DV9035NR,
DV9036EA,DV9037EA,DV9038EA,DV9039EA,DV9040EA,
DV9040EU,DV9040US,DV9041EA,DV9042EA,DV9043EA,
DV9044EA,DV9045EA,DV9046EA,DV9048EA,DV9049EA,
DV9050EA,DV9051EA,DV9052EA,DV9053EA,DV9055EA,
DV9056EA,DV9057EA,DV9058EA,DV9059EA,DV9060EA,
DV9060US,DV9061EA,DV9062EA,DV9063EA,DV9064EA,
DV9065EA,DV9066EA,DV9067EA,DV9068EA,DV9069EA,
DV9071EA,DV9072EA,DV9073EA,DV9074CL,DV9074EA,
DV9075EA,DV9075EU,DV9075LA,DV9076EA,DV9076EU,
DV9077EA,DV9077EU,DV9078EA,DV9079EA,DV9080EA,
DV9081EA,DV9082EA,DV9082EU,DV9083EA,DV9084EA,

DV9085EA,DV9085EU,DV9086EA,DV9087EA,DV9088EA,
DV9089EA,DV9090EA,DV9091EA,DV9092EA,DV9093EA,
DV9093EU,DV9094EA,DV9095EU,DV9095XX,DV9096EA,
DV9096XX,DV9097EA,DV9097XX,DV9098XX,DV9099EA,
DV9099XX,DV9100,DV9200,DV9200XX,DV9201CA,DV9201TX,
DV9202EA,DV9202TX,DV9204TX,DV9205CA,DV9205EU,
DV9205US,DV9206EU,DV9206TX,DV9207TX,DV9207US
DV9208NR,DV9208TX,DV9209TX,DV9210CA,DV9210TX,
DV9210US,DV9211EA,DV9211TX,DV9212EA,DV9212TX,
DV9213EA,DV9213TX,DV9214EA,DV9214TX,DV9215TX,
DV9216EA,DV9216TX,DV9217EA,DV9217TX,DV9218EA,
DV9218TX,DV9219EA,DV9219TX,DV9220CA,DV9220EU,
DV9220TX,DV9220US,DV9221EA,DV9221TX,DV9225US,
DV9230US,DV9231CA,DV9232EU,DV9233CA,DV9233CL,
DV9233EU,DV9235NR,DV9237EU,DV9241EA,DV9243EA,
DV9244EA,DV9244EU,DV9248EA,DV9252EU,DV9253EA,
DV9254EU,DV9255EA,DV9260NR,DV9260US,DV9265EA,
DV9265LA,DV9266EA,DV9266EU,DV9267EA,DV9268EA,
DV9269EA,DV9271EA,DV9272EA,DV9273EA,DV9274EU,
DV9275EA,DV9275LA,DV9276EA,DV9283EA,DV9285EA,
DV9286EA,DV9287CL,DV9288EA,DV9289EA,DV9291EA, DV9292EU,DV9293EA,DV9294EA,DV92
94EU,DV9295EA,DV9295EU,DV9296EA,DV9296EU,DV9297EA,
DV9299EA,DV9299XX,DV9300,DV9301TX,DV9302TX,
DV9303EU,DV9303TX,DV9304EU,DV9304TX,DV9305EU,
DV9306TX,DV9307TX,DV9308EA,DV9308NR,DV9308TX,
DV9309EA,DV9309EU,DV9309TX,DV9310CA,DV9310EA,
DV9310EU,DV9310TX,DV9310US,DV9311EA,DV9311EU,
DV9311TX,DV9312EA,DV9312TX,DV9313EA,DV9314EA,
DV9315CA,DV9315EA,DV9316EA,DV9317CA,DV9317CL,
DV9317EA,DV9318CA,DV9318EA,DV9319EA,DV9320CA
DV9320EA,DV9320US,DV9321EA,DV9322EA,DV9324EA,
DV9330CA,DV9330US,DV9331EU,DV9332EA,DV9332EU,
DV9334US,DV9335NR,DV9337EU,DV9338EU,DV9339US,
DV9340EA,DV9341EU,DV9342EU,DV9343CA,DV9343EU,
DV9344EU,DV9345EU,DV9346EA,DV9347CL,DV9348EA,
DV9350EA,DV9351EA,DV9361EA,DV9362EA,DV9363EA,
DV9372EU,DV9374EU,DV9375EU,DV9377EA,DV9378EA,
DV9379EA,DV9380CA,DV9380EA,DV9381EA,DV9385EA,
DV9389EA,DV9390EA,DV9391EU,DV9392EA,DV9393EA,
DV9394EA,DV9395EA,DV9396EA,DV9397EA,DV9398EA,
V9398EU,DV9399EA,DV9400,DV9401XX,DV9407NR,
DV9408CA,DV9408NR,DV9410CA,DV9410US,DV9413CL,
DV9417CA,DV9417CL,DV9418CA,DV9420CA,DV9420US,
DV9428CA,DV9428NR,DV9429US,DV9438CA,DV9443CA,
DV9500,DV9500EW,DV9501AU,DV9501XX,DV9502XX,
DV9503AU,DV9505TX,DV9507TX,DV9508TX,DV9509TX,
DV9511TX,DV9512TX,DV9513TX,DV9515CA,DV9515EF,
DV9515EO,DV9516TX,DV9518EM,DV9518TX,DV9519TX,
DV9520EB,DV9520TX,DV9521EJ,DV9521TX,DV9522TX,
DV9525EN,DV9525EO,DV9525US,DV9530EB,DV9530EF,
DV9530EM,DV9532EM,DV9533EF,DV9535NR,DV9535US,

DV9540EB,DV9540US,DV9541EV,DV9542EV,DV9543CL,
DV9543EV,DV9547CL,DV9548CA,DV9548US,DV9550EO,
DV9550EP,DV9552ES,DV9555EG,DV9560EA,DV9560EG,
DV9560ER,DV9562EZ,DV9565EG,DV9570EL,DV9570EO,
DV9572EA,DV9574EA,DV9574LA,DV9575EF,DV9575EM,
DV9575EN,DV9575EO,DV9575EP,DV9575ES,DV9575LA
DV9575NR,DV9576EA,DV9580EE,DV9580EG,DV9580EL,
DV9580EN,DV9580EO,DV9580ET,DV9580EZ,DV9580US,
DV9581EE,DV9585EG,DV9585EL,DV9588EF,DV9590EA,
DV9590ED,DV9590EG,DV9590ER,DV9590ET,DV9590EZ,
DV9592EF,DV9595EA,DV9595ED,DV9596XX,DV9597XX,
DV9598XX,DV9599XX,DV9600,DV9601AU,DV9601TX,
DV9602AU,DV9602TX,DV9603AU,DV9603TX,DV9604AU,
DV9604TX,DV9605EF,DV9605EM,DV9605EO,DV9605TX,
DV9606CA,DV9606TX,DV9607TX,DV9607US,DV9608CA,
DV9608ES,DV9608NR,DV9608TX,DV9610CA,DV9610EB,
DV9610EF,DV9610EM,DV9610ET,DV9610EV,DV9610TX,
DV9610US,DV9611TX,DV9612CA,DV9612TX,DV9613TX,
DV9614CA,DV9614TX,DV9615CA,DV9615TX,DV9616CA,
DV9616TX,DV9617NR,DV9617TX,DV9618CA,DV9620EN,
DV9620ET,DV9620US,DV9623CA,DV9623CL,DV9623ED,
DV9625CA,DV9625ER,DV9625EW,DV9626US,DV9627CL,
DV9628CA,DV9628NR,DV9629CA,DV9630EB,DV9630ED,
DV9630EF,DV9630ET,DV9631EF,DV9631EM,DV9634CA,
DV9635CA,DV9635EF,DV9635EM,DV9638US,DV9639EO,
DV9640CA,DV9640US,DV9643EO,DV9644CA,DV9645ED,
DV9645EF,DV9645EM,DV9645EO,DV9646EM,DV9647EF,
DV9647EM,DV9649EF,DV9649EM,DV9650ES,DV9650US,
DV9651XX,DV9652XX,DV9653CL,DV9655EA,DV9655EO,
DV9655EZ,DV9657CL,DV9657EM,DV9657EO,DV9658EA
,DV9660EB,DV9660EF,DV9660EG,DV9660EI,DV9660EV,
DV9665EL,DV9665EO,DV9667EA,DV9670ED,DV9670EE,
DV9670EF,DV9670EL,DV9670EM,DV9670EO,DV9675EG,
DV9675EL,DV9675EO,DV9680ED,DV9680EF,DV9680EP,
DV9680EV,DV9680EW,DV9680EZ,DV9681ER,DV9682EG,
DV9684EG,DV9685EO,DV9686EO,DV9687EO,DV9688EG,
DV9689EA,DV9690EE,DV9690EI,DV9690EL,DV9690EN,
DV9690EV,DV9690EW,DV9690EZ,DV9691EG,DV9694EG,
DV9695EA,DV9695EF,DV9695EG,DV9695EL,DV9695EO,
DV9698EO,DV9699EF,DV9700,DV9700T,DV9700Z,
DV9701AU,DV9701AX,DV9701TX,DV9701XX,DV9702AU,
DV9702AX,DV9702TX,DV9702XX,DV9703AX,DV9703TX,
DV9703XX,DV9704AX,DV9704TX,DV9705AX,DV9705TX,
DV9706AX,DV9706TX,DV9711TX,DV9712TX,DV9714TX,
DV9715NR,DV9715TX,DV9716TX,DV9717TX,DV9718TX,
DV9719TX,DV9720CA,DV9720TX,DV9720US,DV9723CA,
DV9723CL,DV9724CA,DV9727CL,DV9727TX,DV9727US,
DV9728CA,DV9728CL,DV9728TX,DV9729TX,DV9730CA,
DV9730NR,DV9730TX,DV9730US,DV9731CA,DV9732TX,
DV9733TX,DV9734NR,DV9735TX,DV9736CA,DV9736TX,
DV9737TX,DV9738TX,DV9740CA,DV9740TX,DV9740US,

DV9741TX,DV9742TX,DV9743CL,DV9743TX,DV9744CA,
DV9744TX,DV9745TX,DV9746TX,DV9747CL,DV9747TX,
DV9748CA,DV9750US,DV9751XX,DV9758CA,DV9770LA,
DV9774CA,DV9775LA,DV9780LA,DV9785LA,DV9800,
DV9803TX,DV9804CA,DV9808CA,DV9808TX,DV9809TX,
DV9810CA,DV9810TX,DV9810US,DV9811TX,DV9812TX,
DV9812US,DV9813TX,DV9814TX,DV9815NR,DV9815TX,
DV9817CL,DV9818TX,DV9819TX,DV9819WM,DV9820TX,
DV9820US,DV9821TX,DV9822TX,DV9823CA,DV9823CL,
DV9823TX,DV9824CA,DV9825NR,DV9827CL,DV9830US,
DV9831CA,DV9834CA,DV9838CA,DV9843CL,DV9847CA,
DV9851XX,DV9854CA,DV9858CA,DV9894CA,DV9899XX,
DV9900,DV9901TX,DV9903CA,DV9904CA,DV9907CA,
DV9908CA,DV9910CA,DV9910US,DV9912NR,DV9913CL,
DV9917CL,DV9920US,DV9922US,DV9924CA,DV9925NR,
DV9927CL,DV9930US,DV9933CA,DV9933CL,DV9933NR,
DV9934CA,DV9999US,TX1000,TX1100,TX1200,TX2600,
V9500T,V9500Z,X1000,ZE2000,ZE2300,ZE2308,ZE2315,
ZE4900,ZT3000,ZT3010,ZT3020,ZT4000,ZT4900, serija Tablet PC
M2000,TC1000,TC1100,TC4200, LG P300,R200,R405,R410,R500,R510,R700,S1