

**VOLTAIC ACER nešiojamo kompiuterio įkroviklis 90W, 19V, 4.74A (5.5mm x 1.7mm)**

Generuota 2024-05-09



**Pavadinimas**

**IŠSAMIAU**

**Aprašymas**

Įkroviklis skirtas kompiuterių modeliams: Acer Aspire 1410. Acer Aspire 1640. Acer Aspire 1640Z. Acer Aspire 1650. Acer Aspire 1650Z. Acer Aspire 1680. Acer Aspire 1690. Acer Aspire 1690-II. Acer Aspire 2000. Acer Aspire 2010. Acer Aspire 2012WLCi. Acer Aspire 2020. Acer Aspire 2420. Acer Aspire 2920. Acer Aspire 3000. Acer Aspire 3030. Acer Aspire 3050. Acer Aspire 3100. Acer Aspire 3200. Acer Aspire 3500. Acer Aspire 3510. Acer Aspire 3610. Acer Aspire 3620. Acer Aspire 3628AWXCI. Acer Aspire 3630. Acer Aspire 3650. Acer Aspire 3660. Acer Aspire 3670. Acer Aspire 3680. Acer Aspire 3935. Acer Aspire 3935-6504. Acer Aspire 3935-744G25Mn. Acer Aspire 3935-864G32Mn. Acer Aspire 3935-CF61. Acer Aspire 3935-CF61F. Acer Aspire 4220. Acer Aspire 4310. Acer Aspire 4315. Acer Aspire 4320. Acer Aspire 4520. Acer Aspire 4710. Acer Aspire 4710Z. Acer Aspire 4720. Acer Aspire 5000. Acer Aspire 5030. Acer Aspire 5050. Acer Aspire 5100. Acer Aspire 5310. Acer Aspire 5315. Acer Aspire 5500. Acer Aspire 5500Z. Acer Aspire 5510. Acer Aspire 5520. Acer Aspire 5535. Acer Aspire 5535-704G32Mn. Acer Aspire 5570. Acer Aspire 5570Z. Acer Aspire 5580. Acer Aspire 5710. Acer Aspire 5710Z. Acer Aspire 5715Z. Acer Aspire 5720. Acer Aspire 7100. Acer Series: Aspire 9000. Acer Aspire 9400. Acer Series: Aspire One 751. Acer Aspire One 751. Acer Aspire One 751-Bk23. Acer Aspire One 751-Bk23F. Acer Aspire One 751-Bk26. Acer Aspire One 751-Bk26F. Acer Aspire One 751-Bw23. Acer Aspire One 751-Bw23F. Acer Aspire One 751-Bw26. Acer Aspire One 751-Bw26F. Acer Series: Aspire One 751h. Acer Aspire One 751h. Acer Aspire One 751h-1021. Acer Aspire One 751h-1080. Acer Aspire One 751h-1153. Acer Aspire One 751h-1192. Acer Aspire One 751h-1196. Acer Aspire One 751h-1211. Acer Aspire One 751h-1259. Acer Aspire One 751h-1273. Acer Aspire One 751h-1279. Acer Aspire One 751h-1346. Acer Aspire One 751h-1351. Acer Aspire One 751h-1373. Acer Aspire One 751h-1378. Acer Aspire One 751h-1401. Acer Aspire One 751h-1442. Acer Aspire One 751h-1522. Acer Aspire One 751h-1885. Acer Aspire One 751h-1893. Acer Aspire One 751h-1948. Acer Aspire One 751h-52Bb. Acer Aspire One 751h-52Bk. Acer Aspire One 751h-52Br. Acer Aspire One 751h-52Bw. Acer Series: Aspire One A110. Acer Aspire One. Acer Aspire One A110. Acer Aspire One A110-1041. Acer Aspire One A110-1137. Acer Aspire One A110-1283. Acer Aspire One A110-1295. Acer Aspire One A110-1588. Acer Aspire One A110-1626. Acer Aspire One A110-1662. Acer Aspire One A110-1691. Acer Aspire One A110-1698. Acer Aspire One A110-1722. Acer Aspire One A110-1812. Acer Aspire One A110-1831. Acer Aspire One A110-1834. Acer Aspire One A110-1948. Acer Aspire One A110-1982. Acer Aspire One A110-1995. Acer Aspire One A110-AGb. Acer Aspire One A110-AGc. Acer Aspire One A110-Ab. Acer Aspire One A110-Ac. Acer Aspire One A110-BGb. Acer Aspire One A110-Bb. Acer Aspire One A110-Bc. Acer Aspire one A110L. Acer Aspire one A110L blau. Acer Aspire one A110X. Acer Aspire one A110X Black Edition. Acer Series: Aspire One A150. Acer Aspire One A150. Acer Aspire One A150-1001. Acer Aspire One A150-1006. Acer Aspire One A150-1029. Acer Aspire One A150-1035. Acer Aspire One A150-1049. Acer Aspire One A150-1068. Acer Aspire One A150-1083. Acer Aspire One A150-1126. Acer Aspire One A150-1140. Acer Aspire One A150-1141. Acer Aspire One A150-1172. Acer Aspire One A150-1178. Acer Aspire One A150-1249. Acer Aspire One A150-1316. Acer Aspire One A150-1329. Acer Aspire One A150-1348. Acer Aspire One A150-1359. Acer Aspire One A150-1382. Acer Aspire One A150-1400. Acer Aspire One A150-1405. Acer Aspire One A150-1435. Acer Aspire One A150-1444. Acer Aspire One A150-1447. Acer Aspire One